

**E5CK**

**Digital Controller  
(Programmable Type)**

**USERS MANUAL**

**OMRON**

# Preface

The E5CK-T is a high-performance programmable digital controller. The E5CK-T allows the user to carry out the following:

- Set program patterns to each step by time or ramp rise rate
- Execute advance, hold and reset step operations
- Execute continuous operation of all patterns and repeated operation of same patterns
- Check the start of each step or program end time by signals.
- Count time from the beginning of each step (time signal)
- Select from many types of temperature and analog input (multi-input)
- Select output functions such as control output or alarm output (output assignment)
- Monitor the control loop by LBA (Loop Break Alarm)
- Use the communications function
- Calibrate input or transfer output
- The E5CK-T also features a watertight construction (NEMA4: equivalent to IP66).

This User's Manual describes how to use the E5CK-T.

Before using your E5CK-T thoroughly read and understand this manual in order to ensure correct use.

Also, store this manual in a safe place so that it can be retrieved whenever necessary.

## PRECAUTIONS IN USING THE PRODUCT

When the product is used under the circumstances or environment below, ensure adherence to limitations of the ratings and functions. Also, take countermeasures for safety precautions such as fail-safe installations.

- (1) Use under circumstances or environments which are not described in this user's manual.
- (2) Use for nuclear power control, railway, air craft, vehicle, incinerator, medical equipment, entertainment equipment, safety device, etc.
- (3) Use for applications where death or serious property damage is possible and extensive safety precautions are required.

### About this manual

- (1) All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.
- (2) Moreover, because OMRON is constantly striving to improve its high-quality products, the information in this manual is subject to change without notice.
- (3) Every precaution has been taken in the preparation of this manual. Nevertheless, if you find any errors or omissions, please contact the branch of OMRON or sales office listed at the end of this manual, and inform them of the catalog No. on the front cover.

# Conventions Used in This Manual

## ■ Meanings of Abbreviations

Sometimes the following abbreviations are used in parameter names, figures and in text explanations. These abbreviations mean the following:

Symbol	Term
PV	Process value
SP	(Present) set point *1
LBA	Loop break alarm
AT	Auto-tuning
EU	Engineering unit *2

\*1 In program pattern diagrams, the present SP is indicated.

\*2 °C, m, g and other units are indicated for scaled data. However, “EU” is used as the minimum unit for the data. For example, for “50.02 (m)”, 1EU is taken as the minimum unit 0.01 (m).

## ■ How to Read Display Symbols


The following tables show the correspondence between the symbols displayed on the displays and alphabet characters.

A	b	c	d	E	F	G	H	I	J	K	L	M
A	B	C	D	E	F	G	H	I	J	K	L	M

n	o	P	q	r	S	t	U	v	w	X	Y	Z
N	O	P	Q	R	S	T	U	V	W	X	Y	Z

## ■ “Reference” mark

This mark indicates that extra, useful information follows, such as supplementary explanations and how to apply functions.



## ■ How This Manual is Organized

Purpose	Title	Description
<ul style="list-style-type: none"> <li>• <b>Learning about the general features of the E5CK-T</b></li> </ul>	Chapter 1 INTRODUCTION	This chapter describes the features of the E5CK-T, names of parts, and typical functions.
<ul style="list-style-type: none"> <li>• <b>Setting up</b></li> </ul>	Chapter 2 PREPARATIONS	This chapter describes the operations that you must carry out (e.g. installation, wiring and switch settings) before you can use the E5CK-T.
<ul style="list-style-type: none"> <li>• <b>Basic E5CK-T operations</b></li> </ul>	Chapter 3 BASIC OPERATION Chapter 5 PARAMETERS	These chapters describe using basic control examples how to use the front panel keys and how to view the display when setting the parameters of the major functions for the E5CK-T.
<ul style="list-style-type: none"> <li>• <b>Applied E5CK-T operations</b></li> </ul>	Chapter 4 APPLIED OPERATION Chapter 5 PARAMETERS	These chapters describes the important functions of the E5AK-T and how to use the parameters for making full use of the E5CK-T.
<ul style="list-style-type: none"> <li>• <b>Communications with a host computer</b></li> </ul>	Chapter 6 USING THE COMMUNICATIONS FUNCTION	This chapter mainly describes how to use the communications commands, and gives program examples.
<ul style="list-style-type: none"> <li>• <b>Calibration</b></li> </ul>	Chapter 7 CALIBRATION	This chapter describes how the user should calibrate the E5CK-T.
<ul style="list-style-type: none"> <li>• <b>Troubleshooting</b></li> </ul>	Chapter 8 TROUBLE-SHOOTING	This chapter describes what to do if any problems occur.

## PRECAUTIONS ON SAFETY

### ● Marks For Ensuring Safe Use and Their Meanings

This manual uses the following marks to indicate precautions for ensuring that the E5CK-T is used safely.

The precautions indicated below describe important information regarding safety. Be sure to follow the instructions described in these precautions.



### **WARNING**

Incorrect handling may cause death or injury.



### **WARNING**

Do not touch the terminals while the power is ON.  
This may cause an electric shock.

# NOTICE

Be sure to observe these precautions to ensure safe use.

- Do not use the product in places where explosive or flammable gases may be present.
- Never disassemble, repair or modify the product.
- Tighten the terminal screws properly.
- Use the specified size of solderless terminals for wiring.
- Use the product within the rated supply voltage.
- Use the product within the rated load.
- The life expectancy of the output relay varies considerably according to its switching capacity and operating conditions. Be sure to use the output relay within its rated load and electrical life expectancy. If the output relay is used beyond its life expectancy, its contacts may become fused or burned.
- If you remove the controller from its case, never touch nor apply shock to the electronic parts inside.
- Do not cover the E5CK-T. (Ensure sufficient space around the controller to allow heat radiation.)
- Do not use the controller in the following places:
  - Places subject to icing, condensation, dust, corrosive gas (especially sulfide gas or ammonia gas).
  - Places subject vibration and large shocks.
  - Places subject to splashing liquid or oil atmosphere.
  - Places subject to intense temperature changes.
  - Places subject to heat radiation from a furnace.
- Be sure to wire properly with correct polarity of terminals.
- When wiring input or output lines to your controller, keep the following points in mind to reduce the influence from inductive noise:
  - Allow adequate space between the high voltage/current power lines and the input/output lines.
  - Avoid parallel or common wiring with high voltage sources and power lines carrying large currents.
  - Using separating pipes, ducts, and shielded line is also useful in protecting the controller, and its lines from inductive noise.
- Cleaning: Do not use paint thinner or organic solvents. Use standard grade alcohol to clean the product.
- Use a voltage (100 to 240 VAC at 50 to 60 Hz). At power ON, the prescribed voltage level must be attained within two seconds.
- Allow as much space as possible between the controller and devices that generate a powerful high frequency (high-frequency welders, high-frequency sewing machines, etc.) or surge. These devices may cause malfunctions.
- If there is a large power-generating peripheral device and any of its lines near the controller, attach a surge suppressor or noise filter to the device to stop the noise affecting the controller system. In particular, motors, transformers, solenoids and magnetic coils have an inductance component, and therefore can generate very strong noise.
- When mounting a noise filter on the power supply to the controller, be sure to first check the filter's voltage and current capacity, and then mount the filter as close as possible to the controller.

- Use within the following temperature and humidity ranges:
  - Temperature:  $-10^{\circ}\text{C}$  to  $55^{\circ}\text{C}$ , humidity: 35%RH to 85%RH (with no icing or condensation)  
If the controller is installed inside a control board, the ambient temperature must be kept to under  $55^{\circ}\text{C}$ , including the temperature around the controller.  
If the controller is subjected to heat radiation, use a fan to cool the surface of the controller to under  $55^{\circ}\text{C}$ .
- Store within the following temperature and humidity ranges:
  - Temperature:  $-25^{\circ}\text{C}$  to  $65^{\circ}\text{C}$ , humidity: 35%RH to 85%RH (with no icing or condensation)
- Never place heavy objects on, or apply pressure to the controller that may cause it to deform and deteriorate during use or storage.
- Avoid using the controller in places near a radio, television set, or wireless installation. These devices can cause radio disturbances which adversely affect the performance of the controller.

# Table of Contents

Preface .....	I
Conventions Used in This Manual .....	II
Precautions on Safety .....	IV

## CHAPTER 1 INTRODUCTION ..... 1-1

This chapter introduces the names of parts on the E5CK-T and their functions. For details on how to use the controller and parameter settings, see Chapter 2 onwards.

1.1 Names of parts .....	1-2
1.2 Input and Output .....	1-5
1.3 Program .....	1-7
1.4 Parameters and Menus .....	1-8
1.5 About the Communications Function .....	1-11
1.6 About Calibration .....	1-12

## CHAPTER 2 PREPARATIONS ..... 2-1

This chapter describes the operations (e.g. setup, installation and wiring) you should carry out before turning the E5CK-T ON.

2.1 Setup .....	2-2
2.2 Installation .....	2-4
2.3 Wiring Terminals .....	2-6

## CHAPTER 3 BASIC OPERATION ..... 3-1

This chapter describes actual examples for understanding the basic operation of the E5CK-T.

3.1 Convention Used in this Chapter .....	3-2
3.2 Setting Input Specifications .....	3-4
3.3 Setting Output Specifications .....	3-7
3.4 Setting Alarm Type .....	3-9
3.5 Setting Patterns .....	3-13
3.6 Protect Mode .....	3-18
3.7 Starting and Stopping Operation .....	3-20
3.8 Adjusting Control Operation .....	3-21

## CHAPTER 4 APPLIED OPERATION ..... 4-1

This chapter describes each of the parameters required for making full use of the features of the E5CK-T.  
Read this chapter while referring to the parameter descriptions in chapter 5.

4.1 Selecting the Control Method .....	4-2
4.2 Operating Condition Restrictions .....	4-5
4.3 Ramp Rise Rate Setup Program .....	4-7
4.4 Program Operation .....	4-10



4.5	Program output .....	4-13
4.6	Setting Running Conditions .....	4-15
4.7	How to Use Event Input .....	4-17
4.8	LBA .....	4-19
4.9	How to Use Transfer Output .....	4-21
<b>CHAPTER 5 PARAMETERS .....</b>		<b>5-1</b>
This chapter describes the parameters of the E5CK-T. Use this chapter as a reference guide.		
	Conventions Used in this Chapter .....	5-2
	Protect Mode .....	5-3
	Manual Mode .....	5-5
	Level 0 Mode .....	5-6
	Program Mode .....	5-11
	Level 1 Mode .....	5-17
	Level 2 Mode .....	5-22
	Setup Mode .....	5-28
	Expansion Mode .....	5-36
	Option Mode .....	5-44
	Calibration Mode .....	5-48
<b>CHAPTER 6 USING THE COMMUNICATIONS FUNCTION ..</b>		<b>6-1</b>
This chapter mainly describes communications with a host computer and communications commands.		
6.1	Outline of the Communications Function .....	6-2
6.2	Preparing for Communications .....	6-3
6.3	Command Structure .....	6-5
6.4	Commands and Responses .....	6-7
6.5	How to Read Communications Error Information .....	6-15
6.6	Program Example .....	6-17
<b>CHAPTER 7 CALIBRATION .....</b>		<b>7-1</b>
This chapter describes procedures for each calibration operation. Read this chapter only when the controller must be calibrated.		
7.1	Parameter Structure .....	7-2
7.2	Calibrating Thermocouples .....	7-4
7.3	Calibrating Platinum Resistance Thermometers .....	7-7
7.4	Calibrating Current Input .....	7-9
7.5	Calibrating Voltage Input .....	7-10
7.6	Checking Indication Accuracy .....	7-12

CHAPTER 8 TROUBLESHOOTING ..... 8-1

This chapter describes how to find out and remedy the cause if the E5CK-T does not function properly.  
Remedy E5CK-T trouble in the order of the descriptions in this chapter

8.1	Initial Checks .....	8-2
8.2	How to Use the Error Display .....	8-3
8.3	How to Use the Error Output .....	8-5
8.4	Checking Operation Restrictions .....	8-6

APPENDIX

SPECIFICATIONS .....	A-2
CONTROL BLOCK DIAGRAM .....	A-5
SETTING LIST .....	A-6
MODEL LIST .....	A-10
PARAMETER OPERATIONS LIST .....	A-11
ASCII CODE LIST .....	A-13

INDEX

REVISION HISTORY

# *K* CHAPTER 1

## *INTRODUCTION*


This chapter introduces the names of parts on the E5CK-T and their functions.

For details on how to use the controller and parameter settings, see Chapter 2 onwards.


1.1	Names of parts .....	1-2
	Main parts .....	1-2
	Front panel .....	1-2
	About the displays .....	1-3
	How to use keys .....	1-4
1.2	Input and Output .....	1-5
	Input .....	1-5
	Output .....	1-6
1.3	Program .....	1-7
1.4	Parameters and Menus .....	1-8
	Parameter types .....	1-8
	Selecting modes .....	1-9
	Selecting parameters .....	1-10
	Fixing settings .....	1-10
1.5	About the Communications Function ....	1-11
1.6	About Calibration .....	1-12

## 1.1 Names of parts

### ■ Main parts



### ■ Front panel



## ■ About the displays

- **No.1 display**      Displays the process value or parameter symbols.
- **No.2 display**      Displays the set point, manipulated variable or parameter settings.
- **Operation status indicators**
  - OUT1  
Lights when the pulse output function assigned to “control output 1” is ON.
  - OUT2  
Lights when the pulse output function assigned to “control output 2” is ON.
  - SUB1  
Lights when the pulse output function assigned to “auxiliary output 1” is ON.
  - MANU  
Lights in the manual operation mode.
  - RST  
Lights when the control is in reset status.
  - RMT  
Lights during remote operation.
  - AT  
Flashes during auto-tuning.

## ■ How to use keys

The following describes basic key operations.

### ● key

To change to run operation from the reset status, press this key for one second minimum.



To change to the reset status from run operation, press this key for two seconds minimum.



### ● key

The functions of this key change according to how long it is pressed. If the key is pressed for less than one second, the parameters are switched. If the key is pressed for one second minimum, the menu display appears. In key operations from here on, “press the key” refers to pressing the key for less than one second.


For details on switching of parameters and menu display items, see page 1-10.

### ● key

Each press of  key increments or advances the values or settings on the No.2 display, while each press of the  key decrements or returns the values or settings on the No.2 display.

Functions vary, for example, when the  key is held down simultaneously with the  key, or a key is held down continuously. For details, see page 1-10. Also, chapters 3 and 4 describe examples using various key combinations.

## 1.2 Input and Output



### ■ Input

The E5CK-T supports the following inputs:

Temperature input, Current input, Voltage input, and Event input.

#### ● Temperature input/Voltage input/Current input

- Only one of temperature input, current input and voltage input can be selected and connected to the controller. In the above figure, temperature input is selected.
- The following input sensors can be connected for temperature input:  
Thermocouple: K, J, T, E, L, U, N, R, S, B, W, PLII  
Platinum resistance thermometer: JPt100, Pt100
- The following currents can be connected for current input:  
4 to 20 mA, 0 to 20 mA
- The following voltages can be connected for voltage input:  
1 to 5 VDC, 0 to 5 VDC, 0 to 10 VDC

#### ● Event input

Add on the input unit (E53-CKB) when using event input. You can select from the following five event inputs:

Run/Reset, Auto/Manual, Hold/Hold Cancel, Advance, Pattern

## ■ Output

The output functions of the E5CK-T do not operate for five seconds after the E5CK-T is turned ON.

The E5CK-T supports the following five outputs:

- Control output 1
- Control output 2
- Auxiliary output 1
- Transfer output

When using control output 1 and 2, set the output unit (sold separately).

Nine output units are available to suit the output circuit configuration.

When using transfer output, add on the communication unit (E53-AKF).

### ● Output assignments

- The E5CK-T supports the following twelve output functions:  
Control output (heat), Control output (cool), Alarms 1 to 3, LBA, Time Signals 1 and 2, Program End, Stage Output, Error 1 (input error), Error 2 (A/D converter error)
- Assign these output functions to control output 1, control output 2 and auxiliary output 1.
- Only control output (heat), control output (cool), alarms 1 to 3 and LBA can be assigned to control outputs 1 and 2. Only alarms 1 to 3, LBA, error 1 and error 2 can be assigned to auxiliary output 1.  
In the example on the previous page, "control output (heat)" is assigned to "control output 1", "alarm 1" is assigned to "control output 2", and "alarm 2" is assigned to "auxiliary output 1". Accordingly, the configuration is such that heating control output is connected to control output 1, and alarm output is connected to control output 2 and auxiliary output 1.
- When the control is heating and cooling control, assign "control output (cool)" to "control output 1" or "control output 2".

### ● Transfer output


- The E5AK-T supports the following four transfer outputs:  
Present SP, Process value, Heating side manipulated variable, Cooling side manipulated variable
- These transfer outputs can be output after being scaled. Setting of an upper limit value smaller than the lower limit value is allowed, so reverse scaling can also be carried out.



## 1.3 Program

### ■ How programs are structured

E5CK-T allows you to configure programs made up of a maximum of four patterns (pattern 0 to 3) each comprising a maximum of 16 steps. The number of patterns and steps in each pattern can be specified in parameters.



- Generally, the “time setup method” is used to configure programs. By this method, set points at each step and time are used as program elements. However, the “ramp rise rate setup method” can also be used. By this method, the set point, ramp time and soak times are used as program elements.

### ■ Program operation

- Generally, the target patterns are specified before the program is executed.
- In parameter setup, you can specify repeated execution of the same pattern (Repeat) or consecutive execution of all patterns 0 to 4 (Run all).

#### ● Step operation

- During program operation, steps can be skipped (Advance) and the control monitoring can be paused (Hold).

### ■ Alarm output

- Alarms that are assigned as outputs operate referenced to the alarm values preset to each pattern.

### ■ Program output

- Time signals, program end and stage output can be output according to output assignment.
- ON/OFF signals are output as time signals according to the timer that takes a specified step as its start point.

## 1.4 Parameters and Menus

### ■ Parameter types

E5CK-T parameters are distributed between the following ten modes:

- Protect mode
- Manual mode
- Level 0 mode
- Program mode
- Level 1 mode
- Level 2 mode
- Setup mode
- Expansion mode
- Option mode
- Calibration mode

The settings of parameters in each of eight modes (excluding the protect mode and manual mode) can be checked and modified by selection on the menu display.

#### ● Protect mode

The protect function is for preventing unwanted modification of parameters, and switching between run and reset operation or auto and manual operation.

#### ● Manual mode

In this mode, the controller can be switched to manual operation. The manipulated variable can be manipulated manually only in this mode.

#### ● Level 0 mode

Set the controller to this mode during normal operation. In this mode, you can change the set point and pattern during operation, and execute step operation (e.g. advance). You can only monitor (not change) the process value, step No., standby time, pattern elapsing time, pattern execution count and manipulated variable.

#### ● Program mode

This is the programming mode. In this mode, you can set the number of steps used in each pattern, pattern execution count, alarm values, set points for each step, step time, and time signals for two steps.

#### ● Level 1 mode

This is the main mode for adjusting control. In this mode, you can execute AT (auto-tuning), and set up the control period, PID parameters.

#### ● Level 2 mode


This is the auxiliary mode for adjusting control. In this mode, you can set the parameters for limiting the manipulated variable, switch between the remote and local modes, and set the loop break alarm (LBA), alarm hysteresis and the digital filter value of inputs.

#### ● Setup mode

This is the mode for setting the basic specifications. In this mode, you can set parameters that must be checked or set before operation such as the input type, scaling, output assignments and direct/reverse operation.

- Expansion mode** This is the mode for setting expanded functions. In this mode, you can set SP setting limiter, switching between advanced PID control or ON/OFF control, program time unit, selection of step time/rate of rise programming, time unit of ramp rise rate, and the time for automatic return to the monitoring display.
- Option mode** This is the mode for setting optional functions. You can select this mode only when an option unit is mounted in the controller. In this mode, you can set the communications conditions, transfer output and event input parameters to match the type of option unit mount in the controller.
- Calibration mode** This mode is provided so that the user can calibrate inputs and output. When calibrating input, the selected input type is calibrated. Whereas, transfer output can be calibrated only when the communication unit (E53-CKF) is set in the controller.

**■ Selecting modes** The following diagram shows the order in which modes are selected.



- To select the menu display in any of the above modes (excluding the protect mode and manual mode), press the **[F]** key for 1 second minimum. When you have selected the menu display, the previous mode is selected. For example, if you selected the menu display while in the level 0 mode, the No.2 display changes to [Lv-0] as shown on the left.
- To move to the desired mode after you have entered the menu display, select the desired mode using the **[F]** **[F]** keys and hold down the **[F]** key for one second minimum. The display switches to the first parameter of the mode that you specified.
- Protected modes cannot be selected. Also, the menu display does not appear when modes are protected up to the program mode.

- If you select [L 0 - 0], [P r G n], [L 0 - 1] or [L 0 - 2] in the menu display, the level 0, program, level 1 and level 2 modes, respectively, are selected. These modes are selected with control still continuing.


- If you select [SEt] [ESt] [dPt] or [L b] in the menu display, the setup, expansion, option and calibration modes, respectively, are selected.

When these modes are selected, the control is reset. So, control outputs and auxiliary output are turned OFF. When another mode is selected while in these modes control, reset is canceled.

- To set the controller to the protect mode or to return to the level 0 mode from the protect mode, press the [RUN/RST] key and the [↩] key simultaneously for 1 second minimum.
- To set the controller to the manual mode, press the [↗] key for one second minimum with the [↩] key held down in the level 0 to 2 modes. To return to the level 0 mode in the manual mode, press the [↗] key for one second minimum with the [↩] key pressed. Be sure to press the [↩] key first in this operation.

## ■ Selecting parameters

- When the controller is not in the manual mode, each press of the [↩] key switches the parameter in the respective mode.



## ■ Fixing settings

- If you press the [↩] key when at the final parameter, the display returns to the top parameter for the current mode.
- When you change parameter settings or contents, specify the parameter using the [↗] or [↘] keys, and either leave the setting for at least two seconds or press the [↩] key. This fixes the setting.
- When another mode is selected, the content of the parameters before the mode was selected is fixed.
- When you turn the power OFF, you must first fix the settings and parameter contents (by pressing the [↩] key or selecting another mode). The settings and parameter contents are sometimes not changed by merely pressing the [↗] or [↘] keys.

## 1.5 About the Communications Function

The E5CK-T can be provided with a communications function that allows you to check and set controller parameters from a host computer. If the communications function is required, add on the communications unit. For details on the communications function, refer to Chapter 6.

### ● RS-232C

When using the communications function on the RS-232C interface, add on the communications unit (E53-CK01).

### ● RS-485

When using the communications function on the RS-485 interface, add on the communications unit (E53-CK03).

## 1.6 About Calibration

---

The E5CK-T controller is calibrated before shipment from the factory. So, the user need not calibrate the E5CK-T controller during regular use.

However, if the E5CK-T controller must be calibrated by the user, use the parameters provided for the user to calibrate temperature input, analog input (voltage, current) and transfer output. In this case, note that the results of calibration will not be assured.

Also, note that calibration data is updated to the latest value each time that the E5CK-T controller is calibrated. Calibration data set before shipment from the factory cannot be returned to after calibration by the user.

### ● Calibrating inputs

The input type selected in parameters is the item to be calibrated. The E5CK-T is provided with the following four calibration parameters:

- Thermocouple
- Platinum resistance thermometer
- Current input
- Voltage input

Two parameters are provided for thermocouple and voltage input.

### ● Calibrating transfer output

Transfer output also can be calibrated when the communications unit (E53-CKF) is added on.

### ● Registering calibration data

When calibrating each item, the calibration data is temporarily registered. This data can be registered as final calibration data only when all items have been newly calibrated. So, all items must be temporarily registered when the E5CK-T controller is calibrated.

When registering data, information regarding whether or not calibration has been carried out is also registered.

To calibrate these items, the user must prepare separate measuring devices and equipment. For details on handling these measuring devices and equipment, refer to the respective manuals.

For details, see Chapter 7 Calibration.

# K CHAPTER 2

## PREPARATIONS

This chapter describes the operations (e.g. setup, installation and wiring) you should carry out before turning the E5CK-T ON.

2.1	Setup .....	2-2
	Draw-out .....	2-2
	Setting the input type jumper .....	2-2
	Setting up the output unit .....	2-3
	Setting up the option unit .....	2-3
2.2	Installation .....	2-4
	Dimensions .....	2-4
	Panel cutout .....	2-4
	Mounting .....	2-5
2.3	Wiring Terminals .....	2-6
	Terminal arrangement .....	2-6
	Precautions when wiring .....	2-6
	Wiring .....	2-6


## 2.1 Setup

### ■ Draw-out

The following section describes how to draw out the internal mechanism from the housing and how to set the input type jumper.

Draw out the internal mechanism from the housing.

- (1) Press in both of the hooks on the left and right sides of the front panel to unlock the internal mechanism from the housing.




- (2) Draw out the internal mechanism towards you holding both sides of the front panel.

### ■ Setting the input type jumper

- For details on where the input type jumper is located, see the figure on page 1–2.
- Set the jumper to one of temperature input, voltage input or current input matched to the type of sensor connected to the input terminal.

I : Current input      V : Voltage input



TC/PT : Temperature input

- The input type jumper is factory-set to “TC/PT (temperature input)”.
- When you disconnect or insert the input type jumper, do not hold it directly by its pins.
- When you have finished setting the input type jumper, insert the internal mechanism back into the housing.
- To do this, push in the internal mechanism until you hear the hooks on the front panel snap into place.




## ■ Setting up the output unit

### ● Output unit list

The following table shows the output units that can be set in the E5CK controller.

Model	Specifications (control output 1/control output 2)
E53-R4R4	Relay/Relay
E53-Q4R4	Voltage (NPN)/Relay
E53-Q4HR4	Voltage (PNP)/Relay
E53-C4R4	4 to 20 mA/Relay
E53-C4DR4	0 to 20 mA/Relay
E53-V44R4	0 to 10 V/Relay
E53-Q4Q4	Voltage (NPN)/Voltage (NPN)
E53-Q4HQ4H	Voltage (PNP)/Voltage (PNP)

### ● Setup



- (1) Two rectangular holes for slotting are provided on the power board (on right side of controller). Fit the two protrusions on the output unit into these two holes.
- (2) With the output unit fitted into the power board, fit the output unit into the connector on the control board (on left side of controller).


## ■ Setting up the option unit

### ● Option unit list

The following table shows the option units that can be connected to the E5CK controller.

Unit	Model	Specifications
Communications unit	E53-CK01	Communications (RS-232C)
Communications unit	E53-CK03	Communications (RS-485)
Input unit	E53-CKB	Event input: 1 input
Communications unit	E53-CKF	Transfer output: 4 to 20 mA


### ● Setup




- (1) Place the controller with its bottom facing up, and fit the board horizontally into the connector on the power board (on right side of controller).
- (2) With the power board connected, fit the board vertically into the connector on the control board (on left side of controller).

## 2.2 Installation

### ■ Dimensions




### ■ Panel cutout



- Recommended panel thickness is 1 to 5 mm.
- Maintain the specified vertical and horizontal mounting space between each controller. Controllers must not be closely mounted vertically or horizontally.

## ■ Mounting




- (1) Insert the E5CK controller into the mounting hole in the panel at the position shown in the figure above.
- (2) Push the adapter along the controller body from the terminals up to the panel, and fasten temporarily.
- (3) Tighten the two fixing screws on the adapter. When tightening screws, tighten the two screws alternately keeping the torque to approximately 0.29 to 0.39 N·m, or 3 to 4 kgf·cm.




### About the Terminal Cover

E5CK-AA1-500 controller is provided with a terminal cover (E53-COV07). Fasten the terminal cover as follows by using the snap pin.




## 2.3 Wiring Terminals

### ■ Terminal arrangement



### ■ Precautions when wiring

- Separate input leads and power lines in order to protect the controller and its lines from external noise.
- We recommend using solderless terminals when wiring the controller.
- Tighten the terminal screws using a torque no greater than 0.78 N·m (8kgf·cm).
- Use the following type of solderless terminals for M3.5 screws.



### ■ Wiring

#### ● Power supply

5	11	12	10
4			9
3			8
2			7
1	13	14	6

In the following wiring diagrams, the left side of the terminal Nos. indicates the inside of the controller.


- Input power to terminals Nos. 4 and 5. Power specifications are as follows:  
100 to 240 VAC, 50/60 Hz, 15 VA  
or  
24 VAC, 50/60 Hz, 6 VA  
24 VDC, 3.5W



About the power blocks

The E5CK has independent power supplies for each of the terminal blocks shown on the right. However, note that the power supplies for blocks C (exclude relay output) and D are shared for the following option unit.


- Option unit : E53-CKB or E53-CKF



### ● Input

5	11	12	10
4			9
3			8
2			7
1	13	14	6

- Connect the sensor input to terminal Nos. 6 to 8 as follows according to the input type.




- Set the input type jumper inside the controller matched to the input type. Set thermocouples and platinum resistance thermometer as temperature input to the shared jumper setting (TC/PT). For details on the input type jumper, see page 2-2.


### ● Control output

5	11	12	10
4			9
3			8
2			7
1	13	14	6

- Terminal Nos. 11 and 12 are for control output 1 (OUT1). The following diagrams show the available outputs and their internal equalizing circuits.



- Terminal Nos. 9 and 10 are for control output 2 (OUT2). The following diagrams show the available outputs and their internal equalizing circuits.




- The following table shows the specifications for each output type.

Output Type	Specifications
Relay	250VAC, 3 A
Voltage (NPN)	12VDC, 20 mA (with short-circuit protection)
Voltage (PNP)	12VDC, 20 mA (with short-circuit protection)
0 to 10V	0 to 10VDC, Permissible load impedance: 1 k $\Omega$ min., Resolution: Approx. 2600
4 to 20mA	4 to 20 mA, Permissible load impedance: 500 $\Omega$ max., Resolution: Approx. 2600

### ● Auxiliary output 1

5	11	12	10
4			9
3			8
2			7
1	13	14	6

- Terminal Nos.2 and 3 are for auxiliary output 1 (SUB1).
- The internal equalizing circuit for auxiliary output 1 is as follows:




- Relay specifications are as follows:  
1a, 250 VAC, 1 A

### ● Option

5	11	12	10
4			9
3			8
2			7
1	13	14	6


- Terminal Nos.1, 13 and 14 are available only for controllers that support optional functions.
- These terminals can be wired as follows depending on the controller type.



- For details on the RS-232C and RS-485 communications functions, see Chapter 6, Using the Communications Functions.
- Use event inputs under the following conditions:

Contact input	ON: 1kΩmax., OFF: 100 kΩ max.
No-contact input	ON: residual voltage 1.5 V max., OFF: leakage current 0.1 mA max.

Polarities during no-contact input are as follows:



- Transfer output specifications are as follows:  
4 to 20 mA DC, Permissible load impedance: 500Ω max., Resolution: Approx. 2600

# K CHAPTER 3

## BASIC OPERATION

This chapter describes actual examples for understanding the basic operation of the E5CK-T.

3.1	Convention Used in this Chapter .....	3-2
3.2	Setting Input Specifications .....	3-4
	Input type .....	3-4
	Temperature input .....	3-5
	Analog input .....	3-5
3.3	Setting Output Specifications .....	3-7
	Output assignments .....	3-7
	Direct/reverse operation .....	3-7
	Control period .....	3-8
3.4	Setting Alarm Type .....	3-9
	Alarm type .....	3-9
	Alarm value .....	3-9
	Alarm hysteresis .....	3-10
	Close in alarm/open in alarm .....	3-10
3.5	Setting Patterns .....	3-13
	Pattern No. ....	3-14
	Number of steps .....	3-14
	Step SP/Step time .....	3-14
	Alarm value .....	3-15
3.6	Protect Mode .....	3-18
	Security .....	3-18
	Key protect .....	3-18
3.7	Starting and Stopping Operation .....	3-20
3.8	Adjusting Control Operation .....	3-21
	Changing programs .....	3-21
	Manual operation .....	3-23
	Auto-tuning (A.T.) .....	3-24


## 3.1 Convention Used in this Chapter

This chapter describes basic E5CK-T operations such as how to set up parameters, start and stop operation, and adjust control operation.

For more complex control examples, refer to Chapter 4 Applied Operation and Chapter 5 Parameters.

### ● Basic Operation Flow

The following diagram shows the basic flow of operation.



The descriptions in this chapter follow the order of basic operations shown in the flow above. Examples of operation of each of the items are described up to completion of parameter setup. However, you must move to the top parameter of the following Setting. For example, when you have finished “setting input specifications” and you want to “set output specifications,” move to the top parameter of “setting output specifications” from the bottom parameter of “setting input specifications.”



For details on moving to parameters between items, refer Chapter, Selecting modes and Selecting parameters (page 1-10).




### ● Setup examples

This description assumes that the controller is operated under the following conditions.

- A K thermocouple is used as the input.
- Control output (heat), alarm 1 and alarm 2 functions are assigned to “control output 1,” “control output 2” and auxiliary output 1, respectively. Of these, only control output 1 and auxiliary output 1 are used.
- The relay output unit is mounted at control output 1.
- The upper-limit alarm is set as alarm 2. The alarm is output when the temperature exceeds 10°C with respect to the PV.
- The program is made up of one pattern comprising four steps.
- The following figures show terminal wiring and the program used in the setting examples.




## 3.2 Setting Input Specifications



- With temperature input, scaling and decimal point parameters need not be set as this information is determined by the input (sensor) type. (These parameters are not displayed.) Note that temperature unit and temperature input shift parameters need to be set.
- With analog input, the “scaling upper limit”, “scaling lower limit” and “decimal point” parameters need to be set.

### Input type



- Set the type No. (0 to 21) in the “input type” parameter (Set up mode). The factory setting is “2: K1 (thermocouple).”
- When you set the “input type” parameter, be sure to check the setting of the input type jumper. If the jumper setting does not match the type of input connected to the input terminal, reset the input type jumper.
- For details on input types, setting ranges and setting of the input type jumper, see Chapter 5 Parameter/Setup mode/Input type on page 5-31.
- For details on input types and setting ranges, see page 5-31.

## ■ Temperature input

### ● Temperature unit




- To switch the temperature unit from “°C” to “°F” when input is temperature, switch the “°C/°F selection” parameter (setup mode) from “ $\text{C}$ ” to “ $\text{F}$ ”.

### ● Temperature input shift




- When input is temperature input, the upper and lower limit values of the sensor can be shifted linearly. For example, if both the upper and lower limit values are shifted by 1.2°C, the process value (before shift) is regarded as 201.2°C after shift when input is 200°C before shift.
- To set input shift, set shift values in the “input shift upper limit” and “input shift lower limit” parameters (level 2 mode).



## ■ Analog input



- When the analog input (the voltage input and current input) is selected, scaling matched to the control is required.
- The “scaling upper limit”, “scaling lower limit” and “decimal point” parameters (setup mode) are used for scaling. These parameters cannot be used when the temperature input type is selected.
- The “scaling upper limit” parameter sets the physical quantity to be expressed by the upper limit value of input, and the “scaling lower limit” parameter sets the physical quantity to be expressed by the lower limit value of input. The “decimal point” parameter sets the number of digits past the decimal point.
- The following figure shows a scaling example of 4 to 20 mA input. After scaling, the humidity can be directly read. In this case, the “decimal point” parameter is set to “1”.



**Setting Example**


In this example, let's check the input type and temperature units, and shift the lower limit by 1°C and the upper limit by 3°C.

"input type" = "2: K1"

"temperature unit" = "°C"

"input shift upper limit" = "3.0"

"input shift lower limit" = "1.0"



- (1) Select the menu display, and select " **SET** : setup mode" using the or keys. For details on selecting the menu display, see page 1-10.
- (2) Press the key for one second minimum to enter the setup mode. The top parameter in the setup mode "**Ln-t** : input type" is displayed. This parameter is factory-set to "2: K1".
- (3) Press the key to fix the set value. The display changes to "**d-U** : °C/°F selection" parameter. This parameter is factory-set to "**C** : °C".
- (4) Select the menu display, and select "**lv-2** : level 2 mode" using the or keys.
- (5) Press the key for one second minimum to enter the level 2 mode. The top parameter in the level 2 mode [ **r-L** ] ("local/remote" parameter) is displayed.
- (6) Press the key until [ **LnSH** ] ("input shift upper limit" parameter) is selected. This parameter is factory-set to "0.0".
- (7) Press the key until "3.0" is displayed.
- (8) Press the key until [ **LnSL** ] ("input shift lower limit" parameter) is selected. This parameter is factory-set to "0.0".
- (9) Press the key until "1.0" is displayed. This sets the "input shift upper limit" and "input shift lower limit" values.

## 3.3 Setting Output Specifications

### ■ Output assignments

#### ● Standard type

OUT 1

OUT 2

SUB 1

- Twelve outputs are supported. These functions are assigned to control outputs 1 and 2, and auxiliary outputs 1 and 2.
- Restrictions on assignment destination are placed on some of the outputs.
- The following table shows where outputs may be assigned to.

Output Function \ Assignment Destination	Control Output		Auxiliary Output
	1	2	1
Control output (heat)	●	●	
Control output (cool)	●	●	
Alarm 1	●	●	●
Alarm 2	●	●	●
Alarm 3	●	●	●
LBA	●	●	●
Time signal 1	●	●	●
Time signal 2	●	●	●
Program end	●	●	●
Stage output	●	●	●
Error 1 : Input error			●
Error 2 : A/D convertor error			●

With control output (cool), the conditions for switching from standard control to heating and cooling control are reached when the output function is assigned at the cooling side during heating and cooling control.

In other words, heating and cooling control is carried out when control output (cool) is assigned, and standard control is carried out when output is not assigned. For details on heating and cooling control, see Chapter 4 Applied Operation/4.1 Selecting the Control Method (page 4-2).

- Factory settings are as follows:
  - control output 1 = Control output (heat)
  - control output 2 = Alarm 1
  - auxiliary output 1 = Alarm 2
- Output assignments are set in the “control output 1 assignment”, “control output 2 assignment”, “auxiliary output 1 assignment” parameters (setup mode).

### ■ Direct/reverse operation


DR EU

- “Direct operation” (or normal operation) refers to control where the manipulated variable is increased according to the increase in the process value. Alternatively, “reverse operation” refers to control where the manipulated variable is decreased according to the decrease in the process value. For example, when the process value (PV) (temperature), is lower than the set point (SP) (temperature), in a heating control system, the manipulated variable increases by the difference between the PV and SP values.

Accordingly, this becomes “reverse operation” in a heating control system, or alternatively, “direct operation” in a cooling control system.

- Direct/reverse operation is set in the “direct/reverse operation” parameter (setup mode). The “direct/reverse operation” parameter is factory-set to **DR - r** (reverse operation).

## Control period




- The control period is set in the “control period (heat)” parameter (level 1 mode). The “control period (heat)” parameter is factory-set to “20:20 seconds.” The “control period (cool)” output function is not assigned. (the “control period (cool)” parameter cannot be set.)

### Setting Example

All of the above settings in this example are factory settings. In this example, let's check the parameter settings.

In this example, the parameters are set as follows:

“control output 1 assignment”	= “control output (heat)”
“auxiliary output 1 assignment”	= “alarm output 2”
“direct/reverse operation”	= “reverse operation”
“control period”	= “20 secs”



- (1) Select the menu display, and select “ **SET** : setup mode” using the or keys. For details on selecting the menu display, see page 1-10.
- (2) Press the key for one second minimum to enter the setup mode. The top parameter in the setup mode “ **Input type**” is displayed.
- (3) Press the key until [ **OUT 1** ] (“control output 1 assignment” parameter) is displayed. Default is [ **HEAT** ].
- (4) As the setting in this example is to be left as it is, press the key twice. The display changes to [ **SUB 1** ] (“auxiliary output 1 assignment” parameter). Default is [ **AL-2** ].
- (5) As the setting in this example is to be left as it is, press the key until [ **OR-EU** ] (“direct/reverse operation” parameter) is displayed. Default is [ **OR-R** ].
- (6) As the setting in this example is to be left as it is, press the or keys to select “ **Level 1** : level 1 mode”. For details on selecting the menu display, see page 1-7.
- (7) Press the key for one second minimum to enter the level 1 mode. The top parameter in the level 1 mode “ **P** : Proportional band” is displayed.
- (8) Press the key until [ **CP** ] (“control period (heat)” parameter) is displayed. Default is “20”. As the setting in this example is to be left as its is, quit key operation.

## 3.4 Setting Alarm Type

- Three alarm outputs are supported: alarms 1 to 3. Of these, only the alarm assigned as the output can be used.
- Alarm output conditions are determined according to the combination of the “alarm type”, “alarm value” and “alarm hysteresis” parameter settings.
- The contact conditions for when alarm output is ON can be set to “open” or “closed” in the “close in alarm/open in alarm” parameter.
- The following table shows the alarm types supported by the E5CK-T controller and their respective operations.


### ■ Alarm type



Alarm Type		Alarm Output Operation	
		When X is positive	When X is negative
1	Upper-and lower-limit alarm (deviation)	ON OFF	Always ON
2	Upper-limit alarm (deviation)	ON OFF	ON OFF
3	Lower-limit alarm (deviation)	ON OFF	ON OFF
4	Upper-and-lower-limit range alarm (deviation)	ON OFF	Always OFF
5	Upper-and-lower-limit alarm with standby sequence (deviation)	ON OFF	Always OFF
6	Upper-limit alarm with stand-by sequence (deviation)	ON OFF	ON OFF
7	Lower-limit alarm with stand-by sequence (deviation)	ON OFF	ON OFF
8	Absolute-value upper-limit alarm	ON OFF	ON OFF
9	Absolute-value lower-limit alarm	ON OFF	ON OFF
10	Absolute-value upper-limit alarm with standby sequence	ON OFF	ON OFF
11	Absolute-value lower-limit alarm with standby sequence	ON OFF	ON OFF


- Alarm types are set independently for each alarm in the “alarm 1 to 3” parameters (setup mode). Default is “2: Upper-limit alarm (deviation)”.

### ■ Alarm value




- Alarm values are indicated by “X” in the table above. Alarm output operation differs according to whether the value of the alarm is positive or negative.
- Alarm values are built into the program and are set for each pattern. For details, see 3.5 Setting Patterns” (page 3-14).

## ■ Alarm hysteresis



- The hysteresis of alarm outputs when alarms are switched ON/OFF can be set as follows:



- Alarm hysteresis is set independently for each alarm in the “alarm 1 to 3 hysteresis” parameters (level 2 mode). Default is “0.02: 0.02%FS”.

## ● Standby sequence

- “Standby sequence” is a function for unconditionally turning alarm output OFF when the process value has left the alarm range once and it next enters the alarm range.
- For example, when the alarm type is set to “lower-limit alarm,” generally the process value is within the alarm range, and alarm output smaller than the set point, and alarm output becomes ON when this state continues. However, if the alarm type is set to “lower-limit alarm with standby sequence”, alarm output first becomes ON when the process value exceeds the alarm setting value to leave the alarm range and once again falls below the alarm value.
- The standby sequence is canceled when an alarm is output. It is, however, restarted later by one of the following conditions:

Operation is started or power is turned ON.

A pattern is started.

The program advances to the next step.


The SP of the current step is changed.

The currently running alarm value is changed.

The input shift value is changed.

Advance is executed.

## ■ Close in alarm/open in alarm



- When the controller is set to “close in alarm,” the status of the alarm output function is output as it is. When set to “open in alarm,” the status of the alarm output function is output inverted.


	Alarm	Output	Output LED
Close in alarm	ON	ON	Lit
	OFF	OFF	Not lit
Open in alarm	ON	OFF	Lit
	OFF	ON	Not lit

- Alarm type and close in alarm (normally open)/open in alarm (normally close) can be set independently for each alarm.
- Close in alarm/open in alarm is set in the “alarm 1 to 3 open in alarm” parameters (setup mode). Default is “ $n - \bar{o}$  : close in alarm”.



### ● Summary of alarm operations

The figure below visually summarizes the above descriptions of alarm operations (when alarm type is set to “lower-limit alarm with standby sequence”):



**Setting Example**

Alarm 2 is output when the temperature exceeds alarm value 2 programmed to the SP. Parameter factory settings for “alarm type 2,” “alarm hysteresis” and “close in alarm/open in alarm” are used.

In this example, the related parameters are set as follows:


“alarm type 2” = “2: upper-limit”

“alarm value 2” = (set in program setting)

“alarm hysteresis: = “0.02”

“close in alarm/open in alarm” = “ $\alpha - \delta$ : close in alarm”

In this example, let’s check the alarm type.




- (1) Select the menu display, and select “**SET** : setup mode” pressing the or keys. For details on selecting the menu display, see page 1-9.
- (2) Press the key to enter the setup mode. The top parameter in the setup mode “**IN-T** : input type” is displayed.
- (3) Press the key until [**AL T2**] (“alarm type 2” parameter) is displayed. Default is “2: upper limit”.

## 3.5 Setting Patterns

If you want to set parameters in the program mode during controller operation, you must first stop operation. Operation may continue only in special instances, for example, to change SP during controller operation.

- This section describes the procedure to follow when setting two or more patterns. Select the number of patterns in the “number of patterns” parameter (expansion mode).
- Parameters that you use frequently for programming can be set in the “program mode.” The flow below shows the parameters that are available in the program mode and the order in which they are set.



This chapter describes the basic operation of programming. For details on the following parameters, refer to Chapter 4 Applied Operation:

“Step time/Rate of rise programming”, “Pattern execution count”, “Time signal 1, 2”

### ■ Pattern No.

Pln

- This parameter cannot be changed during controller operation.
- Set the desired pattern No. Step SP, step time, alarms and other parameters that follow this parameter are set for the pattern that is set in this parameter.
- Set within the range 0 to (number of patterns - 1). The “number of patterns” parameter is factory-set to “0”.

### ■ Number of steps

5-nā

- Set the number of steps for the pattern that you specified in the “pattern No.” parameter.
- Set within the range 1 to 16 (step). Default is “8”.


### ■ Step SP/Step time

SP \*

ti \*

\* : 0 to 15

- Set only the number of steps used in the program in order from step 0, as “step 0 SP”, “step 0 time”, “step 1 SP”, “step 1 time” and so forth.
- Set within the range from set point lower limit to set point upper limit for step SP. Default is “0”.
- Set within the range 0.00 to 99.59 (hours:minutes or minutes:seconds). Default is “0.00”.



A: SP of steps 0 and 3  
B: SP of steps 1 and 2


- As shown in the above figure, step 0 is a fixed value, so when ramp operation is started, set the “step 0 time” parameter to “0.00” to configure the program so that ramp operation starts from step 1.

Alarm value



\* : 0 to 3


- Alarm values can be set only for alarms that have been assigned as output.
- When a deviation alarm is assigned as output, the alarm value is set with respect to SP. The following example shows the relationship between the SP and alarm value when the alarm type is set to “upper limit.”




About the Alarm Value Decimal Point

The decimal point of the alarm value conforms to the setting of the “decimal point” parameter. In this example, the “decimal point” parameter is set to “1”. (During temperature input, the decimal point of the alarm value conforms to the set sensor.)

### Setting Example






In this example, let's set the next program to pattern 0.



	SP	Time (hr, min.)	Alarm value 2
Step 0	50	0.00	10
Step 1	100	0.20	10
Step 2	100	0.40	10
Step 3	50	0.20	10

- Pattern execution count "1"
- Time signals are not used.

- (1) Select the menu display, and select "PRG : program" pressing the or keys. For details on selecting the menu display, see page 1-10.
- (2) Press the key to enter the program mode. The top parameter in the program mode "Pattern : pattern" is displayed. Default is "0 : pattern 0".
- (3) As the setting "0: pattern 0" in this example is to be left as it is, press the key. The display changes to the [S-nb] ("number of steps" parameter). Default is "8".
- (4) Set the parameter to "4" pressing the or keys.
- (5) When you press the key, the display changes to the [SP0] ("step 0 SP" parameter). Default is "0".
- (6) Set the parameter to "50" pressing the or keys.
- (7) When you press the key, the display changes to the [t0] ("step 0 time" parameter). Default is "0.00".
- (8) As the setting "0.00: 0 minutes" in this example is to be left as it is, press the key. The display changes to the [SP1] ("step 1 SP" parameter). Default is "0".
- (9) Set the parameter to "100" pressing the or keys.
- (10) In the same way, set the "t1 : step 1 time", "SP2 : step 2 SP", "t2 : step 2 time", "SP3 : step 3 SP", "t3 : step 3 time" parameters, in that order.
- (11) When you have finished setting the step SPs and times press the key. The [rPt] ("pattern execution count" parameter, is displayed. Default is "1".)

- (12) As the setting in this example is to be left as it is, set the alarm value.  
Press the  key until [AL-2] (“alarm 2” parameter) is displayed.  
Default is “0”.
- (13) Set the parameter to “10: 10 seconds” pressing the  or  keys.

## 3.6 Protect Mode

### ■ Security



- This parameter allows you to protect until start of operation parameters that do not change during operation to prevent unwanted modification.
- The set value of the “security” parameter (protect mode) limits the range of protectable parameters. The following table shows the relationship between set values and the range of protection. (Only modes marked by ● can be operated.)

Mode	Set value						
	0	1	2	3	4	5	6
Calibration	●	●					
Option	●	●					
Expansion	●	●					
Setup	●	●					
Level 2	●	●	●				
Level 1	●	●	●	●			
Program	●	●	●	●	●		
Level 0	●	●	●	●	●	●	*1

\*1 Only the “PV/Present SP” parameter can be displayed.

- When this parameter is set to “0”, parameters are not protected.
- When this parameter is set to “5”, operations in only the level 0 mode can be selected, and the mode is not displayed on the menu display.
- When this parameter is set to “6”, the “PV/Present SP” parameter can only be monitored.
- Default is “1”.

### ■ Key protect



- This parameter disables key operation for switching run/reset or auto/manual. For example, if you protect the key operation for switching auto/manual by the “key protect” parameter (protect mode) during automatic operation, the controller cannot be set to the manual mode, preventing manual operation of the controller during operation.
- The following table shows the relationship between set values and keys that are protected.

Set value	Description
0	Key protection OFF
1	A/M cannot be selected.
2	RUN/RST cannot be selected.
3	Both A/M and RUN/RST cannot be selected.

- Default is “0 : All keys can be operated.”




## Setting Example

In this example, let's set the parameters as follows:

“Security” “2” (all parameters in modes other than the setup mode are protected)

“Key protect” “1” (Auto/manual key operation cannot be switched)



- (1) Press the **RUN/RST** and **↺** keys simultaneously for 1 second minimum. The controller enters the protect mode. In the protect mode, the top parameter in the protect mode “security” is displayed. Default is “1”.
- (2) Press the **↺** key to change the parameter setting to “2”.
- (3) Press the **↺** key to switch to the “key protect” parameter.
- (4) Press the **↺** key to change the parameter setting to “1”.
- (5) Press the **↺** and **RUN/RST** keys simultaneously for 1 second minimum. The display changes to the “PV/Present SP monitor” parameter (level 0 mode).

## 3.7 Starting and Stopping Operation

### RUN/RST

- To start program operation (that is, switch from the reset state to run operation), press the **RUN/RST** key for one second minimum.
- To stop program operation (that is, switch from run operation to the reset state), press the **RUN/RST** key for two seconds minimum. When the controller has stopped operating (reset state), the RST LED lights.
- The controller cannot be reset during auto-tuning (A.T.).

### ● Manipulated variable at reset



- Specify the manipulated variable (-5.0 to 105.0%) in the “MV at reset” parameter (level 2 mode) to output the manipulated variable during reset. Default is “0.0:0.0%”.
- When the controller is reset in the manual mode, the manual MV takes precedence.
- Both the MV limiter and MV change rate limiter are ineffective against the manipulated value at reset.



#### Using Event Input

On the E53-CKB, run/reset can be selected by event input.

For details on how to use event input, see 4.7 How to Use Event Input, page 4-17.


## 3.8 Adjusting Control Operation

### ■ Changing programs

- Programs are changed in the program mode. Note that pattern Nos. cannot be changed during program operation. So, only the pattern that is currently running can be changed.
- You cannot change the program when the “security” parameter (protect mode) is set to “5” or “6”.


### ● Changing the SP

- Change the SP of steps 0 to 15 in “step 0 to 15 SP” parameters (program mode).
- When the SP is changed midway through a step, the Present SP is shifted on a line obtained by taking the new SP as the target point.



### ● Changing the time value

- Change the time value of steps 0 to 15 in “step 0 to 15 time” parameters (program mode).
- When the time value is changed midway through a step, the step time changes. The gradient of the line by which SP shifts also changes.




About Changing  
the Number of  
Steps

If you set the “number of steps” parameter (program mode) to a value smaller than the current number of steps during program operation, program operation is immediately exited.







Setting Example


In the following example, let's change the temperature set point to "60°C" from "50°C".



- (1) Press the  $\square$  key for one second minimum at the currently executing "PV/Present SP" display.
- (2) The display changes to the menu display.
- (3) Set the parameter to "Pr-Gr : program" pressing the  $\blacktriangle$  or  $\blacktriangledown$  keys.
- (4) Press the  $\square$  key for one second minimum to enter the program mode. The top parameter in the program mode the [5-nd] ("number of steps" parameter) is displayed.
- (5) Press the  $\square$  key. [SP0] ("step 0 SP" parameter) is displayed, and the No.2 display indicates "50.0".
- (6) Press the  $\square$  key to set the parameter to "60.0".
- (7) Press the  $\square$  key for one second minimum. The menu display ("Pr-Gr : program" parameter) is redisplayed.
- (8) Select "LU-0 : level 0 mode" pressing the  $\blacktriangle$  or  $\blacktriangledown$  keys, and press the  $\square$  key for one second minimum. The "PV/Present SP" display is redisplayed.

## Manual operation

- The manipulated variable is controlled manually.
- To set manual operation and manually set the manipulated variable, press the  and  keys simultaneously for 1 second minimum. The controller enters the manual mode. To quit the manual mode, press the  and  keys simultaneously again for 1 second minimum. The controller enters the level 0 mode without entering the menu display.
- Though the control shifts to manual operation if the controller is set to the manual mode during program operation, the program advances. When program operation is started in the manual mode, program also advances.
- In the manual mode, the automatic return of display mode does not work.
- Auto/manual can be switched up to 100,000 times.
- The process value is displayed on the No.1 display, and the manipulated variable is displayed on the No.2 display.
- To change the manipulated variable, press the  or  keys. After two seconds, the manipulated variable is updated to the new setting.
- When switching between manual and auto operation, the manipulated variable is subject to balance-less, bump-less operation.
- If the power is interrupted during manual operation, manual operation is resumed at the manipulated variable that was active at power interruption when the power is reset.



Balance-less,  
Bump-less Operation

To prevent sudden changes in the manipulated variable when switching between manual and auto operation, operation is resumed using the value that was active immediately before operation was switched, and the value is brought gradually closer to the value immediately after operation was switched.

## ■ Auto-tuning (A.T.)




- AT (auto-tuning) cannot be executed while operation is reset or during ON/OFF control.
- When you execute auto-tuning, the optimum PID parameters are automatically set by forcibly changing the manipulated variable to calculate the characteristics (called the “limit cycle method”) of the control target. During auto-tuning, time counting is stopped and the “AT” LED flashes.
- 40%AT or 100%AT can be selected by the limit cycle of MV change width. Specify [At - 1] or [At - 2], respectively, in the “AT execute/cancel” parameter (level 1 mode).
- During heating and cooling control, only 100%AT can be executed. (So, [At - 1] (40%AT) is not displayed.)
- To cancel AT execution, specify “OFF : AT cancel”.

### ● 40%AT



In order to set the limit cycle of MV change width to 40%, select 40%AT to execute auto-tuning with fluctuations in the process value kept to a minimum. However, note that auto-tuning takes longer to execute compared with 100%AT.


The timing by which limit cycles are generated varies according to whether or not the deviation (DV) at the start of AT execution is 10% full-scale or less.




### ● 100%AT



In order to set the limit cycle of MV change width to 100%, select 100%AT to shorten the AT execution time without worrying about fluctuations in the process value.



Setting Example



In this example, let's execute 40%AT.

- (1) Select the menu display, and select “**hEnU - 1** : level 1 mode” using the or keys. For details on selecting the menu display, see page 1-8.
- (2) Press the key to enter the level 1 mode. The top parameter in the setup mode “**At** : AT execute/cancel” is displayed. In this example, the parameter setting is “**0.0FF** : AT cancel”.
- (3) Press the key to specify [**At - 1**].
- (4) The AT LED flashes, and AT execution starts. When the AT LED goes out (end of AT execution), the parameter automatically returns to “**0.0FF** : AT cancel”.




About PID Parameters

When control characteristics are already known, the PID parameters can be set directly to adjust control.  
PID parameters are set in the “proportional band” (P), “integrated time” (I) and “derivative time” (D) parameters (level 1 mode).  
For details on the setting ranges of these parameters, see chapter 5 Level 1 Mode (page 5-17).



AT Execution Timing

The E5CK-T differs from fixed-value type controllers in that the SP changes automatically. So, the timing of AT execution is the most important factor in control.  
To obtain PID parameters for a specific SP, make a fixed-value program as follows and execute AT.







# K CHAPTER 4

## APPLIED OPERATION

This chapter describes each of the parameters required for making full use of the features of the E5CK-T.

Read this chapter while referring to the parameter descriptions in chapter 5.

4.1	Selecting the Control Method .....	4-2
	Heating and cooling control .....	4-2
	ON/OFF control .....	4-4
4.2	Operating Condition Restrictions .....	4-5
	Manipulated variable restrictions .....	4-5
	Set point limiter .....	4-6
4.3	Ramp Rise Rate Setup Program .....	4-7
	Running the ramp rise rate setup program	4-8
	Program example .....	4-9
4.4	Program Operation .....	4-10
	Hold/Advance .....	4-10
	Pattern operation .....	4-11
4.5	Program output .....	4-13
	Time signal .....	4-13
	Program output .....	4-14
4.6	Setting Running Conditions .....	4-15
	Operation at power ON .....	4-15
	Starting the program run .....	4-16
	End condition .....	4-16
4.7	How to Use Event Input .....	4-17
	Input assignments .....	4-17
	Detailed description of input functions ...	4-18
4.8	LBA .....	4-19
4.9	How to Use Transfer Output .....	4-21

## 4.1 Selecting the Control Method

### ■ Heating and cooling control

Heating and cooling control is achieved when the “control output (cool)” function is assigned as the output. Discriminately use standard heating control or cooling control according to the following table:

Parameter Control Method	Control Output 1 Assignment	Control Output 2 Assignment	Direct/Reverse operations
Heating control (Standard)	Control output (heat)	-	Reverse operation
Cooling control (Standard)	Control output (heat)	-	Direct operation
Heating and cooling control	Control output (heat)	Control output (cool)	Reverse operation


(Parameters are factory-set to heating control.)

- For details on how to assign outputs, see 3.3 Setting Output Specifications (page 3-7).
- When heating and cooling control is selected, the “dead band” and “cooling coefficient” parameters can be used.

#### ● Dead band

The dead band is set with the set point as its center. The dead band width is the set value of the “dead band” parameter (level 1 mode). Setting a positive value produces a dead band, while setting a negative value produces an overlap band.

The dead band is factory-set to “0.00:0.00%FS.”



#### ● Cooling coefficient

If the heating and cooling characteristics of the control target greatly differ, preventing satisfactory control characteristics from being obtained by the same PID parameters, adjust the proportional band (P at cooling side) using the cooling coefficient to balance control between the heating and cooling sides. In heating and cooling control, P at the heating or cooling side is calculated by the following formula:

$$\text{Heating side } P = P; \text{ Cooling side } P = \text{cooling coefficient} \times P$$

### ● Manipulated variable at reset

- In heating and cooling control, the manipulated variable output that is output when controller operation is stopped is dependent on the set value of the “MV at reset” parameter (level 2 mode) in the same way as for standard control.
- However, note that in heating and cooling control, the manipulated variable at the cooling side is treated as a negative value for the sake of convenience. When the manipulated variable at reset is a negative value, the manipulated variable is output to only the cooling side, and when a positive value, the manipulated variable is output to only the heating side. Default is “0”. If the controller is operated with default, the manipulated variable is not output to both the heating and cooling sides.




#### Switching with Manual Operation

When the overlap band is set, the bumpless function that operates when switching between manual and automatic operation may not work.


## ■ ON/OFF control

### ● Hysteresis

- Switching between advanced PID control and ON/OFF control is carried out by the “PID/ON/OFF” parameter (expansion mode). When this parameter is set to [ P I D ], advanced PID control is selected, and when set to [ O N O F F ], ON/OFF control is selected. Default is [ P I D ].
- In ON/OFF control, hysteresis is provided in the program when switching between ON and OFF to stabilize operation. The hysteresis width provided during ON/OFF control is simply referred to as “hysteresis.” Control output (heat) and control output (cool) functions are set in the “hysteresis (heat)” and “hysteresis (cool)” parameters, respectively.
- In standard control (heating or cooling control), hysteresis can be set only for the heating side.



- In heating and cooling control, a dead band can be set. So, 3-position control is made possible.



## Parameters

Symbol	Parameter Name: Mode	Description
$\bar{a}U\bar{t}1$	Control output 1 assignment : Setup	For specifying control method
$\bar{a}U\bar{t}2$	Control output 2 assignment : Setup	For specifying control method
$\bar{a}r\bar{E}u$	Direct/reverse operation : Setup	For specifying control method
$\bar{E}-db$	Dead band : Level 1	Heating and cooling control
$\bar{E}-Sc$	Cooling coefficient : Level 1	Heating and cooling control
$\bar{n}u-r$	MV at reset : Level 2	Manipulated variable when control operation is stopped
$\bar{n}u-E$	MV at PV error : Level 2	Manipulated variable when control operation is PV error
$HYS$	Hysteresis (heat) : Level 1	ON/OFF control
$\bar{E}HYS$	Hysteresis (cool) : Level 1	ON/OFF control
$\bar{E}n\bar{t}L$	PID / ON/OFF : Expansion	ON/OFF control


## 4.2 Operating Condition Restrictions

### ■ Manipulated variable restrictions


The upper- and lower-limit values of the manipulated variable can be restricted by the MV limiter, and the change rate of manipulated variable can be restricted by the MV change rate limiter.

#### ● MV limiter

The upper- and lower-limit values of the manipulated variable are set in the “MV upper limit” and “MV lower limit” parameters (level 2 mode). When the manipulated variable calculated by the E5CK-T is outside of the range of the MV limiter, actual outputs are dependent on the set value of these parameters.




In heating and cooling control, the manipulated variable at the cooling side is treated as a negative value for the sake of convenience. The upper limit is set for the heating side (positive value), and the lower limit is set for the cooling side (negative value) as shown in the following figure.



#### ● MV change rate limiter

The “MV change rate limiter” parameter (level 2 mode) sets the maximum permissible change width per second of the manipulated variable. If a change in the manipulated variable exceeds this parameter setting, the value calculated by the E5CK-T is reached while changing the value by the per-second value set in this parameter.




### ● Limiter operation conditions

The limiters are disabled or cannot be set when any of the following conditions occurs:

- During ON/OFF control
- During AT execution (only by MV change rate limiter)
- During manual operation
- When operation is stopped
- When an error has occurred

### ■ Set point limiter

The setting range of the set point is limited by the set point limiter. The upper- and lower-limit values of this set point limiter are set in the “set point upper limit” and “set point lower limit” parameters (expansion mode), respectively. However, note that when the set point limiter is reset, the set point is forcibly changed to the upper- or lower-limit value of the set point limiter if the set point is out of the limiter range. Also, when the input type, temperature unit and scaling (sensor) range are changed, the set point limiter is forcibly reset to the scaling (sensor) range.




### Parameters

Symbol	Parameter Name: Mode	Description
$\bar{O}L-H$	MV upper limit : Level 2	For limiting manipulated variable
$\bar{O}L-L$	MV lower limit : Level 2	For limiting manipulated variable
$\bar{O}r-L$	MV change rate limit : Level 2	For limiting manipulated variable
$S\bar{L}-H$	Set point upper limit : Expansion	For limiting SP setting
$S\bar{L}-L$	Set point lower limit : Expansion	For limiting SP setting
$\bar{O}U\bar{t}1$	Control output 1 assignment : Setup	For specifying control method
$\bar{O}U\bar{t}2$	Control output 2 assignment : Setup	For specifying control method
$\bar{O}r\bar{E}u$	Direct/reverse operation : Setup	For specifying control method
$\bar{C}-db$	Dead band : Level 1	Heating and cooling control
$\bar{C}-SC$	Cooling coefficient : Level 1	Heating and cooling control
$\bar{M}u-r$	MV at reset : Level 2	Manipulated variable when control operation is stopped
$\bar{M}u-E$	MV at PV error : Level 2	Manipulated variable when control operation is PV error
$HYS$	Hysteresis (heat) : Level 1	ON/OFF control
$\bar{C}HYS$	Hysteresis (cool) : Level 1	ON/OFF control
$\bar{C}n\bar{t}L$	PID / ON/OFF : Expansion	ON/OFF control

## 4.3 Ramp Rise Rate Setup Program


Chapter 3 described programs that used the “time setup method.” Programs were executed using a combination of SPs and step time values. The E5CK-T also supports the “ramp rise rate setup method.” By this method, programs are executed using three program elements: “target SP”, “rate of rise” and “soak time.”

To select a ramp rise rate program, set the “Step time/rate of rise programming” parameter (expansion mode) to “ $P_r$ : rate of rise.”



Set each of the above program elements in the “target SP 0 to 7”, “rate of rise 0 to 7” and “soak time 0 to 7” parameters.


In a ramp rise rate program, parameters are set to two steps as shown in the figure above. The following figure shows the relationship between the program and parameters.



### ● Relationship with the number of steps


When the number of steps is set to an odd number, the final soak time cannot be set. For example, if we set the “number of steps” parameter to “7”, the “soak time 3” parameter cannot be set even though the “target SP 3” and “rate of rise 3” parameters can be set.

Accordingly, when the number of steps are set to an even number, the final step is a soak step. When it is set to an odd number, the final step is a ramp step.



### ● When the rate of rise is set to “0”

When “rate of rise 0 to 7” parameter are set to “0”, the ramp step is skipped and the soak step appears to be continuous.




## ■ Running the ramp rise rate setup program

### ● Changing parameters

Ramp rise rate setup programs take the PV at start of program operation as the SP (PV start) when they are started.

When the rate of rise is changed midway during operation, the SP rate of rise and the step time in the ramp cycle both change.




Before change	Step N	Step N+1
After change	Step N	Step N+1

- In the above figure, increasing the rate of rise results in a shorter target step time. Likewise, when the SP is changed, the step time of the ramp cycle also changes.
- When the soak time is changed, only the step time in the soak cycle changes.



## Program example

Let's describe a typical example of a ramp rise rate setup program. In an actual program, set the parameters to match the application.



Target SP 0 : 100	Target SP 1 : 10
Rate of rise 0 : 3	Rate of rise 1 : 3
Soak time 0 : 0.30	Soak time 1 : 0.30

"Number of steps" = 4, "Time unit of ramp rate" = minutes, "PV start" = 10

### Program structure

In a program comprising four steps, steps 0 and 1 follow the settings of the "target SP 0", "rate of rise 0" and "soak time 0" parameters. Steps 2 and 3 follow the settings of the "target SP 1", "rate of rise 1" and "soak time 1" parameters.

### How the program works

- (1) As the program starts at PV (PV start), the program starts operation from "10" in this example.
- (2) As the rate of rise is set to "3", the Present SP takes 30 minutes ( $100-10/3=30$ ) to reach the target SP value "100" in step 0. If the PV is "40" when the program is started, this time then becomes 20 minutes using the same formula.
- (3) In step 1, the Present SP does not change, and the step time is the value set to the "soak time 0" parameter (in this example, "30 minutes").
- (4) In step 2, the Present SP changes according to the value of "rate of rise 1" parameter from that of "target SP 0" parameter to that of "target SP 1" parameter. It takes 30 minutes in this example.
- (5) In step 3, the Present SP does not change, and the step time is the value set to the "soak time 1" parameter (in this example, "30 minutes").

## Parameters

Symbol	Parameter Name: Mode	Description
$t - P_r$	Step time/Rate of rise programming : Expansion	Ramp rise rate
$SP *$	Target SP 0 to 7 : Program	Ramp rise rate
$P_r *$	Rate of rise 0 to 7 : Program	Ramp rise rate
$t_s *$	Soak time 0 to 7 : Program	Ramp rise rate

\* : 0 to 7




Operation  
at Input Error

By ramp rise rate setup method, starting at input error, the program start step is the "step 1".

## 4.4 Program Operation

### ■ Hold/advance

- Steps in currently executing programs can be forcibly stopped (Hold) and advanced (Advance).
- Hold and Advance operation is according to the following procedure:



- Execute hold/advance operation while making sure the step No. in the “step No. monitor” parameter (level 0 mode).
- When the “hold” parameter (level 0 mode) is set to “**ON**”, step time counting is paused (held), and the “HOLD” LED lights. [Hold] and the SP appear alternately on the No.2 display when in the “PV/Present SP” parameter.
- Hold is canceled time counting is restarted by one of the following conditions: “hold” parameter = “**OFF**”, Run, Reset, End operation using advance instruction
- Each time that “advance” parameter (level 0 mode) is set to “**ON**”, the program advances one step. With each step advance, the “Advance” parameter setting returns to “**OFF**”.
- If the advance function is executed with the program in a hold state, the hold state is continued in the next step.


## ■ Pattern operation

### ● Repeating execution of the same pattern


- To repeatedly execute the same pattern, set the number of times that the pattern is to be executed in the “pattern execution count” parameter (program mode).
- The pattern execution count can be set up to 9999 (times). (Default is “0”.)
- Patterns for which the “pattern execution count” parameter is set to “0” cannot be executed.
- The count of the currently executing pattern in the program can be verified in the “pattern execution count monitor” parameter (level 0 mode). “0” is indicated in this parameter when the controller of reset or in a standby state.

### ● Executing all patterns

- To execute all preset patterns in order from pattern 0, set the “run all enable” parameter (expansion mode) to “ON”. (Default “OFF”.)



- When a power interruption occurs during run all execution, if the “operation at power ON” parameter (expansion mode) is set to “Continue”, the currently executing pattern No. is held in memory. When power is restored, program operation resumes from the pattern that was being executed when the power was interrupted. (For details on operation at power ON, see page 4-19.)
- Patterns whose “pattern execution count” is set to “0” are skipped.



**Parameters**

Symbol	Parameter Name: Mode	Description
<i>HōLd</i>	Hold : Level 0	Pauses program execution.
<i>Adv</i>	Advance : Level 0	Advances the program one step.
<i>rPt</i>	Pattern execution count : Program	Repeatedly executes current pattern.
<i>rUnR</i>	Run all :Expansion	Executes all patterns.

**About Reset**


- A reset cancels a hold state.
- When the controller is reset during run all execution, the program returns to step 0 of the currently executing pattern.

## 4.5 Program output

- The E5CK-T outputs the following signals according to how far the program has elapsed:  
Time signal 1/2  
Program end  
Stage output
- These functions can be used only when they have been assigned as outputs.

### ■ Time signal

- Two types of time signals can be set to each pattern.



- There are two timers for time signals: ON time timer and OFF time timer. These times are counted from the beginning of the step.
- Output is ON from the ON time elapsed point up to the OFF time elapsed point.
- Set the step at which to output the time signal in the “time signal 1/2 enabled step” parameter (program mode). (Default is “0: step 0.”)
- Set the ON/OFF timing in the “time signal 1/2 ON time” and “time signal OFF time” parameters (program mode).

### ● About ON conditions

- When the OFF time is set shorter than the ON time, output is ON until a reset from the ON time elapsed point onwards or at start of the next pattern.
- Output does not turn ON when ON and OFF times are set the same.
- When step advance is executed during execution of the time signal enabled step, the controller judges that the time equivalent to the enabled step has elapsed. For example, in the above figure, output is ON from the start of the following step up to the OFF time elapsed point.



#### About Pattern Elapsing Time

You can verify the pattern elapsing time in the “pattern elapsing time” parameter (level 0 mode). During repeated execution of patterns or run all execution, the program is counting for each pattern.

If the count exceeds the monitor range (99 hours:59 minutes or 99 minutes:59 seconds), “99.59” is displayed flashing.


During Hold, time counting is paused.

Executing Advance, the skipped step time is counted.

## Program status


### Program end

- One-second pulse signal is output after the final step is completed.



### Stage output

- One-second pulse signal is output at the beginning of each step.



## Parameters

Symbol	Parameter Name: Mode	Description
$tS \times 5$	Time signal*set step : Program	Time signal
$\bar{on} *$	Time signal*ON time : Program	Time signal
$\bar{of} *$	Time signal*ON time : Program	Time signal
$\bar{out} *$	Control output*assignment : Setup	Program status
$\bar{sub} *$	Auxiliary output*assignment : Setup	Program status

\*: 1 to 2

## 4.6 Setting Running Conditions

### ■ Operation at power ON

- You can select from one of the following operations at power ON: Continue, Reset, Run, Manual
- If you select “Continue,” operation is started from the state that was active when power was interrupted.
- If you select “Reset,” the controller enters the reset state at the beginning of the step.
- If you select “Run,” the controller enters the run state, starting at the beginning of the step.
- If you select “Manual,” the controller enters the manual mode.
- The following table shows the relationship between operation at power ON and the operation details that are stored to memory when a power interruption occurs.

	Continue	Reset	Run	Manual
Pattern No.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Step No.	<input type="radio"/>	-	-	<input type="radio"/>
Pattern elapsing time	<input type="radio"/>	-	-	<input type="radio"/>
Pattern execution count	<input type="radio"/>	-	-	<input type="radio"/>
Hold status	<input type="radio"/>	-	-	<input type="radio"/>
Auto/Manual	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	-
Run/Reset	<input type="radio"/>	-	-	<input type="radio"/>
MV at reset *1	<input type="radio"/>	-	-	<input type="radio"/>
Manual MV *2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

\*1 During auto mode at power interruption

\*2 During manual mode at power interruption


Items marked with a dash (-) are not saved in memory in the event of a power interruption.

- Set the desired operation in the “operation at power ON” parameter (expansion mode). Default is “ $\text{F007}$  : Continue”.

## ■ Starting the program run

### ● PV start

- When the program is configured by the time setup method, a ramp-priority “PV start” can be selected as one of the run start conditions. If you select “PV start” in the “PV start” parameter (expansion mode), program operation is started from the position of the SP that first matches the PV when program run is started. If the SP does not match the PV, the program run is started from the beginning.



### ● Standby operation

## ■ End condition

- After the run instruction, the controller is reset until the standby time elapses.
- Set the standby time in the “standby time” parameter (level 2 mode) within the range 0.00 to 99.59 (hours:minutes). Defaults is “0.00”.
- After end of operation, the controller normally is reset. However, control can be continued on the SP of the final step by setting the “end condition” parameter (expansion mode). If the “end condition” is set, the SP of the final step and [P.End] appears alternately on the No.2 display.
- When the “number of steps” parameter is changed after operation has ended, the controller state does not change state. However, if control with respect to the SP is continued, the SP switches to the new value of the final step.

Note: The end of operation does not refer to the end of the pattern. It refers to the end of executing the pattern the specified number of times.

## Parameters

Symbol	Parameter Name: Mode	Description
P-ON	Operation at power ON : Expansion	Operation when power is turned ON
PVSt	PV start : Expansion	Start of program run
Stb	Standby time : Level 2	Start of program run
ESet	End condition : Expansion	Operation end program run



## 4.7 How to Use Event Input

### ■ Input assignments

- When using event input, add on the input unit (E53–CKB)
- Switching by event input is not possible on the menu display.
- Switch event inputs ON and OFF while controller power is ON.
- You can choose from the following five event input functions:  
Run/Reset  
Auto/Manual  
Hold/Hold cancel  
Advance  
Pattern select
- Event input ON/OFF judgment is carried out on inputs of 200 ms minimum.
- When event inputs are used as program advance input, the program step is advanced at the rising (OFF→ON) edge of the input signal. When event inputs are used as run/reset input, program operation is stopped (reset) at the rising (OFF→ON) edge of the input signal, and program operation is started (run) at the falling (ON→OFF) edge. Other signals are accepted at all times.
- Set event input assignments in the “event input assignment 1” parameter (option mode).
- The following table shows the relationship between the settings and functions of the “event input assignment 1” parameter.


Setting	Function
<i>nōn</i>	Event input disabled
<i>rSt</i>	OFF→ON: Reset / ON→OFF: Run
<i>rAn</i>	ON: Manual / OFF: Auto
<i>HōLd</i>	ON: Hold / OFF: Hold cancel
<i>Adv</i>	Execute at OFF→ON
<i>Ptn0</i>	OFF : pattern 0 / ON: pattern 1 (*1)
<i>Ptn1</i>	OFF: pattern 0 / ON: pattern 2 (*2)

\*1 Enabled when the “number of patterns” parameter is set to “2” or more

\*2 Enabled when the “number of patterns” parameter is set to “3” or more

## ■ Detailed description of input functions

### ● Run/Reset



- There is no order of priority in event input, key operations and communications command setup. However, remote/local, auto/manual, hold/hold cancel or pattern selection be set to either of ON or OFF. So, parameters will always follow event input even if you try to switch settings by key operation and communications commands.


### ● Auto/Manual

- Program operation is stopped (reset) at the rising edge (OFF→ON) of the event input signal, and the RST LED lights. Program operation is started (run) at the falling edge (ON→OFF) of the event input signal.

### ● Hold/Hold cancel

- When event input is set to “ON”, the controller is switched to manual operation, and the “MANU” LED lights.

### ● Advance



- This function is enabled only during program operation.
- The program is paused (Hold) when the event input is ON, and the “HOLD” LED lights. Holds continue until the state of the event input changes to OFF.

### ● Pattern select

- This function is enabled only during program operation.
- Program steps are advanced at the rising (OFF→ON) edge of the event input signal. Accordingly, be sure to set event input OFF before you use this function.

- This function is enabled only when the program is reset.
- Patterns are selected by pattern select input. The number of patterns that can be selected are dependent on the value set to the “number of patterns” parameter. For example, when this parameter is set to “4”, you can select from patterns 0 or 2.

## Parameters

Symbol	Parameter Name: Mode	Description
$E_{in} - 1$	Event input assignments Option	Event input functions

## 4.8 LBA

- The LBA function can be used only when it is assigned as an output. Also, the LBA function does not work when a memory error or A/D converter error results.
- LBA (Loop Break Alarm) is a function for judging that an error has occurred somewhere on the control loop and for outputting an alarm when the process value does not change with the manipulated variable at a maximum or minimum state. Accordingly, the LBA function can be used as a means for detecting a malfunctioning control loop.

### ● LBA detection time


- Normally, when output is set to maximum or minimum, the process value rises or falls after the dead time has elapsed. LBA is output if the process value does not change in the predicted direction after a fixed amount of time has elapsed. This fixed amount of time is the “LBA detection time.”

### ● LBA detection width

- LBA operation sometimes becomes unstable when the process value fluctuates considerably due to the control characteristics. The LBA detection width is provided so that changes with respect to output can be correctly detected. Changes smaller than the detection width due to LBA detection timing are not regarded as changes.

### ● LBA detection example

- The following example describes what happens when a heater burnout occurs at maximum output.




- LBA judgment is carried out at each LBA detection time from the point of maximum output. In the above figure, the process value (PV) is changing greatly at the 1st judgment time band, so LBA remains OFF.
- At the 2nd judgment time band, the process value increases as indicated by the broken line if the process value is normal. This means that the change width exceeds the LBA detection width, and LBA output remains OFF.
- If the heater burns out at the point shown in the above figure, the process value “decreases.” Accordingly, it is judged that “the process value is not changing in the increasing direction” at the 2nd judgment time band and the LBA output becomes ON.

### ● Setting the LBA detection time

- The LBA detection time is automatically set by auto-tuning (except in heating and cooling control).
- If the optimum LBA detection time cannot be obtained by auto-tuning, set the time in the “LBA detection time” parameter (level 2 mode).

### ● Determining the LBA detection time

- Calculate the LBA detection time as follows:
  - (1) Set output to maximum.
  - (2) Measure the time it takes for the input change width to reach the LBA detection width (factory setting: 0.2% FS).



- (3) Take a value twice that of the measurement time as the LBA detection time.

### Parameters

Symbol	Parameter Name: Mode	Description
<b>At</b>	AT execute/Cancel : Level 1	For automatic setting of LBA detection time
<b>LbA</b>	LBA detection time : Level 2	For setting LBA detection time
<b>LbAb</b>	LBA detection width : Expansion	For changing LBA detection width

## 4.9 How to Use Transfer Output

### ● Transfer output type

- When using transfer output, add on the communications unit (E53-CKF).


- You can select the following four data items in the “transfer output type” parameter (option mode) as the transfer outputs:

Present SP (default), Process value, Manipulated variable (heat), Manipulated variable (cool).

- If the output assignment is changed when either the “manipulated variable (heat)” or “manipulated variable (cool)” parameter is selected, the factory setting “set point” is returned to.

### ● Transfer output scaling

- These transfer outputs can be scaled according to the settings of the “transfer output upper limit” and “transfer output lower limit” parameters before output. Setting of an upper limit value smaller than the lower limit value is allowed, so reverse scaling can also be carried out. Also, the scale can be enlarged by the upper- and lower-limit width specified for each data item. The following example shows scaling of the heating side manipulated variable.



### Parameters

Symbol	Parameter Name: Mode	Description
$\text{E}53\text{-T}$	Transfer output type : Option	Transfer output designation
$\text{E}53\text{-H}$	Transfer output upper limit : Option	Transfer output scaling
$\text{E}53\text{-L}$	Transfer output lower limit : Option	Transfer output scaling



# *K* CHAPTER 5

## *PARAMETERS*

This chapter describes the parameters of the E5CK-T.  
Use this chapter as a reference guide.

Conventions Used in this Chapter .....	5-2
Protect Mode .....	5-3
Manual Mode .....	5-5
Level 0 Mode .....	5-6
Program Mode .....	5-11
Level 1 Mode .....	5-17
Level 2 Mode .....	5-24
Setup Mode .....	5-28
Expansion Mode .....	5-36
Option Mode .....	5-44
Calibration Mode .....	5-48

# Conventions Used in this Chapter

## ■ The meaning of icons used in this chapter



Function

Describes the functions of the parameter.



Setting

Describes the range and defaults of the parameter setting.



Monitor

Used for monitor-dedicated parameters.  
Describes the range of the monitor values.



Example  
of use

Describes a procedure using parameters in operating instructions.



See

Describes related parameters and items.




Model

Describes models of the E5AK-T or optional units that support the parameter being described.

## ■ About parameter display

On the E5CK-T controller, only parameters that can be used are displayed. These parameters are displayed only when the “Conditions of Use” on the right of the parameter heading are satisfied. However, note that the settings of protected parameters are still valid, and are not displayed regardless of the conditions of use.



## ■ About the Order in Which Parameters Described in This Chapter

Parameters are described mode by mode

The first page of each mode lists the parameters available in that mode. The parameter names in these contents are listed in the order that they are displayed on the controller.



## Protect Mode

- The protect function restricts key use to prevent unwanted key operation. Before changing parameters in this mode, first make sure that protecting the keys will not cause any problems in operation.
- To select this mode, press the **RUN/RST** and **↺** keys simultaneously for 1 second minimum. To exit this mode, press the **RUN/RST** and **↺** keys simultaneously again for 1 second minimum.
- The following table shows the parameters supported in this mode and the page where the parameter is described.

Symbol	Parameter Name	Page
<b>SECr</b>	Security	5-3
<b>PEYP</b>	Key protect	5-4

### **SECr** Security



Function

- This parameter specifies which parameters are protected. Note that the protect mode and manual mode cannot be protected.



Setting

- Only the modes indicated by the “●” mark in the table below can be selected on the menu display. For example, when this parameter is set to “3”, only levels 0 and 1 and the program mode can be selected.

Mode	Setting value						
	0	1	2	3	4	5	6
Calibration	●						
Option	●	●					
Expansion	●	●					
Setup	●	●					
Level 2	●	●	●				
Level 1	●	●	●	●			
Program	●	●	●	●	●		
Level 0	●	●	●	●	●	●	*1

\*1 The “PV/Present SP” parameter is only displayed.

- When this parameter is set to “0”, the protection function is disabled.
- When this parameter is set to “5”, only the parameters in the level 0 mode can be used, and the menu display is not selected.
- When this parameter is set to “6”, “PV/Present SP” parameter can only be displayed. (The set point cannot be changed.)
- Default is “1”. (Only the calibration mode is protected.)



See

- Related description  
3.6 Protect Mode (page 3-19)



# Protect Mode

PEYP

## Key protect




Function

- Disables key operation of the RUN/RESET or AUTO/MANUAL. For example, if AUTO/MANUAL key operation is disabled (by simultaneously pressing the  and  keys) in the “key protect” parameter (protect mode) during automatic operation, manual operation is no longer possible.



Setting

- The following table shows the relationship between set values and protected keys.

Set value	Description
1	No keys are protected.
2	AUTO/MANUAL key operation cannot be selected.
3	 key cannot be selected.
4	Both the AUTO/MANUAL and RUN/RESET key operations cannot be selected.







- Default is “0” (all keys can be operated).



See

- Related description  
3.6 Protect Mode (page 3-19)



## Manual Mode

- In this mode, manual operation is possible, and the “MANU” LED lights.
- When this mode is selected, the manipulated variable that was active immediately before the mode was switched to is output. To change the manipulated variable, use the  or  keys. If this mode is switched to during auto-tuning, auto-tuning is canceled.
- To select this mode when in the level 0 to 2 modes, press the  and  keys simultaneously for 1 second minimum. To exit this mode, press the  and  keys simultaneously again for 1 second minimum. The mode changes to the level 0 mode.
- “Manual MV” is the only parameter available in this mode.

### Manual MV



Function

- Sets the manipulated variable for manual operation. When you press the  or  keys, the manipulated variable is changed.
- The process value is displayed on the No.1 display and the manipulated variable is displayed on the No.2 display.
- The manual MV is held when the power is interrupted.



Setting






Control Method	Setting Range	Unit	Default
Standard	-5.0 to 105.0	%	0.0
Heating and cooling	-105.0 to 105.0	%	0.0












See

- Related description  
3.8 Adjusting Control Operation/Manual operation (page 3-22)

## Level 0 Mode

- The parameters in this mode can be used only when the “security” parameter (protect mode) is set to “0” to “5”. Only the “PV/Present SP” parameter can be used when the “security” parameter is set to “6”.
- The parameters in this mode comprise step operation parameters and parameters required for monitoring program operating states.
- To select this mode, press the  key for 1 second minimum. The display changes to the menu display. If you select [L u - 0] then press the  key for 1 second minimum, the controller enters the level 0 mode.
- To select parameters in this mode, press the  key. To change parameter settings, use the  or  keys.
- The following table shows the parameters supported in the level 0 mode and the page where the parameter is described.

Symbol	Parameter Name	Page
	PV/Present SP	5-6
	Pattern No.	5-7
	Step No. monitor	5-7
	Hold	5-8
	Advance	5-8
	Standby time monitor	5-9
	Pattern elapsing time	5-9
	Pattern execution count monitor	5-9
	MV monitor (heat)	5-10
	MV monitor (cool)	5-10

### PV/Present SP



Function

- The process value is displayed on the No.1 display, and the Present SP is displayed on the No.2 display.
- The decimal point position is dependent on the selected sensor during temperatures input and on the results of scaling during analog input.



Monitor

	Monitor Range	Unit
Process Value	Scaling lower limit -10%FS to scaling upper limit +10%FS	EU
Present SP	Set point lower limit to set point upper limit	EU

- During temperature input, the range of the currently selected sensor is taken as the PV monitor range.



See

- Related parameters  
 “Input type” “Scaling upper limit” “Scaling lower limit” “Decimal point” (setup mode)  
 “Set point upper limit” “Set point lower limit” (expansion mode)

**Pln**

**Pattern No.**

Conditions of Use

The “number of patterns” parameter must be set to a value greater than “2”.



Function

- This parameter can be set only when the controller is reset.
- Displays the execution pattern during program operation, and the set pattern after the controller is reset.
- This parameter can also be used in the program mode.



Setting

Setting Range	Unit	Default
0 to number of patterns -1	None	0



See

- Related description  
3.5 Setting Patterns (page 3-14)
- Related parameters  
All parameters in the program mode  
“Number of patterns” (expansion mode)

**STEP**

**Step No. monitor**



Function

- Monitors the current step No. (This parameter is reset to “0” when the controller is reset.)



Monitor

Monitor Range	Unit
0 to Number of steps-1	None



See

- Related description  
4.4 Program Operation (page 4-13)
- Related parameters  
“Hold” “Advance” (level 0 mode)

## Level 0 Mode

**HöLd****Hold**

Function

- This parameter can only be used for monitoring when the controller is reset.
- Pauses (holds) or cancels program operation.
- When the event input to which “hold/hold cancel” is assigned is ON, [HöL] (hold) is displayed, and when OFF [HöF] (hold cancel) is displayed.
- In addition to the setting of this parameter, hold is canceled by the following conditions:



Setting

Setting Range	Default
HöF : Hold cancel / HöL: Hold	HöF



See

- Related description
  - 4.4 Program Operation (page 4-13)
  - 4.8 How to Use Event Input (page 4-17)
- Related parameters
  - “Event input assignment 1” (option mode)

**Adv****Advance**

Function

- This parameter can only be used for monitoring when the controller is reset.
- Forcibly advances program operation by one step.
- When the event input to which “hold/hold cancel” is assigned is ON, [Adv] (advance) is displayed.



Example of use

- Selecting this parameter, it is set to [HöF] (OFF).
- When [Adv] (ON) is selected, program operation is advanced by one step.
- After program execution is completed, the setting automatically returns to [HöF].
- Hold is also continued after the program step is advanced when the program is executed in a hold state.



See

- Related description
  - 4.4 Program Operation (page 4-13)
  - 4.7 How to Use Event Input (page 4-17)
- Related parameters
  - “Event input assignment 1” (option mode)

## Stbā

### Standby time monitor

Conditions of Use

The controller must be in a standby state.



Function

- Displays the remaining standby time. (This time is not displayed when the controller is reset.)



Monitor

Monitor Range	Unit
0.00 to 99.59	Hour, minute



See

- Related description  
4.6 Setting Running Conditions (page 4-19)
- Related parameter  
“Standby time” (level 2 mode)

## ElāE

### Pattern elapsing time



Function

- Displays the time that has elapsed since the start of the pattern. When a pattern is repeatedly executed or all patterns are executed, the time counting restarts at the top of each pattern.



Monitor

Monitor Range	Unit
0.00 to 99.59	Program time unit

When the time exceeds “99.59”, “99.59” blinks on the display.

## rPlā

### Pattern execution count monitor



Function

- Displays the number of times that the current pattern has been executed. “0” is displayed when the controller is reset or when the controller is in a standby state.



Monitor

Monitor Range	Unit
0 to pattern execution count	Times



See

- Related parameter  
“Pattern execution count” (program mode)


## Level 0 Mode



**MV monitor (heat)**

Conditions of Use

The control must be standard control or heating and cooling control.



**MV monitor (cool)**



Function

- This parameter cannot be set.
- Monitors the manipulated variable on the heating or cooling side.
- The manipulated variable in a standard control system is monitored in the “MV monitor (heat)” parameter.
- The “MV monitor (cool)” parameter can be used only during heating and cooling control.



Monitor

- MV monitor (heat)








Control	Monitor Range	Unit
Standard	-5.0 to 105.0	%
Heating and cooling	0.0 to 105.0	%























- MV monitor (cool)

Control	Monitor Range	Unit
Heating and cooling	0.0 to 105.0	%



## Program Mode

- The parameters in this mode can be used only when the “security” parameter (protect mode) is set to “0” to “4”.
- This mode contains the parameters that you use for programming.
- To select this mode, press the  key for 1 second minimum. The display changes to the menu display. If you select [P-LN] using the  and  keys, and then press the  key for 1 second minimum, the controller enters the program mode.
- To select parameters in this mode, press the  key. To change parameter settings, use the  or  keys.
- The following table shows the parameters supported in this mode and the page where the parameter is described.

Symbol	Parameter Name	Page
	Pattern No.	5-7 *1
	Number of steps	5-12
	Step 0 SP or Target SP 0	5-12
	Ramp rate 0	5-13
	Step 0 time or Soak time 0	5-13
	Step 7 SP or Target SP7	5-12
	Ramp rate 7	5-13
	Step 7 time or Soak time 7	5-13
	Step 8 SP	5-12
	Step 8 time	5-13
	Step 15 SP	5-12
	Step 15 time	5-13
	Pattern execution count	5-14
	Alarm value 1	5-14
	Alarm value 2	5-14
	Alarm value 3	5-14
	Time signal 1 enabled step	5-15
	Time signal 1 ON time	5-15
	Time signal 1 OFF time	5-16
	Time signal 2 enabled step	5-15
	Time signal 2 ON time	5-15
	Time signal 2 OFF time	5-16

\*1 This parameter is described as a level 0 mode parameter. For details, see page 5-7.

# Program Mode

5-nō

Number of steps



Function

- Specifies the number of steps in the current pattern.



Setting

Setting Range	Unit	Default
1 to 16	None	8



See

- Related description  
3.5 Setting Patterns (page 3-14)
- Related parameter  
All parameters in the program mode

SP0

Step 0 time (Step time)

Target SP 0 (Rate of rise programming)  
to

SP7

Step 7 SP (Step time)

Target SP 7 (Rate of rise programming)

SP8

Step 8 SP (Step time)

to

SP 15

Step 15 SP (Step time)

Conditions of Use  
Within the number of steps.



Function

- Sets the SP of steps 0 to 15 when the step time is set.
- Sets target SP 0 to 7 when the rate of rise programming is set.
- During temperature input, the decimal point position is dependent on the currently selected sensor, and during analog input on the results of scaling.



Setting

Setting Range	Unit	Default
SP lower limit to SP upper limit	EU	0



See

- Related description  
3.5 Setting Patterns (page 3-14)  
4.3 Ramp Rise Rate Setup Program (page 4-9)
- Related parameters  
All parameters in the program mode  
“Input type” “Scaling upper limit” “Scaling lower limit” “Decimal point” (setup mode)  
“Step time/Rate of rise programming” (expansion mode)

# Program Mode

**Pr0**

**Ramp rate 0**

to

**Pr7**

**Ramp rate 7**

Conditions of Use

Within the number of steps only in the rate of rise programming.



Function



Setting



See

- Sets the degree of change per time unit of ramp rate in the step time ramp step.

Setting Range	Unit	Default
0 to 9999	EU/Time unit of ramp rate	0

0: The ramp step is skipped.

- Related description  
4.3 Ramp Rise Rate Setup Program (page 4-9)
- Related parameters  
All parameters in the program mode  
“Step time/Rate of rise programming” “Time unit of ramp rate” (expansion mode)

**tL0**

**Step 0 time (Step time)**

**Soak time 0 (Rate of rise programming)**

to

**tL7**

**Step 7 time (Step time)**

**Soak time 7 (Rate of rise programming)**

**tL8**

**Step 8 time (Step time)**

to

**tL15**

**Step 15 time (Step time)**

Conditions of Use

Within the number of steps.



Function



Setting



See

- Sets the time of steps 0 to 15 when the step time is set.
- Sets soak steps 0 to 7 when the rate of rise programming is set.

Setting Range	Unit	Default
0.00 to 99.59	Program time unit	0.00

- Related description  
3.5 Setting Patterns (page 3-14)  
4.3 Ramp Rise Rate Setup Program (page 4-9)
- Related parameters  
All parameters in the program mode  
“Step time/Rate of rise programming” “Program time unit” “Time unit of ramp rate” (expansion mode)

# Program Mode

**rPl**

## Pattern execution count



Function

- Executes the current pattern for the preset number of times.
- The count during pattern execution can be monitored in the “pattern execution count monitor” (level 0 mode).



Setting

Setting Range	Unit	Default
0 to 9999	Time	1

0: The pattern is not executed



See

- Related description  
4.4 Program Operation/Pattern operation (page 4-13)
- Related parameters  
All parameters in the program mode

**AL - 1**

**Alarm value 1**

**AL - 2**

**Alarm value 2**

**AL - 3**

**Alarm value 3**

### Conditions of Use

Alarms must be assigned as outputs. For example, if alarm outputs 1 and 2 only are assigned as outputs, the “alarm value 3” parameter cannot be used.



Function

- This parameter is used for monitoring or setting the alarm values of alarm outputs 1 to 3.
- During temperature input, the decimal point position is dependent on the currently selected sensor, and during analog input on the results of scaling.



Setting

Setting Range	Unit	Default
-1999 to 9999	EU	0



See

- Related description  
3.4Setting Alarm Type (page 3-10)  
3.5Setting Patterns/Alarm value (page 3-16)
- Related parameters  
“Input type” “Scaling upper limit” “Scaling lower limit” “Decimal point” “Control output 1 assignment” “Control output 2 assignment” “Auxiliary output 1 assignment” “Alarm 1 type” “Alarm 2 type” “Alarm 3 type” “Alarm 1 open in alarm” “Alarm 2 open in alarm” “Alarm 3 open in alarm” (setup mode)  
“Alarm 1 hysteresis” “Alarm 2 hysteresis” “Alarm 3 hysteresis” (level 2 mode)

# Program Mode

ts 15

**Time signal 1 enabled step**

Conditions of Use

Each of the time signals must be assigned as outputs.

ts 25

**Time signal 2 enabled step**



Function



Setting



See

- Sets the step in which the time signal is used.

Setting Range	Unit	Default
0 to 15	None	0

- Related description  
4.5 Program output (page 4-17)
- Related parameters  
“Time signal 1 ON time” “Time signal 1 OFF time” “Time signal 2 ON time” “Time signal 2 OFF time” (program mode)

on 1

**Time signal 1 ON time**

Conditions of Use

Each of the time signals must be assigned as outputs.

on 2

**Time signal 2 ON time**



Function



Setting



See

- Sets the ON time of the time signal.

Setting Range	Unit	Default
0.00 to 99.59	Program time unit	0.00

- Related description  
4.5 Program Output (page 4-17)
- Related parameters  
“Time signal 1 enabled step” “Time signal 2 enabled step” “Time signal 1 OFF time” “Time signal 2 OFF time” (program mode)  
“Program time unit” (expansion mode)

# Program Mode

OFF 1

Time signal 1 OFF time

OFF 2

Time signal 2 OFF time

Conditions of Use  
Each of the time signals must be assigned as outputs.



Function

- Sets the OFF time of the time signal.



Setting






Setting Range	Unit	Default
0.00 to 99.59	Program time unit	0.00














See

- Related description  
4.5 Program output (page 4-17)
- Related parameters  
“Time signal 1 enabled step” “Time signal 2 enabled step” “Time signal 1 ON time”  
“Time signal 2 ON time” (program mode)  
“Program time unit” (expansion mode)

## Level 1 Mode

- The parameters in this mode can be used only when the “security” parameter (protect mode) is set to “0” to “3”.
- This mode contains the main parameters for adjusting control, such as executing AT (auto-tuning), setting the control period, setting PID parameters.
- To select this mode, press the  key for 1 second minimum. The display changes to the menu display. If you select [LW-'] then press the  key for 1 second minimum, the controller enters the level 1 mode.
- To select parameters in this mode, press the  key. To change parameter settings, use the  or  keys.
- The following table shows the parameters supported in this mode and the page where the parameter is described.

Symbol	Parameter Name	Page
	AT Execute/Cancel	5-18
	Proportional band	5-18
	Integral time	5-18
	Derivative time	5-18
	Cooling coefficient	5-19
	Dead band	5-19
	Manual reset value	5-20
	Hysteresis (heat)	5-21
	Hysteresis (cool)	5-21
	Control period (heat)	5-22
	Control period (cool)	5-22

# Level 1 Mode



## AT Execute/Cancel

### Conditions of Use

The controller must be in operation, and control must be advanced PID control.



Function



Example of use



See

- Selects the limit cycle of MV change width (40% or 100%) for execution. After AT execution, the “PID” and the “LBA detection time” (Loop Break Alarm) parameters are automatically set.
- During heating and cooling control, only 100%AT can be executed.
- To execute 40%AT, select [AT - 1], and to execute 100%AT, select [AT - 2]. During execution of auto-tuning, the AT LED flashes. However, note that during heating and cooling control, [AT - 1] is not displayed.
- When AT execution ends, the parameter setting automatically returns to [OFF].
- Related description  
3.8 Adjusting Control Operation/AT (page 3-25)
- Related parameters  
“Proportional band” “Integral time” “Derivative time” (level 1 mode)  
“LBA detection mode” (level 2 mode)



## Proportional band

### Conditions of Use

The control must be advanced PID control.



## Integral time



## Derivative time



Function



Setting



See

- Sets the PID parameters. Note that PID is automatically set when AT is executed.

Parameter	Setting Range	Unit	Default
Proportional band	0.1 to 999.9	%FS	10.0
Integral time	0 to 3999 *1	Second	233
Derivative time	0 to 39999	Second	40

- Related parameter  
“AT Execute/Cancel” (level 1 mode)



**C-5C**

## Cooling coefficient

### Conditions of Use

The control must be either heating and cooling control, or advanced PID control.



Function



Setting



See

- In heating and cooling control, P at the cooling side is calculated by the following formula:

$$\text{Cooling side P} = \text{Cooling coefficient} \times P$$

Setting Range	Unit	Default
0.01 to 99.99	None	1.00

- Related description  
4.1 Selecting the Control Method/Heating and cooling control (page 4-2)
- Related parameter  
“Proportional band” (level 1 mode)

**C-db**

## Dead band

### Conditions of Use

The control system must be heating and cooling control.



Function



Setting



See

- Sets the output dead band width in a heating and cooling control system. A negative setting sets an overlap band.

Setting Range	Unit	Default
-19.99 to 99.99	%FS	0.00

- Related description  
4.1 Selecting the Control Method/Heating and cooling control (page 4-2)

# Level 1 Mode

df-r

## Manual reset value

### Conditions of Use

The control must be either standard control or advanced PID control, and the “integral time” parameter must be set to “0”.



Function

- Sets the required manipulated variable to remove offset during stabilization of P or PD control.



Setting

Setting Range	Unit	Default
0.0 to 100.0	%	50.0

HYS

## Hysteresis (heat)

### Conditions of Use

The control system must be ON/OFF control.

CHYS

## Hysteresis (cool)



Function

- Sets the hysteresis for ensuring stable operation at ON/OFF switching.
- In a standard control system, use the “hysteresis (heat)” parameter. The “hysteresis (cool)” parameter cannot be used.
- In a heating and cooling control system, the hysteresis can be set independently for heating and cooling. Use the “hysteresis (heat)” parameter to set the heating side hysteresis, and use the “hysteresis (cool)” parameter to set the cooling side hysteresis.



Setting

Parameter	Setting Range	Unit	Default
Hysteresis (heat)	0.01 to 99.99	%FS	0.10
Hysteresis (cool)	0.01 to 99.99	%FS	0.10



See

- Related description  
4.1 Selecting the Control Method/ON/OFF control (page 4-5)
- Related parameters  
“Control output 1 assignment” “Control output 2 assignment” (setup mode)  
“PID/ON/OFF” (expansion mode)

CP

**Control period (heat)**

Conditions of Use

Relay, SSR or voltage output must set as the outputs, and the control must be set to advanced PID control, standard control or heating and cooling control.

C-CP

**Control period (cool)**



Function

- Sets the pulse output period. Set the control period taking the control characteristics and life expectancy of the controller into consideration.
- In a standard control system, use the “control period (heat)” parameter. The “control period (cool)” parameter cannot be used.
- In a heating and cooling control system, the control period can be set independently for heating and cooling. Use the “control period (heat)” parameter to set the heating side control period, and use the “control period (cool)” parameter to set the cooling side control period.



Setting








Parameter	Setting Range	Unit	Default
Control period (heat)	1 to 99	Second	20
Control period (cool)	1 to 99	Second	20

















See

- Related description  
3.3 Setting Output Specifications (page 3-7)
- Related parameters  
“Control output 1 assignment” “Control output 2 assignment” (setup mode)

## Level 2 Mode

- The parameters in this mode can be used only when the “security” parameter (protect mode) is set to “0” to “2”.
- This mode contains the auxiliary parameters for adjusting control. These parameters include parameters for limiting the manipulated variable, parameters for switching between remote and local operation, and parameters for setting the LBA (Loop Break Alarm), alarm hysteresis, and input digital filter values.
- To select this mode, press the  key for 1 second minimum. The display changes to the menu display. If you select [1 - 2] pressing the  and  keys, and then press the  key for 1 second minimum, the controller enters the level 2 mode.
- To select parameters in this mode, press the  key. To change parameter settings, use the  or  keys.
- The following table shows the parameters supported in this mode and the page where the parameter is described.

Symbol	Parameter Name	Page
	Remote/Local	5-25
	Standby time	5-25
	LBA detection time	5-26
	MV at reset	5-26
	MV at PV error	5-27
	MV upper limit	5-27
	MV lower limit	5-27
	MV change rate limit	5-27
	Input digital filter	5-28
	Alarm 1 hysteresis	5-29
	Alarm 2 hysteresis	5-29
	Alarm 3 hysteresis	5-29
	Input shift upper limit	5-29
	Input shift lower limit	5-29

**r - L**

## Remote/Local

### Conditions of Use

The communications function must be in use.



Function

- Switches between remote and local operation.
- To change the parameter setting during remote operation, use the communications function. To change the parameter setting during local operation, change the setting on the E5CK-T controller. You can check the parameter setting by both communications and on the E5CK-T controller regardless of whether the controller is switched to remote or local operation.



Setting

Setting Range	Default
"r - L": remote / "L - L": local	L - L



See

- Related description  
Chapter 6 Using the Communications Functions
- Related parameters  
"Communication stop bit" "Communication data length" "Communication parity"  
"Communication baud rate" "Communication unit No." "Event input assignment 1" (option mode)



Model

- Option units  
E53-CK01/03

**Stb**

## Standby time



Function

- Sets the time until program operation is started after the run instruction is issued.



Setting

Setting Range	Unit	Default
0.00 to 99.59	Hour, minute	0.00



See

- Related description  
4.6 Setting Running Conditions/Starting the program run/Standby operation (page 4-20)
- Related parameter  
"Standby time monitor" (level 0 mode)

## Level 2 Mode

**LbA**

### LBA detection time

#### Conditions of Use

The LBA (Loop Break Alarm) function must be assigned as an output.



Function

- This parameter is automatically set by AT execution.
- The LBA is output if the change width of the process value falls below 0.2 %full-scale of the time preset to this parameter when the manipulated variable is set in the “MV upper limit” or “MV lower limit” parameters.
- The LBA function is disabled when this parameter is set to “0”.



Setting

Setting Range	Unit	Default
0 to 9999	Second	0



See

- Related description  
4.8 LBA (page 4-20)  
8.3 How to Use Error Output (page 8-5)
- Related parameters  
“AT Execute/Cancel” (level 1 mode)  
“Control output 1 assignment” “Control output 2 assignment” “Auxiliary output 1 assignment” (setup mode)

**MV-r**

### MV at reset

#### Conditions of Use

Advanced PID control.

**MV-E**

### MV at PV error



Function

- The “MV at reset” parameter sets the manipulated variable when operation has stopped.
- The “MV at PV error” parameter sets the manipulated variable when an input error occurs.



Setting

Control Method	Setting Range	Unit	Default
Standard	-5.0 to 105.0	%	0.0
Heating and cooling	-105.0 to 105.0	%	0.0

The manipulated variable at the cooling side during heating and cooling control is expressed as a negative value.



See

- Related description  
MV at reset : 3.7 Starting and Stopping Operation (page 3-21)  
MV at PV error : 8.2 How to Use the Error Display (page 8-3)

**OL-H**

**MV upper limit**

**OL-L**

**MV lower limit**

**OrL**

**MV change rate limit**

Conditions of Use

The control must be advanced PID control.



Function

- The “MV upper limit” and “MV lower limit” parameters set the upper and lower limits of the manipulated variable. When the manipulated variable calculated by the E5CK-T controller strays from the upper- and lower-limit range, the upper limit or lower limit set to these parameters is output, respectively.
- The “MV change rate limit” parameter sets the maximum permissible change width per second of the manipulated variable. If a change in the manipulated variable causes this parameter setting to be exceeded, the calculated value is reached while changing the value by the per-second value set in this parameter.  
This function is disabled when the set value is “0.0”.



Setting

- MV upper limit  
The setting ranges during standard control and heating and cooling control are different.

Control Method	Setting Range	Unit	Default
Standard	MV lower limit +0.1 to 105.0	%	105.0
Heating and cooling	0.0 to 105.0	%	105.0

The manipulated variable at the cooling side during heating and cooling control is expressed as a negative value.

- MV lower limit  
The setting ranges during standard control and heating and cooling control are different.

Control Method	Setting Range	Unit	Default
Standard	-5.0 to MV upper limit -0.1	%	-5.0
Heating and cooling	-105.0 to 0.0	%	-105.0

The manipulated variable at the cooling side during heating and cooling control is expressed as a negative value.

- MV change rate limit

Setting Range	Unit	Default
0.0 to 100.0	%/S	0.0



See

- Related description  
4.2 Operating Condition Restrictions/Manipulated variable restrictions (page 4-7)

## Level 2 Mode


**INF**

### Input digital filter



Function

- Sets the time constant of the input digital filter. The following figure shows the effect on data after passing through the digital filter.



Setting

Setting Range	Unit	Default
0 to 9999	Second	0

**ALH1**

### Alarm 1 hysteresis

**ALH2**

### Alarm 2 hysteresis

**ALH3**

### Alarm 3 hysteresis

#### Conditions of Use

Alarms must be assigned as output. For example, if alarm outputs 1 and 2 only are assigned as outputs, the “alarm 3 hysteresis” parameter cannot be used.



Function

- Sets the hysteresis of alarm outputs 1 to 3.



Setting

Setting Range	Unit	Default
0.01 to 99.99	%FS	0.02



See

- Related description  
3.4 Setting Alarm Type (page 3-10)

- Related parameters

“Alarm 1 type” “Alarm 2 type” “Alarm 3 type” “Alarm 1 open in alarm” “Alarm 2 open in alarm” “Alarm 3 open in alarm” (setup mode)

“Alarm value 1” “Alarm value 2” “Alarm value 3” (Program mode)



LnSH

Input shift upper limit

LnSL

Input shift lower limit

## Conditions of Use

The input type must be set to temperature input (thermocouple or platinum resistance thermometer).



Function

- Sets each of the shift amounts for the input shift upper and lower limit values.



Setting








Setting Range	Unit	Default
-199.9 to 999.9	°C or °F	0.0



















See

- Related description  
3.2 Setting Input Specifications (page 3-4)
- Related parameter  
“Input type” (setup mode)

# Setup Mode

- The parameters in this mode can be used only when the “security” parameter (protect mode) is set to “0” and “1”.
- This mode contains the parameters for checking or setting the basic specifications of the E5CK-T controller. These parameters include parameters for specifying the input type, scaling, output assignments, and direct/reverse operation.
- To select this mode, press the  key for 1 second minimum. The display changes to the menu display. If you select [SEt] pressing the  and  keys, and then press the  key for 1 second minimum, the controller enters the setup mode.
- To select parameters in this mode, press the  key. To change parameter settings, use the  or  keys.
- The following table shows the parameters supported in this mode and the page where the parameter is described.

Symbol	Parameter Name	Page
	Input type	5-29
	Scaling upper limit	5-30
	Scaling lower limit	5-30
	Decimal point	5-30
	°C/°F selection	5-31
	Parameter initialize	5-31
	Control output 1 assignment	5-32
	Control output 2 assignment	5-32
	Auxiliary output 1 assignment	5-33
	Alarm 1 type	5-34
	Alarm 1 open in alarm	5-35
	Alarm 2 type	5-34
	Alarm 2 open in alarm	5-35
	Alarm 3 type	5-34
	Alarm 3 open in alarm	5-35
	Direct/Reverse operation	5-35

## In-t

### Input type



Function

- Sets the sensor type by the code.



Setting

- Set the code according to the following table. Default is “2 : K1 thermocouple”.

Set value	Input Type	
0	JPt100 -199.9 to 650.0 (°C)	/-199.9 to 999.9 (°F)
1	Pt100 -199.9 to 650.0 (°C)	/-199.9 to 999.9 (°F)
2	K1 -200 to 1300 (°C)	/-300 to 2300 (°F)
3	K2 0.0 to 500.0 (°C)	/0.0 to 900.0 (°F)
4	J1 -100 to 850 (°C)	/-100 to 1500 (°F)
5	J2 0.0 to 400.0 (°C)	/0.0 to 750.0 (°F)
6	T -199.9 to 400.0 (°C)	/-199.9 to 700.0 (°F)
7	E 0 to 600 (°C)	/0 to 1100 (°F)
8	L1 -100 to 850 (°C)	/-100 to 1500 (°F)
9	L2 0.0 to 400.0 (°C)	/0.0 to 750.0 (°F)
10	U -199.9 to 400.0 (°C)	/-199.9 to 700.0 (°F)
11	N -200 to 1300 (°C)	/-300 to 2300 (°F)
12	R 0 to 1700 (°C)	/0 to 3000 (°F)
13	S 0 to 1700 (°C)	/0 to 3000 (°F)
14	B 100 to 1800 (°C)	/300 to 3200 (°F)
15	W 0 to 2300 (°C)	/0 to 4100 (°F)
16	PLII 0 to 1300 (°C)	/0 to 2300 (°F)
17	4 to 20mA	
18	0 to 20mA	
19	1 to 5V	
20	0 to 5V	
21	0 to 10V	

Platinum resistance thermometer

Thermocouple

Current input

Voltage input



See

- Related description

3.2 Setting Input Specifications (page 3-4)

- Related parameter

When input type is set to temperature input:

“°C/°F selection” (setup mode)

When input type is set to voltage input or current input:

“Scaling upper limit” “Scaling lower limit” “Decimal point” (setup mode)

# Setup Mode

Ln-H

Scaling upper limit

Ln-L

Scaling lower limit

dP

Decimal point

Conditions of Use

The input type must be set to analog input (voltage or current input).



Function

- This parameter can be used when voltage input or current input is selected as the input type.
- When voltage input or current input is selected as the input type, scaling is carried out. Set the scaling upper limit in the “scaling upper limit” parameter and the scaling lower limit in the “scaling lower limit” parameter.
- The “decimal point” parameter specifies the decimal point position of parameters (alarm value, etc.) whose unit is set to EU (Engineering Unit).



Setting

- Scaling upper limit, Scaling lower limit

Parameter	Setting Range	Unit	Default
Scaling upper limit	Scaling lower limit +1 to 9999	None	100
Scaling lower limit	-1999 to scaling upper limit -1	None	0

- Decimal point : Default is “0”.

Set Value	Setting	Example
0	0 digits past decimal point	1234
1	1 digit past decimal point	123.4
2	2 digits past decimal point	12.34
3	3 digits past decimal point	1.234



See

- Related description  
3.2 Setting Input Specifications (page 3-4)
- Related parameter  
“Input type” (setup mode)



°C/°F selection

Conditions of Use  
The input type must be set to temperature input (thermocouple or platinum resistance thermometer).



Function

- This parameter can be used when thermocouple or platinum resistance thermometer is selected as the input type.
- Set the temperature input unit to either of “°C” or “°F”.



Setting

Setting Range	Default
“ $\square$ ”: °C / “ $\square$ ”: °F	$\square$



See

- Related description  
3.2 Setting Input Specifications (page 3-4)
- Related parameter  
“Input type” (setup mode)



Parameter initialize



Function

- Returns parameter settings to their factory settings. However, note that the following parameters are not affected by execution of this parameter:  
“Input type”, “Scaling upper limit”, “Scaling lower limit”, “Decimal point” and “°C/°F selection”



Example of use

- When this parameter is selected, [no] (“no”) is first displayed. To initialize parameters, press the key to specify [YES] (“yes”).

# Setup Mode

**OUT 1**

Control output 1  
assignment

**OUT 2**

Control output 2  
assignment



Function

- Assigns the output functions to either of control output 1 or 2.
- The following 10 output functions can be assigned as outputs:  
Control output (heat), Control output (cool), Alarms 1 to 3, LBA, Time signals 1 and 2, Program end and Stage output
- When the output function assigned to control output 1 or control output 2 is ON, the “OUT1” or “OUT2” LED lights.



Setting

Symbol	HEAT	COOL	AL - 1 to AL - 3	LBA
Function	Control output (heat)	Control output (cool)	Alarms 1 to 3	LBA

Symbol	TS - 1 to TS - 2	PEND	STG
Function	Time signals 1 to 2	Program end	Stage output

Default :

“Control output 1” = [HEAT], “Control output 2” = [AL - 1].



See

- Related description  
3.3 Setting Output Specifications (page 3-7)
- Related parameters
  - Alarm-related parameters
  - Heating and cooling related parameter  
“Time signal 1 enabled step” “Time signal 2 enabled step” “Time signal 1 to 2 ON time” “Time signal 1 to 2 OFF time” (program mode)  
“LBA detection time” (level 2 mode)

**SUB 1**

## Auxiliary output 1 assignment



Function

- Assigns output functions to auxiliary output 1.  
The following 10 output functions can be assigned as outputs:  
Alarms 1 to 3, LBA, Time signals 1 to 2, Program end, Stage output, Error 1 (input error), Error 2 (A/D converter error)
- When the output function assigned to auxiliary output 1 is ON, the SUB1 LED lights.



Setting

Symbol	<i>AL-1</i> to <i>AL-3</i>	<i>LbA</i>	<i>TS-1</i> to <i>TS-2</i>
Function	Alarms 1 to 3	LBA	Time signals 1 to 2

Symbol	<i>PEnd</i>	<i>StG</i>	<i>SErr</i>	<i>E333</i>
Function	Program end	Stage output	Error 1	Error 2

These parameters are factory-set to [*AL-2*].



See

- Related description  
3.3 Setting Output Specifications (page 3-7)
- Related parameters
- Alarm-related parameters  
“Time signal 1 enabled step” “Time signal 2 enabled step” “Time signal 1 to 2 ON time” “Time signal 1 to 2 OFF time” (program mode)  
“LBA detection time” (level 2 mode)

# Setup Mode

ALt1

Alarm 1 type

ALt2

Alarm 2 type

ALt3

Alarm 3 type

## Conditions of Use

Alarms must be assigned as outputs. For example, if alarm output 1 and 2 only are assigned as outputs, the “alarm 3 type” parameter cannot be used.



Function



Setting

- “Alarm 1 to 3 type” parameters specify the operation of the alarm by the one of the set values in the following table. For details of operation at an alarm, see page 3-10.

Set Value	Settings	Set Value	Settings
1	Upper- and lower-limit alarm	7	Lower-limit alarm with standby sequence
2	Upper-limit alarm	8	Absolute-value upper-limit alarm
3	Lower-limit alarm	9	Absolute-value lower-limit alarm
4	Upper- and lower-limit range alarm	10	Absolute-value upper-limit alarm with standby sequence
5	Upper- and lower-limit alarm with standby sequence	11	Absolute-value lower-limit alarm with standby sequence
6	Upper-limit alarm with standby sequence		

Default is “2 : upper limit”.



See

- Related description  
3.4 Setting Alarm Type (page 3-10)
- Related parameters  
“Alarm value 1” “Alarm value 2” “Alarm value 3” (Program mode)  
“Alarm 1 hysteresis” “Alarm 2 hysteresis” “Alarm 3 hysteresis” (level 2 mode)  
“Alarm 1 open in alarm” “Alarm 2 open in alarm” “Alarm 3 open in alarm” “Control output 1 assignment” “Control output 2 assignment” “Auxiliary output 1 assignment” (setup mode)



**AL 1n**

**Alarm 1 open in alarm**

**AL 2n**

**Alarm 2 open in alarm**

**AL 3n**

**Alarm 3 open in alarm**

## Conditions of Use

Alarms must be assigned as outputs. For example, if alarm outputs 1 and 2 only are assigned as outputs, the “alarm 3 open in alarm” parameter cannot be used.



Function

- Sets the output states of alarms 1 to 3.
- When the controller is set to “close in alarm,” the status of the alarm output function is output as it is. When set to “open in alarm,” the status of the alarm output function is output inverted. The following table shows the relationship between alarm output functions, alarm output and output LEDs.

	Alarm Output Function	Alarm Output	Output LED
Close in alarm	ON	ON	Lit
	OFF	OFF	Not lit
Open in alarm	ON	OFF	Lit
	OFF	ON	Not lit



Setting

Setting Range	Default
“ n - 0 ” : Close in alarm/ “ n - 1 ” : Open in alarm	n - 0



See

- Related description  
3.4 Setting Alarm Type (page 3-10)
- Related parameters  
“Alarm value 1” “Alarm value 2” “Alarm value 3” (level 1 mode)  
“Alarm 1 hysteresis” “Alarm 2 hysteresis” “Alarm 3 hysteresis” (level 2 mode)  
“Alarm 1 open in alarm” “Alarm 2 open in alarm” “Alarm 3 open in alarm” “Control output 1 assignment” “Control output 2 assignment” “Auxiliary output 1 assignment” (setup mode)

**0rEv**

**Direct/Reverse operation**



Function

- “Direct operation” (or normal operation) refers to control where the manipulated variable is increased according to the increase in the process value. Alternatively, “reverse operation” refers to control where the manipulated variable is increased according to the decrease in the process value.



Setting








Setting Range	Default
“ 0r - r ” : Reverse operation/ “ 0r - d ” : Direct operation	0r - r



See

- Related description  
3.3 Setting Output Specifications/Direct/reverse operation (page 3-8)

# Expansion Mode

- The parameters in this mode can be used only when the “security” parameter (protect mode) is set to “0” and “1”.
- This mode contains the parameters for setting expanded functions. These parameters include parameters for setting the SP setting limiter, selecting advanced PID and ON/OFF control, and setting the program time unit, step time/rate of rise programming, time unit of ramp rate and the automatic return of display mode.
- To select this mode, press the  key for 1 second minimum. The display changes to the menu display. If you select [ESt] using the  and  keys, and then press the  key for 1 second minimum, the controller enters the expansion mode.
- To select parameters in this mode, press the  key. To change parameter settings, use the  or  keys.
- The following table shows the parameters supported in this mode and the page where the parameter is described.

Symbol	Parameter Name	Page
SL-H	Set point upper limit	5-37
SL-L	Set point lower limit	5-37
EntL	PID/ON/OFF	5-37
P-on	Operation at power ON	5-38
ESEt	End condition	5-38
P-no	Number of patterns	5-39
t-U	Program time unit	5-39
t-Pr	Step time/Rate of rise programming	5-40
Pr-U	Time unit of ramp rate	5-40
PvSt	PV start	5-41
rPAL	Alarm during ramp step enable	5-41
rUnA	Run all enable	5-41
ALFA	$\alpha$	5-42
At-G	AT calculated gain	5-42
rEt	Automatic return of display mode	5-43
At-H	AT hysteresis	5-43
LbAb	LBA detection width	5-43

5L-H

Set point upper limit

5L-L

Set point lower limit



Function

- Limits the upper and lower limits when the SP is set. The SP can be set within the range defined by the upper and lower limit set values of the “set point upper limit” and “set point lower limit ” parameters. Note that as these parameters are reset, the SP of existing settings that are out of the range are forcibly changed to one of the upper or lower limit values.
- When the temperature input type and temperature unit have been changed, the set point upper limit and set point lower limit are forcibly changed to the upper and lower limits of the sensor.
- During temperature input, the decimal point position is dependent on the currently selected sensor, and during analog input on the results of scaling.



Setting

Parameter	Setting Range	Unit	Default
Set point upper limit	Set point lower limit +1 to scaling upper limit	EU	1300
Set point lower limit	Scaling lower limit to set point upper limit -1	EU	-200

During temperature input, the range becomes the range of use of the selected sensor instead of the range defined by the scaling upper and lower limit values.



See

- Related description  
4.2 Operating Condition Restrictions (page 4-7)
- Related parameter  
“Input type” “Scaling upper limit” “Scaling lower limit” “Decimal point” (setup mode)

Ctrl

PID/ON/OFF



Function

- Selects advanced PID control or ON/OFF control.



Setting

Setting Range	Default
“PID”:Advance PID/ “ON/OFF”:ON/OFF	PID



See

- Related description  
4.1 Selecting the Control Method/ON/OFF control (page 4-5)
- Related parameters  
“Hysteresis (heat)” “Hysteresis (cool)” (level 1 mode)

# Expansion Mode

**P-ON**

## Operation at power ON



Function

Selects one of the following operations when the power is turned ON:

- “Continue” : Starts operations from the state that was active when the power was interrupted.
- “Reset” : Resets the controller.
- “Run” : Starts normal program operation.
- “Manual” : Sets the controller to the manual mode.

“Manual” cannot be selected when Auto/Manual key operation is protected.



Setting

Setting Range	Default
“ <b>Cōn</b> ”:Continue/“ <b>rSt</b> ”:Reset/“ <b>rUn</b> ”:Run/“ <b>MAN</b> ”:Manual	<b>Cōn</b>



See

### ● Related description

4.6 Setting Running Conditions/Operation at power ON (page 4-14)

**ESet**

## End condition



Function

- Specifies a reset state or continued control on the SP of the final step after program operation ends.
- The program end state will not change when the “number of steps” parameter setting has been changed after program operation ends. However, when control on the SP is continued, the SP of the final step is selected after the number of steps has been changed.



Setting

Setting Range	Default
“ <b>rSt</b> ”:Reset/“ <b>SP</b> ”:Continued control using final SP	<b>rSt</b>



See

### ● Related description

4.6 Setting Running Conditions/End condition (page 4-15)

### ● Related parameter

“Number of steps” (program mode)

Note: The end of operation does not refer to the end of the pattern. It refers to the end of executing the pattern the specified number of times.

# Expansion Mode

**P-nā**

## Number of patterns



Function

- Sets the number of patterns that can be used in a program.



Setting

Setting Range	Default
1 to 4	1



See

- Related parameters
  - “Run all enable” (expansion mode)
  - “Event input assignment 1” (option mode)

**t-U**

## Program time unit



Function

- Specifies the time unit of the following parameters:
  - “Pattern elapsing time monitor”, “Step 0 to 15 time”/Soak time 0 to 7”, “Time signal 1 ON time” “Time signal 2 ON time” “Time signal 1 OFF time” “Time signal 2 OFF time”



Setting

Setting Range	Default
“HHnā” :Hour, minute/ “nāSS” :Minute, second	HHnā



See

- Related parameters
  - “Pattern elapsing time monitor” (level 1 mode)
  - “Steps 0 to 15 time/Soak time 0 to 7” “Time signal 1 ON time” “Time signal 2 ON time” “Time signal 1 OFF time” “Time signal 2 OFF time” (program mode)

# Expansion Mode

**t-P<sub>r</sub>**

## Step time/Rate of rise programming



Function

- Specifies the program method.



Setting

Setting Range	Default
"t <sub>0</sub> ~t <sub>n</sub> ": Set time/ "P <sub>r</sub> ": Rate of rise programming	t <sub>0</sub> ~t <sub>n</sub>



See

- Related description  
3.5 Setting Patterns (page 3-14)  
4.3 Ramp Rise Rate Setup Program (page 4-9)
- Related parameter  
"Step 0 to 15 SP/Target SP 0 to 7" "Ramp rate 0 to 7" "Step 0 to 15 time/Soak time 0 to 7" (program mode)

**P-U**

## Time unit of ramp rate

Conditions of Use  
Rate of rise programming must be set.



Function

- Specifies the unit time of "rate of rise 0 to 7."



Setting

Setting Range	Default
"m": Minute/ "H": Hour	m



See

- Related parameter  
"Ramp rate 0 to 7" (program mode)

# Expansion Mode

**PVSt**

## PV start

Conditions of Use  
The set time must be set.



Function

Specifies either of the following current SP at the start of program operation:

- PV : Process value at start of program operation (PV start)
- SP : SP of step 0 (normal program operation)

When “PV” is selected, program operation is started from the position where the current SP first matches the PV at the start of program operation. If the SP does not match the PV, program operation is started from the beginning of the program.



Setting

Setting Range	Default
“PV” : PV/ “SP” : SP	SP



See

- Related description  
4.6 Setting Running Conditions/Starting the program run/PV start (page 4-20)

**rPAL**

## Alarm during ramp step enable



Function

- To enable alarms during the ramp step, set to [ON]. To disable alarm, set to [OFF].



Setting

Setting Range	Default
“ON” : / “OFF”	ON

**rUnA**

## Run all enable

Conditions of Use  
The “number of patterns” parameter must be set to a value greater than “1”.



Function

- To successively execute the program of all patterns from pattern 0, set to [ON].
- Patterns whose “pattern execution count” parameter (level 1 mode) is set to “0” are skipped.

Setting Range	Default
“ON” : / “OFF”	OFF

## Expansion Mode

**ALFA**  $\alpha$

### Conditions of Use

The control must be advanced PID control.



Function

- Normally, use the default value.
- Sets advanced PID-control parameter  $\alpha$ .



Setting

Setting Range	Unit	Default
0.00 to 1.00	None	0.65

**AL-C**

**AT calculated gain**

### Conditions of Use

The control must be advanced PID control.



Function

- Normally, use the default value.
- Sets the gain when adjusting the PID parameters by auto-tuning.
- To give priority to response, decrease the set value of this parameter. To give priority to stability, increase the set value of this parameter.



Setting

Setting Range	Unit	Default
0.1 to 10.0	None	1.0



See

- Related parameter
  - “AT Execute/Cancel” (level 1 mode)
  - “PID/ON/OFF” (expansion mode)



**RET**

## Automatic return of display mode



Function

- If you do not operate any of the controller keys for the time set in this parameter when in levels 0 to 2 and program modes, the display automatically returns to the PV/Present SP display.
- When this parameter is set to “0”, this function is disabled. (That is, the display does not automatically return to the PV/Present SP display.)
- This parameter is disabled while the menu display is displayed.



Setting

Setting Range	Unit	Default
0 to 99	Second	0

**AT-H**

## AT hysteresis

### Conditions of Use

The control must be advanced PID control.



Function

- Normally, use the factory setting.
- The levels of limit cycle operations during AT execution are given hysteresis at event ON/OFF switching. This parameter sets this hysteresis width.



Setting

Setting Range	Unit	Default
0.1 to 9.9	%FS	0.2

**LbAb**

## LBA detection width

### Conditions of Use

The LBA (Loop Break Alarm) function must be assigned as an output.



Function








- This parameter can be used when LBA is assigned as an output.
- When the change width of the manipulated variable is below the width set in this parameter, the controller regards this as detection of an LBA.












Setting

Setting Range	Unit	Default
0.0 to 999.9	%FS	0.2

## Option Mode

- The parameters in this mode can be used only when the “security” parameter (protect mode) is set to “0” and “1”.
- You can select this mode only on controllers that support optional functions. In this mode, you can set the communications conditions, transfer output and event input parameters to match the type of optional function supported on the controller.
- To select this mode, press the  key for 1 second minimum. The display changes to the menu display. If you select [Opt] using the  and  keys, and then press the  key for 1 second minimum, the controller enters the option mode.
- To select parameters in this mode, press the  key. To change parameter settings, use the  or  keys.
- The following table shows the parameters supported in this mode and the page where the parameter is described.

Symbol	Parameter Name	Page
	Event input assignment 1	5-45
	Communication stop bit	5-46
	Communication data length	5-46
	Communication parity	5-46
	Communication baud rate	5-46
	Communication unit No.	5-46
	Transfer output type	5-47
	Transfer output upper limit	5-47
	Transfer output lower limit	5-47

## E<sub>U</sub>-1

### Event input assignment 1

#### Conditions of Use

The event input function must be in use.



Function

- The following functions are assigned as event inputs:  
“Run/reset,” “Auto/manual,” “Hold/hold cancel,” “Advance,” “Pattern select 0 to 1”
- Weighting of the remote/local function is as follows:  
Pattern select 0 =  $2^0$ , Pattern select 1 =  $2^2$
- When event input is used as advance input, program steps are advanced at the rising edge (OFF→ON) of the event input signal. When event input is used as run/reset input, the program is reset at the rising edge (OFF→ON) of the event input signal, and the program runs at the falling edge (ON→OFF). Other signals are accepted as during regular operation.



Setting

Settings	Function
$\bar{n} \bar{o} n$	Event input disabled
$r \bar{s} t$	OFF→ON : Reset / ON→OFF : Run
$\bar{a} \bar{r} n$	ON : Manual / OFF : Auto
$H \bar{o} l d$	ON : Hold / OFF : Hold cancel
$\bar{A} d v$	OFF→ON Execution
$P \bar{t} n 0$	OFF: pattern 0 / ON: pattern 1 (*1)
$P \bar{t} n 1$	OFF: pattern 0 / ON: pattern 2 (*2)

\*1 Enabled when the “number of patterns” parameter is set to “2” or more

\*2 Enabled when the “number of patterns” parameter is set to “3” or more

- Default is “ $r \bar{s} t$ ”.



See

- Related description  
4.7 How to Use Event input (page 4-23)
- Related parameters  
“Remote/local” (level 2 mode)  
“Hold” “Advance” (level 0 mode)  
“Pattern No.” (level 0/program mode)




Model

- Option units  
E53-CKB


# Option Mode

<b>5bit</b>	Communication stop bit	<b>6PS</b>	Communication baud rate
<b>LEN</b>	Communication data length	<b>U-no</b>	Communication unit No.
<b>Prty</b>	Communication parity	Conditions of Use The communications function must be in use.	



Function

- These parameters are enabled when the power is turned ON again.
- These parameters set the communications conditions. Make sure that the stop bit, data length, parity and baud rate of the host computer and the E5CK-T controller are matching.
- When connecting two or more E5CK-T controllers to the host computer, set unit Nos. that will not conflict with the unit Nos. of other controllers.



Setting

- “Communication stop bit” parameter

Setting Range	Unit	Default
1, 2	Bits	2

- “Communication data length” parameter

Setting Range	Unit	Default
7, 8	Bits	7

- “Communication parity” parameter


Setting	Default
“non”: None/ “EEN”:Even/ “odd”:Odd	EEN

- “Communication baud rate” parameter

Setting Range	Unit	Default
1.2, 2.4, 4.8, 9.6, 19.2	kbps	9.6


- “Communication unit No.” parameter

Setting Range	Unit	Default
0 to 99	None	0



See

- Related description  
Chapter 6 Using the Communications Functions
- Related parameter  
“Remote/Local” (level 2 mode)



Model

- Option units  
E53-CK01/03

**tr-t**

**Transfer output type**

Conditions of Use

The transfer output function must be in use.

**tr-H**

**Transfer output upper limit**

**tr-L**

**Transfer output lower limit**



Function

- These parameters set the transfer output conditions.
- The “transfer output type” parameter selects one of the following data items as the transfer output type, and assigns this to transfer output:  
Present SP, Process value, Manipulated variable (heat), Manipulated variable (cool) (during heating and cooling control)
- The “transfer output upper limit” and “transfer output lower limit” parameters are used for scaling of transfer output. The setting range varies according to this output data. Also, a lower limit value larger than the upper limit value may be set.
- During temperature input, the decimal point position of the set point or process value is dependent on the currently selected sensor, and during analog input on the results of scaling.
- Set the scaling of the present SP or process value within the sensor input indication range.



Setting

Transfer Output Type	Transfer Output Lower Limit to Transfer Output Upper Limit
“ <b>SP</b> ” Present SP	-1999 to 9999
“ <b>PV</b> ” Process Value	-1999 to 9999
“ <b>Δ</b> ” Manipulated variable (heat)	-5.0% to 105.0% (standard control), 0.0 to 105.0% (heating and cooling control)
“ <b>Δ - Δ</b> ” Manipulated variable (cool)	0.0 to 105.0%

- Default : [**SP**].



See







- Related description  
4.9 How to Use Transfer Output (page 4-21)



Model

- Option units  
E53-CKF

## Calibration Mode

- The parameters in this mode can be used only when the “security” parameter (protect mode) is set to “0”. When selecting this mode for the first time after the E5AK-T has left the factory, return the “security” parameter to “0”.
- This mode contains the parameters for user calibration of inputs and outputs. Only parameters relating to input types specified in the “input type” parameter (setup mode) can be used. Also, related output parameters can be used only when the communications unit (E53-CKF) is added on.
- To select this mode, press the  key for 1 second minimum. The display changes to the menu display. If you select [ ] using the  and  keys, and then press the  key for 1 second minimum, the controller enters the calibration mode.
- For details on parameters in the calibration mode, see Chapter 7 Calibration.

# K CHAPTER 6

## USING THE COMMUNICATIONS FUNCTION

This chapter mainly describes communications with a host computer and communications commands.

6.1	Outline of the Communications Function .	6-2
	Outline .....	6-2
	Transfer procedure .....	6-2
	Interface .....	6-2
6.2	Preparing for Communications .....	6-3
	Cable connections .....	6-3
	Setting the communications specifications	6-4
6.3	Command Structure .....	6-5
6.4	Commands and Responses .....	6-7
	Reading/writing parameters .....	6-7
	Issuing special commands .....	6-10
	Reading/writing program parameters ....	6-12
6.5	How to Read Communications	
	Error Information .....	6-15
	End code .....	6-15
	Undefined error .....	6-16
6.6	Program Example .....	6-17
	How to use programs .....	6-17
	Program list .....	6-18
	Examples of use .....	6-19

## 6.1 Outline of the Communications Function

### ■ Outline

The communications function allows you to monitor and set E5CK-T parameters by a program prepared and running on a host computer connected to the E5CK-T controller. This chapter describes operations as viewed from the host computer.

When the communications function is used, the E53-CK01/03 communications unit must be added on.

The E5CK-T communications function allows you to carry out the following:

- Read/write parameters
- Instruct operations
- Select the setting level.


The communications function assumes the following conditions:

- Writing of parameters is possible only during remote operation. Also, parameters cannot be written during execution of auto-tuning.
- Writing of parameters is limited by setting level. Writing conditions are as follows depending on the setting level:
- Setting level 1: No restrictions
- Setting level 0: Writing of parameters in the setup, expansion and option modes only is prohibited.
- The “remote/local”, “AT execute/cancel”, “hold/hold cancel” and “advance” parameters are set aside from other parameters as special commands for instructing operations.

### ■ Transfer procedure

The host computer sends a “command frame” to the controller, and the controller returns a “response frame” corresponding to the content of the command sent by the host computer. In other words, a response frame is returned for each command frame sent.

The following diagram shows command frame/response frame operations.



### ■ Interface

The host computer carries out communications conforming to the RS-232C, RS-422 or RS-485 interface specifications.

Controllers supporting the RS-232C, and RS-485 specifications are as follows:

- Option units
  - E5-CK01: RS-232C
  - E5-CK03: RS-485




## 6.2 Preparing for Communications

For details on wiring when the communications function is used, see Chapter 2 Preparations.

### ■ Cable connections


#### ● RS-232C

- Only one controller can be connected to the host computer. (1:1 connection)
- The cable length should not exceed 15 meters.
- Use shielded twisted-pair cables (AWG28 or more) for the cables.



#### ● RS-485

- 1:1 or 1:N connections are allowed. In a 1:N connection, up to 32 controllers including the host computer can be connected.
- The total cable length should not exceed 500 meters.
- Use shielded twisted-pair cables (AWG28 or more) for the cables.
- Attach terminators to the controllers at both ends of the series of controllers connected in an open configuration. For example, in the following configuration, connect the terminator to unit No.30, and do not connect terminators to unit Nos.0 to 29.
- Use terminators having a resistance of 120  $\Omega$  (1/2 W). The total resistance of both ends should be at least 54  $\Omega$



## ■ Setting the communications specifications

Match the communications specifications of the host computer and E5CK-T controller. When two or more controllers are connected to the host computer, make sure that the communications specifications of all controllers are the same.

This section describes how to set the communications specifications for the E5CK-T controller. For details on the host computer, see the relevant manual supplied with the host computer.

## ● Communications parameters

Set the communications specifications of the E5CK-T in the controller's communications parameters. The communications parameters are set on the front panel of the E5CK-T controller.


The following table shows the communications parameters (option mode) provided on the E5CK-T controller and their respective settings.

Parameter/Symbol		Setting	Set Value
Unit No.	U-nō	0 to 99	<b>0</b> to 99
Baud rate	bPS	1.2/2.4/4.8/9.6/19.2 (kbps)	1.2/2.4/4.8/ <b>9.6</b> /19.2
Bit length	LEN	7/8 (bit)	<b>7</b> /8
Parity	PrtY	None/even/odd	nōnE / <b>Even</b> / odd
Stop bit	SbLē	1/2	1/ <b>2</b>

Inverted items are factory settings.

## 6.3 Command Structure

Command structure is as follows. Each command is paired with a response.



- “@”  
The start character. This character must be inserted before the leading byte.
- Unit No.  
Specifies the “unit No.” of the E5CK-T. If there are two or more transmission destinations, specify the desired destination using “unit No.”
- Command type

Code	Command type
1	Parameter read
2	Parameter write
3	Special command
4	Program parameter read
5	Program parameter write

- Command code  
Specifies the command for each command type. With parameter read/write commands and program parameter read/write commands, this becomes the parameter No.
- Data  
Specifies the set value or setting content. With the parameter read and program parameter read commands, set dummy data “0000”. In the response, this is inserted only when the end code is “00”.



### About invalid parameters

Currently, if a command is used for invalid parameters (parameters that do not satisfy the conditions of use in Chapter 5), the “undefined” error (end code: IC) response is returned.

- **End code**  
Sets the communication results. For details on the types and meanings of end codes, see 6.5 How to Read Communications Error Information (page 6-12).
- **FCS (Frame Check Sequence)**  
Set the frame check results from the start character to the data area. For details on the frame check, see 6.6 Program Example (page 6-18).
- **“\*” “CR (Carriage Return) code”**  
Indicates the end (terminator) of the command or response block.



#### How to Calculate FCS

Calculate the exclusive OR from the start character to the data section. The following describes an example of how to calculate the FCS for “@001000000”.

- (1) Convert the ASCII codes of each character to Hexadecimal “40H, 30H, ..., 30H”.
- (2) Calculate the exclusive OR of all characters.
- (3) Convert to ASCII code. (→ “4B”)
- (4) Set the result as FCS.

##### ● ASCII → Hex

ASCII	@	0	0	1	0	0	0	0	0	0
Hex	40H	30H	30H	31H	30H	30H	30H	30H	30H	30H

##### ● Exclusive OR

$$40H \oplus 30H \oplus 30H \oplus 31H \oplus 30H \oplus 30H \oplus 30H \oplus 30H \oplus 30H \oplus 30H = 71H$$

##### ● Conversion to ASCII code at each digit of the calculation result and setting to FCS

ASCII	@	0	0	1	0	0	0	0	0	0	7	1
Hex	40H	30H	30H	31H	30H	30H	30H	30H	30H	30H	37H	31H

FCS

##### ● Completed frame (with appended terminator)

ASCII	@	0	0	1	0	0	0	0	0	0	7	1	*	CR
Hex	40H	30H	30H	31H	30H	30H	30H	30H	30H	30H	37H	31H	2AH	0DH

FCS

Terminator


# 6.4 Commands and Responses

This section describes commands and response in detail. The conventions used in this section and data restrictions are as follows:


- Data is expressed in 1-byte units and in ASCII code.
  - When the read or write data is a numerical value, the data to be set must conform to the following conditions:
    - (1) The decimal point “.” is not indicated in fractions.
    - (2) The leftmost bit of minus numerical data must be expressed as follows:  
A: -1, F: - (minus)
- [example]  
10.0=[0100], -150.0=[A500], -15=[F015]

## ■ Reading/writing parameters

### ● Reading parameters



### ● Writing parameters



Parameters of a specified controller are read or written.

- Writing is possible only during remote operation.
- Reading is impossible during execution of auto-tuning.
- The following are set aside as special commands. For details, see page 6-10.
- “AT execute/cancel”, “Hold/Hold cancel” and “Advance”
- For details on parameters in each setting level, see the tables on page 6-8 and 6-9.

Parameter No.	Parameter	Data Setting and Monitor Range	Mode
00	PV monitor *1 *2	Scaling lower limit -10% to scaling upper limit +10%	Level 0
01	Set point *1	Set point lower limit to set point upper limit	
04	MV monitor (heat) *1	-5.0 to 105.0 *3	
14	Valve opening monitor *1	-10.0 to 110.0	Level 0
02	Alarm value 1	-1999 to 9999	Program
03	Alarm value 2	-1999 to 9999	
41	Alarm value 3	-1999 to 9999	
19	Proportional band	0.1 to 999.9	
20	Integral time	0 to 3999	Level 1
21	Derivative time	0 to 3999	
22	Cooling coefficient	0.01 to 99.99	
09	Dead band	-19.99 to 99.99	
23	Manual reset value	0.0 to 100.0	
06	Hysteresis (heat)	0.01 to 99.99	
43	Hysteresis (cool)	0.01 to 99.99	
07	Control period (heat)	1 to 99	
08	Control period (cool)	1 to 99	
46	LBA detection time	0 to 9999	Level 2
47	MV at reset *5	-5.0 to 105.0	
48	MV at PV error *5	-5.0 to 105.0	
50	MV upper limit *3	MV lower limit +0.1 to 105.0	
49	MV lower limit *4	-5.0 to MV upper limit -0.1	
51	MV change rate limit	0.0 to 100.0	
56	Input digital filter	0 to 9999	
25	Alarm 1 hysteresis	0.01 to 99.99	
26	Alarm 2 hysteresis	0.01 to 99.99	
52	Alarm 3 hysteresis	0.01 to 99.99	
53	Input shift upper limit	-199.9 to 999.9	
54	Input shift lower limit	-199.9 to 999.9	

\*1 Possible only during reading

\*2 During temperature input, the range becomes the range of use of the selected sensor.

\*3 During heating and cooling control, the range becomes 0.0 to 105.0.

\*4 During heating and cooling control, the range becomes -105.0 to 0.0.

\*5 During heating and cooling control, the range becomes -105.0 to 105.0.

Parameter No.	Parameter	Data Setting Range	Mode
57	Input type	0 to 21 *7	Set up
59	Scaling upper limit	Scaling lower limit +1 to 9999	
58	Scaling lower limit	-1999 to scaling upper limit -1	
60	Decimal point	0 to 3	
30	°C/°F selection	0: °C, 1: °F	
61	Control output 1 assignment	0 to 4, 6, 10 to 13 *8	
62	Control output 2 assignment	0 to 4, 6, 10 to 13 *8	
63	Auxiliary output 1 assignment	2 to 4, 6 to 8, 10 to 13 *8	
65	Alarm 1 type	1 to 11 *9	
66	Alarm 1 open in alarm	0: Closed in alarm, 1: Open in alarm	
67	Alarm 2 type	1 to 11 *9	
68	Alarm 2 open in alarm	0: Closed in alarm, 1: Open in alarm	
69	Alarm 3 type	1 to 11 *9	
70	Alarm 3 open in alarm	0: Closed in alarm, 1: Open in alarm	
71	Direct/Reverse operation	0: Reverse operation, 1: Direct operation	
28	Set point upper limit *1	Set point lower limit +1 to scaling upper limit	Expansion
27	Set point lower limit *1	Scaling lower limit to Set point upper limit -1	
72	PID / ON/OFF	0: Advanced PID, 1: ON/OFF	
35	$\alpha$	0.00 to 1.00	
85	AT calculated gain	0.1 to 10.0	
36	Automatic return of display mode	0 to 99	
93	AT hysteresis	0.1 to 9.9	
55	LBA detection width	0.0 to 999.9	


\*7 See page 5-29.

\*8 0: Control output (heat), 1: Control output (cool), 2 to 4: Alarms 1 to 3, 6: LBA, 7 and 8: Errors 1 to 2, 10 to 11: Time signal 1 to 2, 12: Program end, 13: Stage output

\*9 See page 5-34.

\*10 During temperature input, the range becomes the range of use of the selected sensor instead of the scaling upper/lower limit values.

## ■ Issuing special commands



The following functions are issued as special commands.

- **Run/Reset**  
Runs or stops programs. This command cannot be issued in setting level 1.
- **AT Execute/Cancel**  
Executes or cancels auto-tuning. This command cannot be issued in setting level 1.
- **Move to setting level 1**  
Issue this command when writing parameters in the setup, expansion and option modes. On the E5CK-T, the parameter switches to the top parameter “ $\bar{\iota}\eta\text{-}\bar{\iota}$  : input type” of the setup mode, and control is stopped.
- **Software reset**  
Resets E5CK-T operation (same as turning power ON) by communications. A response is not returned to this command. Also, communications with the E5CK-T cannot be carried out for five seconds after reset.
- **Status**  
Monitors the status of the E5CK-T. Two command groups are available, A and B, depending on the instruction code. The response is returned in bit units to the instruction code (4B) of the response frame. For details on the monitoring details of each group, see page 6-11.
- **Hold**  
Holds program execution or cancels hold. This command cannot be issued in setting level 1.
- **Advance**  
Advances execution of steps in the program. This command cannot be issued in setting level 1.

00	Run/Reset	0000: Run, 0001: Reset
02	Remote/Local	0000: Local, 0001: Remote
07	AT Execute/Cancel	0000: Cancel, 0001: 40% AT execution, 0002: 100% AT execution
09	Move to setting level 1	0000
11	Software reset	0000
14	Status	0000: A group, 0001: B group
15	Hold	0000: Hold cancel, 0001: Hold
16	Advance	0000

In the case of the “Run/Reset” or “Advance” command, issue command when the response of the previous command was returned and passed for 0.5 seconds.



### ● A group

Bit	Description	[1]	[0]
0	Heating side output	ON	OFF *1
1	Cooling side output	ON	OFF
2	Alarm output 1	ON	OFF *2
3	Alarm output 2	ON	OFF *2
4	Alarm output 3	ON	OFF *2
5	LBA output	ON	OFF *2
6			
7	Run/Reset	Reset	Run
8	Auto/Manual	Manual	Auto
9	Remote/Local	Remote	Local
10			
11	AT	AT execution	OFF
12	Hold	During hold	OFF
13			
14			
15			

### ● B group

Bit	Description	[1]	[0]
0	Setting level	1	0
1			
2	Control output 1 type	Linear	Pulse
3			
4			
5	Input error	ON	OFF
6	A/D converter error	ON	OFF
7			
8			
9			
10			
11	Time signal 1 output	ON	OFF *2
12	Time signal 2 output	ON	OFF *2
13	Ramp/soak	Ramp	Soak
14	Program end	ON	OFF *4
15	During standby	ON	OFF

\*1 Always “OFF” at linear output

\*2 Always “OFF” when output is not assigned

\*3 When the ON time during control output is less than 190 ms, the heater current to which “1” is set and the previous current value is held.


\*4 “ON” while the No.2 display indicates [P E n d]. For details on the [P E n d] indication, see page 4-15.

#### About Setting Levels


To return to setting level 0 from setting level 1, issue the “software reset” command. If the parameter write command is issued for the setup, expansion and option modes in setting level 0, an error occurs, and the end code (0D = Command cannot be executed) is returned.

## ■ Reading/writing program parameters

### ● Reading parameters



### ● Writing parameters



Parameters relating to the program of the specified unit are read or written.

- Writing is possible only during remote operation.
- Reading is impossible during execution of auto-tuning.
- For details on parameters in each setting level, see the lists for each setting level on pages 6-13 to 6-14.

Parameter No.	Parameter	Data Setting and Monitor Range	Mode
00	Pattern No. *2	0 to number of patterns -1	*2
01	Step No. monitor *1	0 to number of steps -1	Level 0
63	Standby time monitor *1	0.00 to 99.59	
02	Pattern elapsing time monitor *1	0.00 to 99.59	
03	Pattern execution count monitor *1	0 to 9999	
60	Number of steps	1 to 16	
05	Step 0 SP/Target SP 0	SP lower limit to SP upper limit	Program
06	Ramp rate 0	0 to 9999	
07	Step 0 time/Soak time 0	0.00 to 99.59	
08	Step 1 SP/Target SP 1	SP lower limit to SP upper limit	
09	Ramp rate 1	0 to 9999	
10	Step 1 time/Soak time 1	0.00 to 99.59	
11	Step 2 SP/Target SP 2	SP lower limit to SP upper limit	
12	Ramp rate 2	0 to 9999	
13	Step 2 time/Soak time 2	0.00 to 99.59	
14	Step 3 SP/Target SP 3	SP lower limit to SP upper limit	
15	Ramp rate 3	0 to 9999	
16	Step 3 time/Soak time 3	0.00 to 99.59	
17	Step 4 SP/Target SP 4	SP lower limit to SP upper limit	
18	Ramp rate 4	0 to 9999	
19	Step 4 time/Soak time 4	0.00 to 99.59	
20	Step 5 SP/Target SP 5	SP lower limit to SP upper limit	
21	Ramp rate 5	0 to 9999	
22	Step 5 time/Soak time 5	0.00 to 99.59	
23	Step 6 SP/Target SP 6	SP lower limit to SP upper limit	
24	Ramp rate 6	0 to 9999	
25	Step 6 time/Soak time 6	0.00 to 99.59	
26	Step 7 SP/Target SP 7	SP lower limit to SP upper limit	
27	Ramp rate 7	0 to 9999	
28	Step 7 time/Soak time 7	0.00 to 99.59	
29	Step 8 SP	SP lower limit to SP upper limit	
30	Step 8 time	0.00 to 99.59	
31	Step 9 SP	SP lower limit to SP upper limit	
32	Step 9 time	0.00 to 99.59	
33	Step 10 SP	SP lower limit to SP upper limit	
34	Step 10 time	0.00 to 99.59	
35	Step 11 SP	SP lower limit to SP upper limit	
36	Step 11 time	0.00 to 99.59	
37	Step 12 SP	SP lower limit to SP upper limit	
38	Step 12 time	0.00 to 99.59	
39	Step 13 SP	SP lower limit to SP upper limit	
40	Step 13 time	0.00 to 99.59	

\*1 Reading only is possible.

\*2 Can be used in either the level 0 or program modes.  
Read only during program run

Parameter No.	Parameter	Data Setting and Monitor Range	Mode
41	Step 14 SP	SP lower limit to SP upper limit	Program
42	Step 14 time	0.00 to 99.59	
43	Step 15 SP	SP lower limit to SP upper limit	
44	Step 15 time	0.00 to 99.59	
04	Pattern execution count	0 to 9999	
45	Time signal 1 enabled step	0 to 15	
46	Time signal 1 ON time	0.00 to 99.59	
47	Time signal 1 OFF time	0.00 to 99.59	
48	Time signal 2 enabled step	0 to 15	
49	Time signal 2 ON time	0.00 to 99.59	
50	Time signal 2 OFF time	0.00 to 99.59	
62	Standby time	0.00 to 99.59	Level 2
54	Operation at power ON	*3	Expansion
55	End condition	0: Reset, 1: Final step SP	
61	Number of patterns	1 to 4	
51	Program time unit	0: Hour, minute, 1: Minute, second	
56	Step time/Rate of rise programming	0: Step time, 1: Rate of rise programming	
57	Time unit of ramp rate	0: Minute, 1: Hour	
58	PV start	0: SP start, 1: PV start	
52	Alarm during ramp step enable	0: OFF, 1: ON	
53	Run all enable	0: OFF, 1: ON	


\*3 0: Continue, 1: Reset, 2: Run, 3: Manual

## 6.5 How to Read Communications Error Information

The result of communications on the E5CK-T can be checked by the end code or undefined error response in the response frame. Use this end code or undefined error response to remedy errors that may occur.

### ■ End code

Communications are normal when the end code in the response is “00”. If the end code is not “00”, this indicates that an error that is not an undefined error has occurred. The end code format is as follows and does not contain a data area.



End code	0D	Code name	Command cannot be executed
----------	----	-----------	----------------------------

#### ● Description

- Writing was carried out during local operation.
- Writing was carried out during execution of auto-tuning.
- An attempt was made to execute 40%AT during heating and cooling control.
- An attempt was made to switch run/reset in setting level 1.
- An attempt was made to execute AT in setting level 1.

#### ● Action

- Issue the parameter read or write commands in conditions other than above.

End code	10	Code name	Parity error
----------	----	-----------	--------------

#### ● Description

Parity check error was detected in the received data.

#### ● Action

Check the communications conditions. If the communications conditions of the host computer and E5CK-T controller match, then a probable cause is a problem in the communications circuit of one or both of the host computer and E5CK-T controller.

End code	11	Code name	Framing error
----------	----	-----------	---------------

#### ● Description

Stop bit cannot be detected.

#### ● Action

Check the communications conditions. If the communications conditions of the host computer and E5CK-T controller match, then a probable cause is a problem in the communications circuit of one or both of the host computer and E5CK-T controller.



About the Unit No.

Responses are not returned unless the target unit for communications and the unit No. defined in the command match.

End code	13	Code name	FCS error
----------	----	-----------	-----------

● **Description** The FCS (Frame Check Sequence) do not match.

● **Action** Check the FCS program.

End code	14	Code name	Format error
----------	----	-----------	--------------

● **Description** The received command length does not match the length defined in the frame format.


● **Action** Check the communications conditions. If the communications conditions of the host computer and E5CK-T controller match, then a probable cause is a problem in the communications circuit of one or both of the host computer and E5CK-T controller.

End code	15	Code name	Setting range error
----------	----	-----------	---------------------

● **Description** Numerical values or code values in the data are not within the setting range.

● **Action** Check the parameter and read or write data of special commands.

## ■ Undefined error



● **Description**

- An undefined header code has been received.
- A currently invalid parameter (e.g. the scaling command during temperature input) has been received.

● **Action**


- Check the parameter No.

## 6.6 Program Example


### ■ How to use programs

The program described below obtains corresponding response frame data when some of the command frame data is input.

The input format is as follows. The FCS and terminator are automatically generated, and need not be input.



The output format is as follows. The content of the response frame is displayed as it is.



### ● Procedure

- (1) Read the program.
- (2) Enter "RUN".
- (3) When "send data:" is displayed, enter the command data (from @ to the command string).
- (4) The content of the response frame is displayed following "receive data:".

### ● Conditions when running a program

- Set the communications conditions as follows:
  - Baud rate : 9600 bps
  - Bit length : 7 bits
  - Parity : Even
  - Stop bit : 2
- Make sure that the communications cable is properly connected.

## ■ Program list (language: IBM PC Compatible Machine)

```

1000 ' -----
1010 ' PROGRAM : E5CK-T COMMUNICATION PROGRAM
1020 ' ----- FOR IBM PC COMPATBLE MACHINE
1050 ' -----
1060 ' ----- Default RS-232C SPEED: 9600BPS, PARITY: EVEN, DATA: 7, STOP: 2 ---
1070 OPEN "COM: E73" AS #1
1080 *REPEAT
1090 ' ----- Enter send data -----
1100 INPUT "send data : " , SEND$
1110' ----- FCS calculation -----
1120 FCS=0
1130 FOR IFCS=1 TO LEN (SEND$)
1140 FCS=FCS XOR ASC (MID$ (SEND$, IFCS, 1))
1150 NEXT
1160 FCS$=RIGHT$ ("0"+HEX$ (FCS), 2)
1170 ' ----- Execute communications -----
1180 ZZZ$=SEND$+FCS$+"*" +CHR$ (13)
1190 PRINT #1, ZZZ$;
1120' ----- Check response -----
1210 RECCNT=0: TMP$=""
1220 *DRECLOOP:
1230 IF LOC (1) < > 0 THEN DREC1
1240 RECCNT=RECCNT+1
1250 IF RECCNT=5000 THEN *DRECERR ELSE DRECLOOP
1260 *DREC1
1270 TMP$=TMP$+INPUT$ (LOC (1), #1)
1280 IF RIGHT$ (TMP$, 1)=CHR$ (13) THEN *DRECEND
      ELSE RECCNT=0: GOTO *DRECLOOP
1290 *DRECERR
1300 TMP$="No response !!" +CHR$ (13)
1310 *DRECEND
1320 RECV$=TMP$
1330 PRINT "receive data : " ; RECV$
1340 ' ----- Repeat to make Command -----
1350' GOTO *REPEAT
1360 ' ----- END -----
1370 CLOSE #1
1380 END

```




## ■ Examples of use


- Set the unit No. to “00”.
- In the following examples, data is shown in individual blocks to make the examples easier to understand. However, when actually creating programs, do not leave spaces between frame items. Also, response are displayed without spaces between frame items.

### ● Set the set point to “300.0”

- Input data




- Response




### ● Start running

- Input data




- Response




### ● Monitor process value

- Input data



- Response





# *K* CHAPTER 7


## *CALIBRATION*

This chapter describes procedures for each calibration operation.  
Read this chapter only when the controller must be calibrated.

7.1	Parameter Structure .....	7-2
7.2	Calibrating Thermocouples .....	7-4
7.3	Calibrating Platinum Resistance Thermometers .....	7-7
7.4	Calibrating Current Input .....	7-9
7.5	Calibrating Voltage Input .....	7-10
7.6	Checking Indication Accuracy .....	7-12

## 7.1 Parameter Structure

- To calibrate the E5CK-T controller, select [ **Cal** ] in the menu display to select the calibration mode. [ **Ad** ] is displayed.
- However, note that [ **Cal** ] may not be displayed on the menu display when, for example, the user is calibrating the E5CK-T controller for the first time. If this happens, [ **Cal** ] is displayed by changing the “security” parameter (protect mode) to “0”.
- The parameters in the calibration mode are structure as follows:




- To select the desired parameter, press the **←** key. Parameters are displayed in the following order:  
Calibration of inputs → Calibration of transfer output → Storage of calibration data  
If the E5CK-T controller does not support the transfer output function, calibration of transfer output is automatically deleted from the calibration procedure as follows:  
Calibration of inputs → Storage of calibration data
- Only inputs that have been set in the “input type” parameter (setup mode) can be calibrated. To temporarily store data for each of the calibration parameters, press the **↵** key for 1 second.
- Transfer output can be calibrated only when the Communications unit (E53-CKF) is set in the controller. To adjust data items, press the **↵** or **↶** keys.
- The data store menu is displayed only when all calibration items have temporarily been stored.
- After calibrating input, you must always check indication accuracy. For details, see page 7-12.

### ● Calibration item menu



Calibration item  
parameter

Process value

- Parameters are displayed on the No.1 display, and the process value is displayed in Hexadecimal on the No.2 display.
- Normally, the process value changes by several digits. The process value flashes, for example, when a sensor error causes the process value to stray from the calibration target range.
- When the process value display is flashing, the process value is not stored as data even if the  key is pressed.

### ● Calibration store mark




Calibration store mark

- Once the E5CK-T controller has been calibrated by the user, [ Adj ] is displayed preceded by the “.” mark when the calibration mode is next selected.

## 7.2 Calibrating Thermocouples

- Calibrate according to the type of thermocouple, thermocouple 1 group (K1, J1, L1, E, N, W, PLII) and thermocouple 2 group (K2, K2, L2, R, S, B, T, U).
- When calibrating, do not cover the bottom of the controller. Also, do not touch the input terminals (Nos.6 and 7) or compensating conductor on the E5CK-T controller.

### ● Preparations




- Set the cold junction compensator designed for compensation of internal thermocouples to 0°C. However, make sure that internal thermocouples are disabled (tips are open).
- In the above figure, STV refers to a standard DC current/voltage source, and DMM refers to a precision digital multimeter. However, note that DMM is required only when the transfer output function is supported.
- Use the compensating conductor on the selected thermocouple. However, note that when thermocouple R, S, E, B, W and PLII is used, the cold junction compensator and the compensating conductor can be substituted with the cold junction compensator and the compensating conductor for thermocouple K.




### Connecting the Cold Junction Compensator

Correct process values cannot be obtained if you touch the contact ends of the compensating conductor during calibration of a thermocouple. Accordingly, short (enable) or open (disable) the tip of the thermocouple inside the cold junction compensator as shown in the figure below to create a contact or non-contact state for the cold junction compensator.




### ● Calibration: thermocouple 1



This example describes how to calibrate a thermocouple when the transfer output function is supported. If the transfer output function is not supported, skips steps (7) to (10).

- (1) When [ Adj ] is displayed, the 30-minute timer is displayed on the No.2 display and counts down. This timer serves as a guide for the aging time when aging is required.
- (2) First, calibrate the main input. Press the key to display [ 1t 50 ] (50 mV calibration display). Set STV output to 50 mV. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (3) Press the key to display [ 1t 0 ] (0 mV calibration display). Set STV output to 0 mV. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (4) Next, calibrate the cold junction compensator. Press the key to display [ P3 10 ] (310 mV calibration display). Set STV output to 310 mV. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (5) Press the key to display [ P 0 ] (0 mV calibration display). Set STV output to 0 mV. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (6) Finally, calibrate the bias compensation value. Disconnect the STV, and enable the thermocouple of the cold junction compensator. When carrying this out, make sure that the wiring on the STV is disconnected. Make sure that the cold junction compensator is set to 0°C and press the key. The display changes to [ b 85 ] (calibration display for the bias compensation value). When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (7) Next, calibrate the transfer output function. If the transfer output function is not supported, skip to step (11). Press the key. The display changes to [ t r 20 ] (20 mA calibration display).
- (8) Set the output to 20 mA by the or keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is “20 mA”.
- (9) Press the key. The display changes to [ t r 4 ] (4 mA calibration display).
- (10) Set the output to 4 mA by the or keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is “4 mA”:
- (11) Press the key until the display changes to the date save display. Press the key. The No.2 display changes to [ 4E5 ], and two seconds later the calibration data is stored to internal memory. If you press the key when the No.2 display reads [ no ], the calibration data is disabled.
- (12) This completes calibration of the thermocouple 1 group. Press the key to return the display to [ Adj ].

### ● Calibration: thermocouple 2




This example describes how to calibrate a thermocouple when the transfer output function is supported. If the transfer output function is not supported, skips steps (7) to (10).

- (1) When [ **Ad 30** ] is displayed, the 30-minute timer is displayed on the No.2 display and counts down. This timer serves as a guide for the aging time when aging is required.
- (2) First, calibrate the main input. Press the key to display [ **2t 20** ] (20 mV calibration display). Set STV output to 20 mV. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (3) Press the key to display [ **2t 0** ] (0 mV calibration display). Set STV output to 0 mV. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (4) Next, calibrate the cold junction compensator. Press the key to display [ **43 10** ] (310 mV calibration display). Set STV output to 310 mV. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (5) Press the key to display [ **4 0** ] (0 mV calibration display). Set STV output to 0 mV. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (6) Finally, calibrate the bias compensation value. Disconnect the STV, and enable the thermocouple of the cold junction compensator. When carrying this out, make sure that the wiring on the STV is disconnected. Make sure that the cold junction compensator is set to 0°C and press the key. The display changes to [ **6.85** ] (calibration display for the bias compensation value). When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (7) Next, calibrate the transfer output function. If the transfer output function is not supported, skip to step (11). Press the key. The display changes to [ **t 20** ] (20 mA calibration display).
- (8) Set the output to 20 mA by the or keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is “20 mA”.
- (9) Press the key. The display changes to [ **t 4** ] (4 mA calibration display).
- (10) Set the output to 4 mA by the or keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is “4 mA”.
- (11) Press the key until the display changes to the data store display. Press the key. The No.2 display changes to [ **9E5** ], and two seconds later the calibration data is stored to internal memory. If you press the key when the No.2 display reads [ **no** ], the calibration data is disabled.
- (12) This completes calibration of the thermocouple 2 group. Press the key to return the display to [ **Ad 30** ].




## 7.3 Calibrating Platinum Resistance Thermometers

### ● Preparation



- Use leads of the same thickness when connecting to the platinum resistance thermometer.
- In the above figure, 6-dial refers to a precision resistance box, and DMM stands for a digital multimeter. However, note that the DMM is required only when the transfer output function is supported.
- Connect (short) the leads from terminal Nos.6 and 7.


### ● Calibration



Cont'd on next page


This example describes how to calibrate a platinum resistance thermometer when the transfer output function is supported. If the transfer output function is not supported, skips steps (7) to (10).

- (1) When [ **Rd** ] is displayed, the 30-minute timer is displayed on the No.2 display and counts down. This timer serves as a guide for the aging time when aging is required.
- (2) First, calibrate the main input. Press the **CAL** key to display [ **P300** ] (300Ω calibration display). Set the 6-dial to 300Ω when the value on the No.2 display has stabilized (changes of several digits max.), press the **ENTER** key to temporarily store the calibration data.
- (3) Press the **CAL** key to display [ **P 0** ] (0Ω calibration display). Short terminal Nos.6 to 8. When the value on the No.2 display has stabilized (changes of several digits max.), press the **ENTER** key to temporarily store the calibration data.
- (4) Next, calibrate the B-B' input. Change the wiring as follows:



Make the connection across terminal Nos.6 and 7 and the 6-dial as short as possible. Short terminal Nos.6 and 8.


From previous page




- (5) Press the key to display [Pb 10] (10Ω calibration display). Set the 6-dial to 10Ω. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (6) Press the key to display [Pb 0] (0Ω calibration display). Short terminal Nos.6 to 8. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (7) Next, calibrate the transfer output function. If the transfer output function is not supported, skip to step (11). Press the key. The display changes to [tr 20] (20 mA calibration display).
- (8) Set the output to 20 mA by the or keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is “20 mA”.
- (9) Press the key. The display changes to [tr 4] (4 mA calibration display).
- (10) Set the output to 4 mA by the or keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is “4 mA”.
- (11) Press the key until the display changes to the data store display. Press the key. The No.2 display changes to [ 4E5], and two seconds later the calibration data is stored to internal memory. If you press the key when the No.2 display reads [ 00], the calibration data is disabled.
- (12) This completes calibration of the platinum resistance thermometer. Press the key to return the display to [ Adj].

## 7.4 Calibrating Current Input

### ● Preparation



### ● Calibration




- In the above figure, STV refers to a standard DC current/voltage source, and DMM refers to a precision digital multimeter. However, note that the DMM is required only when the transfer output function is supported.

This example describes how to calibrate a platinum resistance thermometer when the transfer output function is supported. If the transfer output function is not supported, skips steps (4) to (7).

- (1) When [ **Rd** ] is displayed, the 30-minute timer is displayed on the No.2 display and counts down. This timer serves as a guide for the aging time when aging is required.
- (2) Press the **[ ]** key. The display changes to [ **R 20** ] (20 mA calibration display). Set the STV output to 20 mA. When the value on the No.2 display has stabilized (changes of several digits max.), press the **[ ]** key to temporarily store the calibration data.
- (3) Press the **[ ]** key. The display changes to [ **R 0** ] (0 mA calibration display). Set the STV output to 0 mA. When the value on the No.2 display has stabilized (changes of several digits max.), press the **[ ]** key to temporarily store the calibration data.
- (4) Next, calibrate the transfer output function. If the transfer output function is not supported, skip to step (8). Press the **[ ]** key. The display changes to [ **R 20** ] (20 mA calibration display).
- (5) Set the output to 20 mA by the **[ ]** or **[ ]** keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is "20 mA".
- (6) Press the **[ ]** key. The display changes to [ **R 4** ] (4 mA calibration display).
- (7) Set the output to 4 mA by the **[ ]** or **[ ]** keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is "4 mA".
- (8) Press the **[ ]** key until the display changes to the data store display. Press the **[ ]** key. The No.2 display changes to [ **YES** ], and two seconds later the calibration data is stored to internal memory. If you press the **[ ]** key when the No.2 display reads [ **no** ], the calibration data is disabled.
- (9) This completes calibration of the current input. Press the **[ ]** key to return the display to [ **Rd** ].


## 7.5 Calibrating Voltage Input

### ● Preparation



- In the above figure, STV refers to a standard DC current/voltage source, and DMM refers to a precision digital multimeter. However, note that the DMM is required only when the transfer output function is supported.

### ● Calibration: 0 to 5V, 1 to 5V




Cont'd on next page


This example describes how to calibrate a platinum resistance thermometer when the transfer output function is supported. If the transfer output function is not supported, skips steps (4) to (7).

- (1) When [Adj] is displayed, the 30-minute timer is displayed on the No.2 display and counts down. This timer serves as a guide for the aging time when aging is required.
- (2) Press the key. The display changes to [1.5] (5 V calibration display). Set the STV output to 5 V. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (3) Press the key. The display changes to [1.0] (0 V calibration display). Set the STV output to 0 V. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (4) Next, calibrate the transfer output function. If the transfer output function is not supported, skip to step (8). Press the key. The display changes to [1.0] (20 mA calibration display).
- (5) Set the output to 20 mA by the or keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is “20 mA”.
- (6) Press the key. The display changes to [1.0] (4 mA calibration display).
- (7) Set the output to 4 mA by the or keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is “4 mA”.

From previous page



### ● Calibration: 0 to 10V



- (8) Press the key until the display changes to the data store display. Press the key. The No.2 display changes to [ YES ], and two seconds later the calibration data is stored to internal memory. If you press the key when the No.2 display reads [ no ], the calibration data is disabled.
- (9) This completes calibration of the voltage input (0 to 5 V, 1 to 5 V). Press the key to return the display to [ Adj ].

This example describes how to calibrate a platinum resistance thermometer when the transfer output function is supported. If the transfer output function is not supported, skips steps (4) to (7).

- (1) When [ Adj ] is displayed, the 30-minute timer is displayed on the No.2 display and counts down. This timer serves as a guide for the aging time when aging is required.
- (2) Press the key. The display changes to [ 2u 10 ] (10 V calibration display). Set the STV output to 10 V. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (3) Press the key. The display changes to [ 2u 0 ] (0 V calibration display). Set the STV output to 0 V. When the value on the No.2 display has stabilized (changes of several digits max.), press the key to temporarily store the calibration data.
- (4) Next, calibrate the transfer output function. If the transfer output function is not supported, skip to step (8). Press the key. The display changes to [ tr 20 ] (20 mA calibration display).
- (5) Set the output to 20 mA by the or keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is “20 mA”.
- (6) Press the key. The display changes to [ tr 4 ] (4 mA calibration display).
- (7) Set the output to 4 mA by the or keys while monitoring the voltage on the digital multimeter. In the example on the left, the display indicates that the value two digits smaller than before calibration is “4 mA”.
- (8) Press the key until the display changes to the data store display. Press the key. The No.2 display changes to [ YES ], and two seconds later the calibration data is stored to internal memory. If you press the key when the No.2 display reads [ no ], the calibration data is disabled.
- (9) This completes calibration of the voltage input (0 to 10 V). Press the key to return the display to [ Adj ].

## 7.6 Checking Indication Accuracy


### ■ Checking indication accuracy

- After calibrating input, be sure to check indication accuracy to make sure that the E5CK-T controller has been correctly calibrated.
- Operate the E5CK-T controller in the PV/SP monitor (level 0 mode) mode.
- Check the indication accuracy at the upper and lower limits and mid-point.

#### ● Thermocouple

- Preparation

The following figure shows the required device connection. Make sure that the E5CK-T controller and cold junction compensator are connected by a compensating conductor for the input type (thermocouple) that is to be used during actual operation.




- Operation

Make sure that the cold junction compensator is at 0°C, and set STV output to the voltage equivalent to the starting power of the check value.

#### ● Platinum resistance thermometer

- Preparation

The following figure shows the required device connection.




- Operation

Set the 6-dial to the resistance equivalent to the check value.

## ● Current input or Voltage input

### • Preparation

The following figure shows the required device connection.



### • Operation

Set the STV to the current value equivalent to the check value or set the STV to the voltage value equivalent to the check value.





# *K* CHAPTER 8

## *TROUBLESHOOTING*

This chapter describes how to find out and remedy the cause if the E5CK-T does not function properly.

Remedy E5CK-T trouble in the order of the descriptions in this chapter

8.1	Initial Checks .....	8-2
8.2	How to Use the Error Display .....	8-3
8.3	How to Use the Error Output .....	8-5
8.4	Checking Operation Restrictions .....	8-6

## 8.1 Initial Checks

If trouble occurs, first of all check the following:

(1) Power supply

Make sure that the power supply is ON. Also, make sure that the power supply is within the rated voltage range.

(2) Input type jumper

Make sure that the input type jumper is set to the correct input type. The table below describes the operations when the jumper is not set matched to the type of sensor connected to the input terminal.

Jumper Setting	Parameter	Operation
TC/PT	Current (0 to 20 mA)	Operation is fixed at scaling lower limit value.
	Current (4 to 20 mA)	Err
	Voltage (0 to 10 V, 0 to 5 V)	Operation is fixed at scaling lower limit value.
	Voltage (1 to 5 V)	Err
I	Temperature input	Err
	Voltage (0 to 10 V, 0 to 5 V)	Operation is fixed at scaling lower limit value.
	Voltage (1 to 5 V)	Err
V	Temperature input	Err
	Current (0 to 20 mA)	Operation is fixed at scaling lower limit value.
	Current (4 to 20 mA)	Err

(3) Wiring

Make sure that all cables are properly connected.

(4) Communications conditions

When communicating via the RS-232C, RS-422 or RS-485 interfaces, make sure that the baud rate and other communications condition settings on the host computer and E5AK-T controller are matching, and are within the permissible ranges.

If there appears to be nothing wrong after checking the E5CK-T controller, and the same phenomenon continues, check the controller in more detail, for example, on the error display.



### About Errors That Occur During Motor Calibration

If an error occurs during motor calibration, “Err” is displayed on the No.2 display. The following causes of errors are possible:

- Control motor or potentiometer malfunction
- Incorrect control motor or potentiometer wiring
- Potentiometer is not connected

## 8.2 How to Use the Error Display


When an error has occurred, the No.1 display alternately indicates error codes together with the current display item.

This section describes how to check error codes on the display, and the actions you must take to remedy the problem.



### Input error

- **Meaning** Input is in error.
- **Action** Check the wiring of inputs, disconnections, and shorts, and check the input type.
- **Operation at error** For control output functions, the manipulated variable matched to the setting of the “MV at PV error” parameter (level 2 mode) is output. Alarm output functions are activated as if the upper limit is exceeded. Program operation is continued.



### Memory error

- **Meaning** Internal memory operation is in error.
- **Action** First, turn the power OFF then back ON again. If the display remains the same, the E5CK-T controller must be repaired. If the display is restored to normal, then a probable cause can be external noise affecting the control system. Check for external noise.
- **Operation at error** Control output functions turn OFF (2 mA max. at 4 to 20 mA output, and output equivalent to 0% in case of other outputs). Alarm output functions turn OFF.



### A/D converter error

- **Meaning** Internal circuits are in error.
- **Action** First, turn the power OFF then back ON again. If the display remains the same, the E5CK-T controller must be repaired. If the display is restored to normal, then a probable cause can be external noise affecting the control system. Check for external noise.
- **Operation at error** Control output functions turn OFF (2 mA max. at 4 to 20 mA output, and output equivalent to 0% in case of other outputs). Alarm output functions turn OFF. Program operation is stopped.

**Calibration data error**

This error is output only during temperature input, and is displayed for two seconds when the power is turned ON.

- **Meaning** Calibration data is in error.
- **Action** E5CK-T must be repaired.
- **Operation at error** Both control output functions and alarm output functions operate. However, note that readout accuracy is not assured.

**Display range over**

- **Meaning** Though not an error, this is displayed when the process value exceeds the display range when the control range (setting range  $\pm 10\%$ ) is larger than the display range (-1999 to 9999).
  - When less than “-1999” [c c c c]
  - When greater than “9999” [ㄗ ㄗ ㄗ ㄗ]
- **Operation** Control continues, allowing normal operation.

**About Errors That Occur During Motor Calibration**

If an error occurs during motor calibration, [ E r r ] is displayed on the No.2 display. The following causes of errors are possible:

- Control motor or potentiometer malfunction
- Incorrect control motor or potentiometer wiring
- Potentiometer is not connected

## 8.3 How to Use the Error Output

The E5CK-T controller allows you to assign error output to terminals as outputs.

For details on output assignments, see 3.3 Setting Output Specifications (page 3-7).

### ● LBA

- LBA (Loop Break Alarm) can be used as a means for detecting loop breaks when the control loop is not functioning normally. For details, see 4.8 LBA (page 4-16).
- LBA allows you to detect the following errors:
  - (1) Output error (contact weld, damaged transistors, etc.)
  - (2) Sensor error (constant input values, etc.)
- If you use the LBA function, set the loop break detection time matched to the control characteristics in the “LBA detection time” parameter (level 2 mode).

### ● Input errors

- If you assign error 1 as the output, an error can be output to auxiliary output 1 when input is in error. When this error occurs, remedy by following the description for “Input error”.

### ● A/D converter error

- If you assign error 2 as the output, an error can be output to auxiliary output 1 when the A/D converter is in error. When this error occurs, remedy by following the description for “A/D converter error”.

## 8.4 Checking Operation Restrictions

With the E5CK-T controller, auto-tuning or self-tuning sometimes do not operate depending on how functions are combined. The table below summarizes the main operating restrictions.

If the E5CK-T controller is not operating properly, first check whether operating conditions violate the restrictions in this table.

Restriction	Inoperable or Invalid Functions		
	AT Execution	Limiter Function	Other
At heating and cooling control	40%AT		
At ON/OFF control	×	Manipulated variable MV change rate	
At AT execution	/	MV change rate	Parameter setting
At reset		×	Manipulated variable MV change rate

Items marked by a “x” indicate combinations of conditions that are not acceptable during AT execution.

# *K* APPENDIX

SPECIFICATIONS .....	A-2
CONTROL BLOCK DIAGRAM .....	A-5
SETTING LIST .....	A-6
MODEL LIST .....	A-10
PARAMETER OPERATIONS LIST .....	A-11
ASCII CODE LIST .....	A-13



**OMRON Corporation**  
**Industrial Automation Company**

**Control Devices Division H.Q.**  
**Analog Controller Division**  
Shiokoji Horikawa, Shimogyo-ku,  
Kyoto, 600-8530 Japan  
Tel: (81)75-344-7080/Fax: (81)75-344-7189

***Regional Headquarters***

**OMRON EUROPE B.V.**  
Wegalaan 67-69, NL-2132 JD Hoofddorp  
The Netherlands  
Tel: (31)2356-81-300/Fax: (31)2356-81-388

**OMRON ELECTRONICS LLC**  
1 East Commerce Drive, Schaumburg, IL 60173  
U.S.A.  
Tel: (1)847-843-7900/Fax: (1)847-843-8568

**OMRON ASIA PACIFIC PTE. LTD.**  
83 Clemenceau Avenue,  
#11-01, UE Square,  
239920 Singapore  
Tel: (65)6835-3011/Fax: (65)6835-2711

**OMRON (CHINA) CO., LTD.**  
Room 2211, Bank of China Tower,  
200 Yin Cheng Road (M)  
Shanghai, 200120 China  
Tel: (86)21-5037-2222/Fax: (86)21-5037-2200

Authorized Distributor:



# SPECIFICATIONS

## ■ Ratings

Supply voltage	100 to 240V AC, 50/60 Hz	24 VAC/DC, 50/60 Hz
Operating Voltage Range	85% to 110% of rated supply voltage	
Power Consumption	15VA	6 VA, 3.5 W
Sensor Input	Thermocouple: K, J, T, E, L, U, N, R, S, B, W, PLII *1, *2 Platinum resistance thermometer: JPt100, Pt100 Voltage input: 4 to 20 mA, 0 to 20 mA (input impedance 150Ω) Current input: 1 to 5 V, 0 to 5 V, 0 to 10 V (input impedance 1MΩ)	
Control Output	According to output unit (see “Output Unit Ratings and Characteristics” (page A-4)	
Auxiliary Output	SPST-NO, 3 A at 250 VAC (resistive load)	
Control Method	Advanced PID or ON/OFF control	
Setting Method	Digital setting using front panel keys.	
Indication Method	7-segment digital display and LEDs	
Other Functions	According to option unit (see “Option Unit Ratings and Characteristics” (page A-4)	
Ambient Temperature	-10°C to 55°C (without condensation and icing)/3-year warranty period: -10 to 50°C	
Ambient Humidity	35% to 85% (relative humidity)	
Storage Temperature	-25°C to 65°C (without condensation and icing)	

\*1 Thermocouple W is W/Re5-26.

\*2 For the setting ranges and indication ranges for each of inputs, see page A-4.

## ■ Characteristics

Indication Accuracy	Thermometer: ( $\pm 0.3\%$ of indication value or $\pm 1^\circ\text{C}$ , whichever greater) $\pm 1$ digit max. (*1) Platinum resistance thermometer: ( $\pm 0.2\%$ of indication value or $\pm 0.8^\circ\text{C}$ whichever greater) $\pm 1$ digit max. Analog input: $\pm 0.2\%\text{FS} \pm 1$ digit max.	
Temperature variation influence (*2)	Platinum resistance thermometer: ( $\pm 1\%$ of PV or $\pm 2^\circ\text{C}$ , whichever greater) $\pm 1$ digit max. Thermocouple (R, S, B, W): ( $\pm 1\%$ of PV or $\pm 10^\circ\text{C}$ , whichever greater) $\pm 1$ digit max. Other thermocouples (K1, K2, J1, J2, E, N, T, L1, L2, U, PLII): ( $\pm 1\%$ of PV or $\pm 4^\circ\text{C}$ , whichever greater) $\pm 1$ digit max. Analog input (current, voltage, or remote SP input): $\pm 1\%\text{FS} \pm 1$ digit max.	
Voltage variation influence (*2)		
Hysteresis	0.01 to 99.99%FS (in units of 0.1%FS)	
Proportional Band (P)	0.1 to 999.9%FS (in units of 0.1%FS)	
Integral Time (I)	0 to 3999s (in units of 1 second)	
Derivative Time (D)	0 to 3999s (in units of 1 second)	
Control Period	1 to 99s (in units of 1 second)	
Manual Reset Value	0.0 to 100.0% (in units of 0.1%)	
Alarm Setting Range	-1999 to 9999 (decimal point position dependent on input type)	
Sampling Period	Temperature input: 250 ms, Analog input: 100 ms.	
Program Method	Set time or rate of rise programming	
Program Size	Max. 4 patterns, Max. 16 steps/pattern	
Program Time Accuracy	$\pm 0.2\%$ $\pm 500$ ms of set value (even-numbered steps in the "rate of rise programming" setting are set to the time unit of ramp rate)	
Insulation Resistance	20 M $\Omega$ min. (at 500 VDC)	
Dielectric Strength	2000 VAC, 50/60 Hz for 1 min. (between electrically live terminals of different polarities)	
Vibration Resistance	Malfunction	10 to 55 Hz, 10m/s <sup>2</sup> {approx. 1G} for 10 min. each in X, Y, and Z directions
	Destruction	10 to 55 Hz, 10m/s <sup>2</sup> {approx. 2G} for 2 hrs. each in X, Y, and Z directions
Shock Resistance	Malfunction	200 m/s <sup>2</sup> min. {approx. 20G}, 3 times each in 6 directions (100 m/s <sup>2</sup> {approx. 10G} applied to the relay)
	Destruction	300 m/s <sup>2</sup> min. {approx. 30G}, 3 times each in 6 directions
Weight	Approx. 170 g, adapter: approx. 10 g	
Enclosure Ratings	Front panel: NEMA4 for indoor use (equivalent to IP66) Fear case: IP20 Terminals: IP00	
Memory Protection	Non-volatile memory (number of writes: 100,000) (*3)	

\*1 The indication accuracy of the K1, T and N thermocouples at a temperature of  $-100^\circ\text{C}$  or less is  $\pm 2^\circ\text{C} \pm 1$  digit maximum. The indication accuracy of the U, L1 and L2 thermocouples at any temperature is  $\pm 2^\circ\text{C} \pm 1$  digit maximum.  
 The indication accuracy of the B thermocouple at a temperature of  $400^\circ\text{C}$  or less is unrestricted.  
 The indication accuracy of the R and S thermocouples at a temperature of  $200^\circ\text{C}$  or less is  $\pm 3^\circ\text{C} \pm 1$  digit maximum.  
 The indication accuracy of the W thermocouple  $\pm 1$  digit max. of whichever is the greater of  $\pm 0.3\%$  or  $\pm 3^\circ\text{C}$  of the indicated value.  
 The indication accuracy of the PLII thermocouple is  $\pm 1$  digit max. of whichever is the greater of  $\pm 0.3\%$  or  $\pm 2^\circ\text{C}$  of the indicated value.

\*2 Ambient temperature:  $-10^\circ\text{C}$  to  $23^\circ\text{C}$  to  $55^\circ\text{C}$   
 Voltage range:  $-15$  to  $+10\%$  of rated voltage

\*3 Write operations: Parameter changes, remote/local selection, etc.

## ■ Sensor Input Setting Ranges and Indication Ranges

Input	Setting Range	Indication Range
JPt100	-199.9 to 650.0 (C°) / -199.9 to 999.9 (F°)	-199.9 to 735.0 (C°) / -199.9 to 999.9 (F°)
Pt100	-199.9 to 650.0 (C°) / -199.9 to 999.9 (F°)	-199.9 to 735.0 (C°) / -199.9 to 999.9 (F°)
K1	-200 to 1300 (C°) / -300 to 2300 (F°)	-350 to 1450 (C°) / -560 to 2560 (F°)
K2	-0.0 to 500.0 (C°) / -0.0 to 900.0 (F°)	-50.0 to 550.0 (C°) / -90.0 to 990.0 (F°)
J1	-100 to 850 (C°) / -100 to 1500 (F°)	-195 to 945 (C°) / -260 to 1660 (F°)
J2	-0.0 to 400.0 (C°) / -0.0 to 750.0 (F°)	-40.0 to 440.0 (C°) / -75.0 to 825.0 (F°)
T	-199.9 to 400.0 (C°) / -199.9 to 700.0 (F°)	-199.9 to 460.0 (C°) / -199.9 to 790.0 (F°)
E	0 to 600 (C°) / -0 to 1100 (F°)	-60 to 660.0 (C°) / -110 to 1210 (F°)
L1	-100 to 850 (C°) / -100 to 1500 (F°)	-195 to 945 (C°) / -260 to 1660 (F°)
L2	0.0 to 400.0 (C°) / 0.0 to 750.0 (F°)	-40.0 to 440.0 (C°) / -75.0 to 825.0 (F°)
U	-199.9 to 400.0 (C°) / -199.9 to 700.0 (F°)	-199.9 to 650.0 (C°) / -199.9 to 999.9 (F°)
N	-200.0 to 1300 (C°) / -300 to 2300 (F°)	-199.9 to 460.0 (C°) / -199.9 to 790.0 (F°)
R	0 to 1700 (C°) / 0 to 3000 (F°)	-350 to 1450 (C°) / -560 to 2560 (F°)
S	0 to 1700 (C°) / 0 to 3000 (F°)	-170 to 1870 (C°) / -300 to 3300 (F°)
B	100 to 1800 (C°) / 300 to 3200 (F°)	-170 to 1870 (C°) / -300 to 3300 (F°)
W	0 to 2300 (C°) / 0 to 4100 (F°)	-70 to 1970 (C°) / 10 to 3490 (F°)
PLII	0 to 1300 (C°) / 0 to 2300 (F°)	-230 to 2530 (C°) / -410 to 4510 (F°)
4 to 20mA 0 to 20mA 1 to 5V 0 to 5V 0 to 10V	One of following ranges depending on results of scaling -1999 to 9999 -199.9 to 999.9 -19.99 to 99.99 -1.999 to 9.999	-10 to 110% of setting range. Note, however, that max. value is -1999 to 9999.


## ■ Output Unit Ratings and Characteristics

Ratings and characteristics conform to the output unit mounted on the controller. For details on the ratings of the output unit, see page 2-7.

## ■ Option Unit Ratings and Characteristics

Event inputs	Contact input	ON: 1kΩ max., OFF: 100kΩ min.
	No-contact input	ON: residual voltage 1.5 V max., OFF: leakage current 0.1 mA max.
Communications	Interface	:RS-232C, RS-422 or RS-485
	Transmission method	:Half-duplex
	Synchronization method	:Start-stop synchronization (asynchronous method)
	Baud rate	:1.2/2.4/4.8/9.6/19.2 kbps
Transfer output	DC 4 to 20 mA, Permissible load impedance: 600Ω max., Resolution: Approx. 2600	

# CONTROL BLOCK DIAGRAM



# SETTING LIST

Mode	Parameter Name	Setting Range	Unit	Default	Remarks	Setting
Protect	<b>SECr</b> Security	0 to 6	None	1		
	<b>KEYP</b> Key protect	0/1/2/3	None	0		
Manual	Manual MV	-5.0 to 105.0 *1	%	0.0		
Level 0	<b>PtErn</b> Pattern No.	0 to number of patterns -1	None	0		
	<b>HOLD</b> Hold	OFF/ON	None	OFF	At program operation	
	<b>Adv</b> Advance	OFF/ON	None	OFF	At program operation	
Program	<b>PtErn</b> Pattern No.	0 to number of patterns -1	None	0		
	<b>S-ns</b> Number of steps	1 to 16	None	8		
	<b>SP0 to 15</b> Steps 0 to 15 SP/ Target SP 0 to 7	SP lower limit to SP upper limit	EU	0		*2
	<b>Pr0 to 7</b> Ramp rate 0 to 7	0 to 9999	*3	0		*2
	<b>t0 to 15</b> Step 0 to 15 time/ Soak time 0 to 7	0.00 to 99.59	*4	0.00		*2
	<b>rPt</b> Pattern execution count	0 to 9999	Times	1		
	<b>AL-1</b> Alarm value 1	-1999 to 9999	EU	0		
	<b>AL-2</b> Alarm value 2	-1999 to 9999	EU	0		
	<b>AL-3</b> Alarm value 3	-1999 to 9999	EU	0		
	<b>tS1S</b> Time signal 1 enabled step	0 to 15	None	0		
	<b>on1</b> Time signal 1 ON time	0.00 to 99.59	*4	0.00		
	<b>off1</b> Time signal 1 OFF time	0.00 to 99.59	*4	0.00		
	<b>tS2S</b> Time signal 2 enabled step	0 to 15	None	0		
	<b>on2</b> Time signal 2 ON time	0.00 to 99.59	*4	0.00		
	<b>off2</b> Time signal 2 OFF time	0.00 to 99.59	*4	0.00		
Level 1	<b>At</b> AT Execute/Cancel	OFF/ AT-1/AT-2	None	OFF		
	<b>P</b> Proportional band	0.1 to 999.9	%FS	10.0		
	<b>I</b> Integral time	0 to 3999	sec	233		
	<b>d</b> Derivative time	0 to 3999	sec	40		
	<b>[ -SC</b> Cooling coefficient	0.01 to 99.99	None	1.00	At heating and cooling control	
	<b>[ -db</b> Dead band	-19.99 to 99.99	%FS	0.00	At heating and cooling control	
	<b>off-r</b> Manual reset value	0.0 to 100.0	%	50.0		
	<b>HYS</b> Hysteresis (heat)	0.01 to 99.99	%FS	0.10		
	<b>[HYS</b> Hysteresis (cool)	0.01 to 99.99	%FS	0.10	At heating and cooling control	
	<b>[P</b> Control period (heat)	1 to 99	sec	20		
	<b>[ -[P</b> Control period (cool)	1 to 99	sec	20	At heating and cooling control	

Mode	Parameter Name	Setting Range	Unit	Default	Remarks	Setting
Level 2	<b>r-L</b> Remote/Local	RMT/LCL	None	LCL		
	<b>Stb</b> Standby time	0.00 to 99.59	Hour, Min.	0.00		
	<b>LbA</b> LBA detection time	0 to 9999	Sec	0		
	<b>ñu-r</b> MV at reset	-5.0 to 105.0 *1	%	0.0		
	<b>ñu-E</b> MV at PV error	-5.0 to 105.0 *2	%	0.0		
	<b>ōL-H</b> MV upper limit	MV lower limit +0.1 to 105.0 *5	%	105.0		
	<b>ōL-L</b> MV lower limit	-5.0 to MV upper limit -0.1 *6	%	-5.0		
	<b>ōrL</b> MV change rate limiter	0.0 to 100.0	%FS	0.0		
	<b>īnF</b> Input digital filter	0 to 9999	sec	0		
	<b>ALH1</b> Alarm 1 hysteresis	0.01 to 99.99	%FS	0.02		
	<b>ALH2</b> Alarm 2 hysteresis	0.01 to 99.99	%FS	0.02		
	<b>ALH3</b> Alarm 3 hysteresis	0.01 to 99.99	%FS	0.02		
	<b>īnSH</b> Input shift upper limit	-199.9 to 999.9	°C/°F	0.0	Temperature input	
	<b>īnSL</b> Input shift lower limit	-199.9 to 999.9	°C/°F	0.0	Temperature input	
Setup	<b>īn-t</b> Input type	0 to 21	None	2		
	<b>īn-H</b> Scaling upper limit	Scaling lower limit +1 to 9999	None	100	Analog input	
	<b>īn-L</b> Scaling lower limit	-1999 to scaling upper limit -1	None	0	Analog input	
	<b>dP</b> Decimal point	0 to 3	None	0	Analog input	
	<b>d-U</b> °C/°F selection	°C/°F	None	°C	Temperature input	
	<b>īnīē</b> Parameter initialize	Yes/No	None	NO		
	<b>ōUē1</b> Control output 1 assignment	*7	None	HEAT		
	<b>ōUē2</b> Control output 2 assignment	*7	None	AL-1		
	<b>SUē1</b> Auxiliary output 1 assignment	*8	None	AL-2		
	<b>ALē1</b> Alarm 1 type	1 to 11	None	2	Output assignment needed	
	<b>AL1n</b> Alarm 1 open in alarm	N-O/N-C	None	N-O	Output assignment needed	
	<b>ALē2</b> Alarm 2 type	1 to 11	None	2	Output assignment needed	
	<b>AL2n</b> Alarm 2 open in alarm	N-O/N-C	None	N-O	Output assignment needed	
	<b>ALē3</b> Alarm 3 type	1 to 11	None	2	Output assignment needed	
	<b>AL3n</b> Alarm 3 open in alarm	N-O/N-C	None	N-O	Output assignment needed	
	<b>ōrEu</b> Direct/Reverse operation	OR-R/OR-D	None	OR-R		

\*1 During heating and cooling control, the lower limit becomes -105.0%

\*2 Use "Program List" (page A-11) for the setting value of each step.

\*3 EU/Time unit of ramp rate

\*4 Program time unit

\*5 During heating and cooling control, the setting range becomes 0.0 to 105.0%.

\*6 During heating and cooling control, the setting range becomes -105.0 to 0.0%.

\*7 HEAT/COOL/AL-1/AL-2/AL-3/HBA/LBA/TS-1/TS-2/PEND/STG

\*8 AL-1/AL-2/AL-3/HBA/LBA/TS-1/TS-2/PEND/STG/S.ERR/E333

Mode	Parameter Name	Setting Range	Unit	Default	Remarks	Setting
Expansion	<b>SL-H</b> Set point upper limit	Set point lower limit +1 to scaling upper limit	EU	1300	*9	
	<b>SL-L</b> Set point lower limit	Scaling lower limit to Set point upper limit -1	EU	-200	*9	
	<b>OnEL</b> PID / ON/OFF	PID / ON/OFF	None	PID		
	<b>P-on</b> Operation at power ON	CON/RST/RUN/MAN	None	CON		
	<b>ESSE</b> End condition	RST/SP	None	RST		
	<b>P-no</b> Number of patterns	1 to 4	None	1		
	<b>t-U</b> Program time unit	HHMM/MMSS	None	HHMM		
	<b>t-Pr</b> Step time/Rate of rise programming	TIME/PR	None	OFF		
	<b>PrU</b> Time unit of ramp rate	M/H	None	OFF		
	<b>PnSt</b> PV start	PV/SP	None	SP		
	<b>rPRL</b> Alarm during ramp step enable	ON/OFF	None	ON		
	<b>rUnR</b> Run all enable	ON/OFF	None	OFF		
	<b>ALFA</b> $\alpha$	0.00 to 1.00	None	0.65		
	<b>At-G</b> AT calculated gain	0.1 to 10.0	None	1.0		
	<b>rEt</b> Automatic return of display mode	0 to 99	Sec	0		
	<b>At-H</b> AT hysteresis	0.1 to 9.9	%FS	0.2		
	<b>LbAb</b> LB detection width	0.0 to 999.9	%FS	0.2		
Option	<b>Eu-1</b> Event input assignment 1	NON/RST/MAN/HOLD/ADV/PTN0 to 1	None	NON		
	<b>StEt</b> Communication stop bit	1/2	bit	2		
	<b>LEn</b> Communication data length	7/8	bit	7		
	<b>PrEtY</b> Communication parity	NONE/EVEN/ODD	None	EVEN		
	<b>bPS</b> Communication baud rate	1.2/2.4/4.8/9.6/19.2	kbps	9.6		
	<b>U-no</b> Communication unit No.	0 to 99	None	0		
	<b>tr-t</b> Transfer output type	SP/PV/O/C-O	None	SP		
	<b>tr-H</b> Transfer output upper limit	*10	*10	10		
	<b>tr-L</b> Transfer output lower limit	*10	*10	*10		

\*9 When temperature input is selected, the range of the sensor selected in the “input type” parameter (setup mode) corresponds to the scaling upper and lower limit value.

\*10 Set the transfer output type parameter according to the following table.

Transfer Output Type		Transfer Output Lower Limit to Transfer Output Upper Limit
SP	:Present SP	-1999 to 9999
PV	:Process value	-1999 to 9999
O	:Manipulated variable (heat)	-5.0 to 105.0% (standard control), 0.0 to 105.0% (heating and cooling control)
C-O	:Manipulated variable (cool)	0.0 to 105.0%

- Default : [SP]

### Time Setup Program List

Program name

Pattern No.

Pattern execution count

Program time unit: Hour, minute/minute, second

Alarm value 1:

$$/2: /3:$$
[illegible]




## MODEL LIST

Description	Type Name	Specification
Base unit	E5CK-TAA1 AC100-240	Base Unit
	E5CK-TAA1-500 AC100-240	Base Unit with terminal cover
	E5CK-TAA1 AC/DC24	Base Unit
	E5CK-TAA1-500 AC/DC24	Base Unit with terminal cover
Output module	E53-R4R4	Relay/relay
	E53-Q4R4	Pulse (NPN)/relay
	E53-Q4HR4	Pulse (PNP)/relay
	E53-C4R4	Linear (4 to 20mA)/relay
	E53-C4DR4	Linear (0 to 20mA)/relay
	E53-V44R4	Linear (0 to 10V)/relay
	E53-Q4Q4	Pulse (NPN)/pulse (NPN)
	E53-Q4HQ4H	Pulse (PNP)/pulse (PNP)
Option module	E53-CK01	RS-232C
	E53-CK03	RS-485
	E53-CKB	Event input : 1 point
	E53-CKF	Transfer output (4 to 20mA)
Terminal cover	E53-COV07	Terminal cover for E5CK-T

The output unit is required for E5CK-TAA1 (including -500). For details on the output unit, see page 2-3.  
When adding on the option unit, also see the option unit list on page 2-3.

# PARAMETER OPERATIONS LIST

- Switching to modes other than the manual or protect mode is carried out by mode selection in the menu display.
- The figure below shows all parameters in the order that they are displayed. Some parameters are not displayed depending on the protect mode setting and conditions of use.



Level 0	Program	Level 1
PV/Present SP	<i>Pt rn</i> Pattern No.	<i>At</i> AT Execute/Cancel
<i>Pt rn</i> Pattern No.	<i>S - nō</i> Number of steps	<i>P</i> Proportional band
<i>StEP</i> Step No. monitor	<i>SP0</i> to <i>7</i> Step 0 to 7 SP *1	<i>I</i> Integral time
<i>Hōld</i> Hold	<i>Pr0</i> to <i>7</i> Ramp rate 0 to 7 *1	<i>d</i> Derivative time
<i>Adv</i> Advance	<i>t0</i> to <i>7</i> Step 0 to 7 time	<i>C - SC</i> Cooling coefficient
<i>Stbn</i> Standby time monitor	<i>SP8</i> to <i>15</i> Step 8 to 15 SP	<i>C - db</i> Dead band
<i>tLnE</i> Pattern elapsing time monitor	<i>t8</i> to <i>15</i> Step 8 to 15 time	<i>db</i> Position-proportional dead band
<i>rPt rn</i> Pattern execution count monitor	<i>rPt</i> Pattern execution count	<i>ōF - r</i> Manual reset value
<i>tō</i> MV monitor (heat)	<i>AL - 1</i> Alarm value 1	<i>HYS</i> Hysteresis (heat)
<i>C - ō</i> MV monitor (cool)	<i>AL - 2</i> Alarm value 2	<i>CHYS</i> Hysteresis (cool)
	<i>AL - 3</i> Alarm value 3	<i>CP</i> Control period (heat)
	<i>tS 15</i> Time signal 1 enabled step	<i>C - CP</i> Control period (cool)
	<i>ōn 1</i> Time signal 1 ON time	
	<i>ōF 1</i> Time signal 1 OFF time	
	<i>tS 25</i> Time signal 2 enabled step	
	<i>ōn 2</i> Time signal 2 ON time	
	<i>ōF 2</i> Time signal 2 OFF time	

\*1 In the rate of rise setting, Target SP 0 to 7 and Soak time 0 to 7.

## Level 2

<b>r-l</b>	Remote/Local
<b>Stb</b>	Standby time
<b>LbA</b>	LBA detection time
<b>ñu-r</b>	MV at reset
<b>ñu-E</b>	MV at PV error
<b>õL-H</b>	MV upper limit
<b>õL-L</b>	MV lower limit
<b>õrL</b>	MV change rate limit
<b>LnF</b>	Input digital filter
<b>ALH1</b>	Alarm 1 hysteresis
<b>ALH2</b>	Alarm 2 hysteresis
<b>ALH3</b>	Alarm 3 hysteresis
<b>LnSH</b>	Input shift upper limit
<b>LnSL</b>	Input shift lower limit

## Setup

<b>Ln-t</b>	Input type
<b>Ln-H</b>	Scaling upper limit
<b>Ln-L</b>	Scaling lower limit
<b>dP</b>	Decimal point
<b>d-U</b>	°C/°F selection
<b>LnLt</b>	Parameter initialize
<b>õUt1</b>	Control output 1 assignment
<b>õUt2</b>	Control output 2 assignment
<b>SUb1</b>	Auxiliary output 1 assignment
<b>ALt1</b>	Alarm 1 type
<b>ALIn</b>	Alarm 1 open in alarm
<b>ALt2</b>	Alarm 2 type
<b>AL2n</b>	Alarm 2 open in alarm
<b>ALt3</b>	Alarm 3 type
<b>AL3n</b>	Alarm 3 open in alarm
<b>õrEu</b>	Direct/Reverse operation

## Expansion

<b>SL-H</b>	Set point upper limit
<b>SL-L</b>	Set point lower limit
<b>LnLt</b>	PID / ON/OFF
<b>P-õn</b>	Operation at power ON
<b>ESEt</b>	End condition
<b>P-nõ</b>	Number of patterns
<b>t-U</b>	Program time unit
<b>t-Pr</b>	Step time/Rate of rise programming
<b>PrU</b>	Time unit of ramp rate
<b>PnSt</b>	PV start
<b>rPRL</b>	Alarm during ramp step enable
<b>rUnA</b>	Run all enable
<b>ALFA</b>	$\alpha$
<b>At-G</b>	AT calculated gain
<b>rEt</b>	Automatic return of display mode
<b>At-H</b>	AT hysteresis
<b>LbAb</b>	LBA detection width

## Option

<b>Eu-1</b>	Event input assignment 1
<b>SbLt</b>	Communication stop bit
<b>LEn</b>	Communication data length
<b>Prty</b>	Communication parity
<b>bPS</b>	Communication baud rate
<b>U-nõ</b>	Communication unit No.
<b>tr-t</b>	Transfer output type
<b>tr-H</b>	Transfer output upper limit
<b>tr-L</b>	Transfer output lower limit

## Calibration

For details, refer to Chapter 7 Calibration/7.1 Structure of Parameters" (page 7-2).

## Manual

☐ Manual MV

## Protect

<b>SECr</b>	Alarm 1 open in alarm
<b>PEYP</b>	Alarm 2 type

# ASCII CODE LIST

Hex		0	1	2	3	4	5	6	7	Upper 4 bits
	Bin	0000	0001	0010	0011	0100	0101	0110	0111	
0	0000			SP	0	@	P		p	
1	0001			!	1	A	Q	a	q	
2	0010			"	2	B	R	b	r	
3	0011			#	3	C	S	c	s	
4	0100			\$	4	D	T	d	t	
5	0101			%	5	E	U	e	u	
6	0110			&	6	F	V	f	v	
7	0111			'	7	G	W	g	w	
8	1000			(	8	H	X	h	x	
9	1001			)	9	I	Y	i	y	
A	1010			*	:	J	Z	j	z	
B	1011			+	;	K	[	k	{	
C	1100			,	<	L	¥	l		
D	1101			-	=	M	]	m	}	
E	1110			.	>	N	^	n	~	
F	1111			/	?	O	—	o	DEL	

Lower 4 bits

## Symbols

°C/°F selection ..... 5–31

## Numbers

100%AT ..... 3–24

40%AT ..... 3–24

## A

A group ..... 6–11

A/D converter error ..... 8–3, 8–5

A/M key ..... 1–4

About Calibration ..... 1–12

About Changing the Number of Steps ..... 3–21

About Errors That Occur During Motor  
Calibration ..... 8–4

About invalid parameters ..... 6–5

About ON conditions ..... 4–13

About parameter display ..... 5–2

About Pattern Elapsing Time ..... 4–13

About PID Parameters ..... 3–25

About Reset ..... 4–12

About the Alarm Value Decimal Point ..... 3–15

About the Communications Function ..... 1–11

About the displays ..... 1–3

About the Order in Which Parameters  
Described in This Chapter ..... 5–2

About the Unit No. .... 6–15

Advance ..... 4–18, 5–8

Alarm 1 hysteresis ..... 5–26

Alarm 1 open in alarm ..... 5–35

Alarm 1 type ..... 5–34

Alarm 2 hysteresis ..... 5–26

Alarm 2 open in alarm ..... 5–35

Alarm 2 type ..... 5–34

Alarm 3 hysteresis ..... 5–26

Alarm 3 open in alarm ..... 5–35

Alarm 3 type ..... 5–34

Alarm hysteresis ..... 3–10

Alarm type ..... 3–9

Alarm value ..... 3–9, 3–15

Alarm value 1 ..... 5–14

Alarm value 2 ..... 5–14

Alarm value 3 ..... 5–14

Alfa ..... 5–42

Analog input ..... 3–5

ASCII CODE LIST ..... A–13

AT Execute/Cancel ..... 5–18

AT Execution Timing ..... 3–25

Auto-tuning (A.T.) ..... 3–24

Auto-turning key ..... 1–4

Auto/Manual ..... 4–18

Auxiliary output 1 ..... 2–8

Auxiliary output 1 assignment ..... 5–33

## B

B group ..... 6–11

Balance-less, Bump-less Operation .. 3–23

Basic Operation Flow ..... 3–2

## C

Cable connections ..... 6–3

Calibrating Current Input ..... 7–9

Calibrating inputs ..... 1–12

Calibrating Platinum Resistance  
Thermometers ..... 7–7

Calibrating Thermocouples ..... 7–4

Calibrating transfer output ..... 1–12

Calibrating Voltage Input ..... 7–10

Calibration ..... 7–7, 7–9

Calibration data error ..... 8–4

Calibration item menu ..... 7–3

Calibration Mode ..... 1–9

Calibration: 0 to 10V ..... 7–11

Calibration: 0 to 5V, 1 to 5V ..... 7–10

Calibration: thermocouple 1 ..... 7–5

Calibration: thermocouple 2 ..... 7–6

Changing parameters ..... 4–8

Changing programs ..... 3–21

Changing the SP ..... 3–21

Changing the time value ..... 3–21

Characteristics ..... A–3

Checking Indication Accuracy ..... 7–12

Checking indication accuracy ..... 7–12

Checking Operation Restrictions ..... 8–6

Close in alarm/open in alarm ..... 3–10

Command Structure ..... 6–5

Commands and Responses ..... 6–7

Communication baud rate ..... 5–46

Communication data length ..... 5–46

Communication parity ..... 5–46

Communication stop bit ..... 5–46

Communication unit No. .... 5–46

Communications parameters ..... 6–4

Conditions when running a program .. 6–17

Connecting the Cold Junction  
Compensator ..... 7–4

CONTROL BLOCK DIAGRAM ..... A–5

Control output ..... 2–7

Control output 1 assignment ..... 5–32

Control output 2 assignment ..... 5–32

Control period ..... 3–8

Control period (cool) ..... 5–21

Control period (heat) ..... 5-21  
 Convention Used in this Chapter ..... 3-2  
 Conventions Used in this Chapter ..... 5-2  
 Cooling coefficient ..... 4-2, 5-19  
 Current input ..... 1-5  
 Current input or Voltage input ..... 7-13

**D**

Dead band ..... 4-2, 5-19  
 Decimal point ..... 5-30  
 Derivative time ..... 5-18  
 Detailed description of input functions ..... 4-18  
 Determining the LBA detection time .. 4-20  
 Dimensions ..... 2-4  
 Direct/Reverse operation ..... 3-7, 5-35  
 Display range over ..... 8-4  
 Down key ..... 1-4  
 Draw-out ..... 2-2

**E**

End code ..... 6-15  
 End condition ..... 4-16, 5-38  
 Event input ..... 1-5  
 Event input assignment 1 ..... 5-45  
 Examples of use ..... 6-19  
 Executing all patterns ..... 4-11  
 Expansion Mode ..... 1-9, 5-36

**F**

Fixing settings ..... 1-10  
 Front panel ..... 1-2

**H**

Heating and cooling control ..... 4-2  
 Hold ..... 5-8  
 Hold/advance ..... 4-10  
 Hold/Hold cancel ..... 4-18  
 How the program works ..... 4-9  
 How to Calculate FCS ..... 6-6  
 How to Read Communications  
   Error Information ..... 6-15  
 How to use keys ..... 1-4  
 How to use programs ..... 6-17  
 How to Use the Error Display ..... 8-3  
 How to Use the Error Output ..... 8-5  
 How to Use Transfer Output ..... 4-21  
 Hysteresis ..... 4-4  
 Hysteresis (cool) ..... 5-20  
 Hysteresis (heat) ..... 5-20

**I**

Initial Checks ..... 8-2

Input ..... 2-7  
 Input and Output ..... 1-5  
 Input assignments ..... 4-17  
 Input digital filter ..... 5-26  
 Input error ..... 8-3  
 Input errors ..... 8-5  
 Input shift lower limit ..... 5-27  
 Input shift upper limit ..... 5-27  
 Input type ..... 3-4, 5-29  
 Installation ..... 2-4  
 Integral time ..... 5-18  
 Interface ..... 6-2  
 Issuing special commands ..... 6-10

**K**

Key protect ..... 3-18, 5-4

**L**

LBA ..... 4-19, 8-5  
 LBA detection example ..... 4-19  
 LBA detection time ..... 4-19, 5-24  
 LBA detection width ..... 4-19  
 Level 0 Mode ..... 1-8, 5-6  
 Level 1 Mode ..... 1-8, 5-17  
 Level 2 Mode ..... 1-8, 5-22  
 Limiter operation conditions ..... 4-6

**M**

Main parts ..... 1-2  
 Manipulated variable at reset ..... 4-3  
 Manipulated variable at stop ..... 3-20  
 Manipulated variable restrictions ..... 4-5  
 Manual Mode ..... 1-8, 5-5  
 Manual MV ..... 5-5  
 Manual reset value ..... 5-20  
 Memory error ..... 8-3  
 MODEL LIST ..... A-10  
 Monitor process value ..... 6-19  
 MV at PV error ..... 5-24  
 MV at reset ..... 5-24  
 MV change rate limit ..... 5-25  
 MV change rate limiter ..... 4-5  
 MV limiter ..... 4-5  
 MV lower limit ..... 5-25  
 MV monitor (cool) ..... 5-10  
 MV monitor (heat) ..... 5-10  
 MV upper limit ..... 5-25

**N**

Names of parts ..... 1-2  
 No.1 display ..... 1-3  
 No.2 display ..... 1-3

Number of patterns ..... 5-39  
 Number of steps ..... 3-14, 5-12

## O

ON/OFF control ..... 4-4  
 Operating Condition Restrictions ..... 4-5  
 Operation at Input Error ..... 4-9  
 Operation at power ON ..... 4-15, 5-38  
 Operation indicator LEDs ..... 1-3  
 Option ..... 2-8  
 Option Mode ..... 1-9, 5-44  
 Option Unit Ratings and  
   Characteristics ..... A-4  
 Outline ..... 6-2  
 Outline of the Communications  
   Function ..... 6-2  
 Output ..... 1-6  
 Output assignments ..... 1-6, 3-7  
 Output Unit Ratings and  
   Characteristics ..... A-4

## P

Panel cutout ..... 2-4  
 Parameter initialize ..... 5-31  
 PARAMETER OPERATIONS LIST .. A-11  
 Parameter Structure ..... 7-2  
 Parameter types ..... 1-8  
 Parameters and Menus ..... 1-8  
 Pattern elapsing time ..... 5-9  
 Pattern execution count ..... 5-14  
 Pattern execution count monitor ..... 5-9  
 Pattern No. .... 3-14, 5-7  
 Pattern operation ..... 4-11  
 Pattern select ..... 4-18  
 PID/ON/OFF ..... 5-37  
 Platinum resistance thermometer .... 7-12  
 Power supply ..... 2-6  
 Precautions when wiring ..... 2-6  
 Preparation ..... 7-7, 7-9, 7-10  
 Preparations ..... 7-4  
 Preparing for Communications ..... 6-3  
 Procedure ..... 6-17  
 Program ..... 1-7  
 Program end ..... 4-14  
 Program Example ..... 6-17  
 Program example ..... 4-9  
 Program list ..... 6-18  
 Program Mode ..... 5-11  
 Program mode ..... 1-8  
 Program Operation ..... 4-10  
 Program output ..... 4-13, 4-14

Program structure ..... 4-9  
 Proportional band ..... 5-18  
 Protect Mode ..... 1-8, 3-18, 5-3  
 PV start ..... 4-16, 5-41  
 PV/Present SP ..... 5-6

## R

Ramp rate 0 ..... 5-13  
 Ramp rate 7 ..... 5-13  
 Ramp Rise Rate Setup Program ..... 4-7  
 Reading parameters ..... 6-7, 6-12  
 Reading/writing parameters ..... 6-7  
 Reading/writing program  
   parameters ..... 6-12  
 Registering calibration data ..... 1-12  
 Relationship with the  
   number of steps ..... 4-8  
 Remote/Local ..... 5-23  
 Repeating execution of the  
   same pattern ..... 4-11  
 RS-232C ..... 1-11, 6-3  
 RS-485 ..... 1-11, 6-3  
 Run/Reset ..... 4-18  
 Running the ramp rise  
   rate setup program ..... 4-8

## S

Scaling lower limit ..... 5-30  
 Scaling upper limit ..... 5-30  
 Security ..... 3-18, 5-3  
 Selecting modes ..... 1-9  
 Selecting parameters ..... 1-10  
 Selecting the Control Method ..... 4-2  
 Sensor Input Setting Ranges  
   and Indication Ranges ..... A-4  
 Set point limiter ..... 4-6  
 Set point lower limit ..... 5-37  
 Set point upper limit ..... 5-37  
 Set the set point to "300.0" ..... 6-19  
 Setting Alarm Type ..... 3-9  
 Setting Input Specifications ..... 3-4  
 SETTING LIST ..... A-6  
 Setting Output Specifications ..... 3-7  
 Setting Patterns ..... 3-13  
 Setting Running Conditions ..... 4-15  
 Setting the communications  
   specifications ..... 6-4  
 Setting the input type jumper ..... 2-2  
 Setting the LBA detection time ..... 4-20  
 Setup ..... 2-2  
 Setup examples ..... 3-3  
 Setup Mode ..... 1-8, 5-28  
 SPECIFICATIONS ..... A-2

Stage output .....	4-14
Standard type .....	3-7
Standby operation .....	4-16
Standby sequence .....	3-10
Standby time .....	5-23
Standby time monitor .....	5-9
Start running .....	6-19
Starting and Stopping Operation .....	3-20
Starting the program run .....	4-16
Step 0 time (Step time) .....	5-12, 5-13
Step 15 SP (Step time) .....	5-12
Step 15 time (Step time) .....	5-13
Step 7 SP (Step time) .....	5-12
Step 7 time (Step time) .....	5-13
Step 8 SP (Step time) .....	5-12
Step 8 time (Step time) .....	5-13
Step No. monitor .....	5-7
Step operation .....	1-7
Step SP/Step time .....	3-14
Summary of alarm operations .....	3-11
Switching with Manual Operation .....	4-3

## T

Temperature input .....	1-5, 3-5
Temperature input shift .....	3-5
Temperature unit .....	3-5
Terminal arrangement .....	2-6
The meaning of icons used in this chapter .....	5-2

Thermocouple .....	7-12
Time signal .....	4-13
Time signal 1 enabled step .....	5-15
Time signal 1 OFF time .....	5-16
Time signal 1 ON time .....	5-15
Time signal 2 enabled step .....	5-15
Time signal 2 OFF time .....	5-16
Time signal 2 ON time .....	5-15
Time unit of ramp rate .....	5-40
Transfer output .....	1-6
Transfer output lower limit .....	5-47
Transfer output scaling .....	4-21
Transfer output type .....	4-21, 5-47
Transfer output upper limit .....	5-47
Transfer procedure .....	6-2

## U

Undefined error .....	6-16
Up key .....	1-4
Using Event Input .....	3-20

## V

Voltage input .....	1-5
---------------------	-----

## W

When the rate of rise is set to "0",	4-8
Wiring .....	2-6
Wiring Terminals .....	2-6
Writing parameters .....	6-7, 6-1



# Revision History

A manual revision code appears as a suffix to the catalog number on the front cover of the manual.

Cat. No. H090-E1-01B



Revision code

The following table outlines the changes made to the manual during each revision. Page numbers refer to previous version.

Revision code	Date	Revised content
1	September 1997	Original Production
01A	December 2004	<b>Page A-3:</b> Added information to table and accompanying notes.
01B	July 2006	<b>Page 4-15:</b> Changed descriptions for “Reset” and “Run” selection. <b>Page 4-15:</b> Added a note describing “—” after the table. <b>Pages 4-16 and 5-38:</b> Added a note at the end of <i>End Condition</i> . <b>Page A-7:</b> Changed the unit for alarm hysteresis from “%” to “%FS.”



**OMRON Corporation**  
**Industrial Automation Company**

**Control Devices Division H.Q.**  
**Analog Controller Division**  
Shiokoji Horikawa, Shimogyo-ku,  
Kyoto, 600-8530 Japan  
Tel: (81)75-344-7080/Fax: (81)75-344-7189

***Regional Headquarters***

**OMRON EUROPE B.V.**  
Wegalaan 67-69, NL-2132 JD Hoofddorp  
The Netherlands  
Tel: (31)2356-81-300/Fax: (31)2356-81-388

**OMRON ELECTRONICS LLC**  
1 East Commerce Drive, Schaumburg, IL 60173  
U.S.A.  
Tel: (1)847-843-7900/Fax: (1)847-843-8568

**OMRON ASIA PACIFIC PTE. LTD.**  
83 Clemenceau Avenue,  
#11-01, UE Square,  
239920 Singapore  
Tel: (65)6835-3011/Fax: (65)6835-2711

**OMRON (CHINA) CO., LTD.**  
Room 2211, Bank of China Tower,  
200 Yin Cheng Road (M),  
Shanghai, 200120 China  
Tel: (86)21-5037-2222/Fax: (86)21-5037-2200

Authorized Distributor: